


Bone conduction earphone



Instructions for usage and warranty
Operating instructions and Warranty description



Charge

The headphone uses a built-in rechargeable battery, the first use of the headphone must be fully charged to the battery. In use, if the voice prompts "low battery", the battery is low, and you need to charge the headphone.

The charging cable should be connected to the headphone magnetic charging port, about 2 hours to be fully charged. The charging status: Red light (always on), full charge is always on the blue light.

Note : Magnetic charging has a positive and negative polarity correspondence, mutual adsorption can be charged normally, and mutual repulsion will not charge or even cause a short circuit.

Warning : The rechargeable battery of this product must be disposed of properly for recycling. Please do not put the battery into the fire, so as not to cause an explosion.

Operating instruction

Function	Operation	Indicator
On	Press and hold Power button (around 3-5 seconds)	Light on
Off		Light off

Music Play

How to pair with Bluetooth

Bluetooth pairing: In the off state, press and hold the power button for 2 seconds, the light into the red and blue flashing state, and then enter the pairing state. Turn on the Bluetooth (cell phone/computer) on the device and search for the device name "S800Pro2", click the device "S800Pro2" to pair and connect.

Bluetooth / MP3 mode switching: Double click the power button (multi-function composite button) to freely switch between Bluetooth and memory mode.

For example: You can directly control the earphone areas:

What time is it now.....Today's weather.....

Navigate to Taipei 101.....Call someone

Emphasis: The power on automatically default Bluetooth mode status.

Answer the phone

Song download(USB name:S800Pro2): Connect the original charging data cable to the computer and headset to read Take a USB flash drive and copy the computer song to the USB flash drive

TF card playback mode switch: When playing audio in TF card mode, triple-click 'POWER' to switch between shuffle and sequential playback modes (with memory function)

Indicator

Charging	Red light (always on)
Charging completed	Blue light (always on)
Search for pairing	Flash in red and blue alternately
Bluetooth music playback	Blue light flashes once every 5 sec.

Operating instruction

AI intelligent voice control

(Phone needs to support voice wake-up function)

Function

Headphone status

Operation

Increase volume

Play music

Click "+"

Reduce volume

Play music

Click "-"

Previous song

Play music

Long press for 1s "-"

Next song

Play music

Long press for 1s "+"

Pause

Play music

Click the Power button

Resume

Pause

Product parameter

* Charging time: About 2 hours

* Distance: Bluetooth 10 meters

* Battery: 180mAh

* Play: ≈5 hours@65% volume

* Agreement: A/RCP_V1.6.2/HF_V1.7.2/A/D_V1.2

* Bluetooth communication protocol

* Music format support: MP3,WAV,WMA,APE,LAC,AAC,M4A

* Waterproof grade: IPX8

* Version: 6.0

* Input: 5V/140mA

C Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna; increase the separation between the equipment and receiver; connect the equipment into an outlet on a circuit different from that which the receiver is connected; consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Maintenance and cleaning

- The headphones can not soak in water for a long time, they use fresh water to rinse and dry. Charging electromagnetic suction parts is easy to corrode.
- If not used for a long time, please at least once a month full charge.

TF card playback mode switch: When playing audio in TF card mode, triple-click 'POWER' to switch between shuffle and sequential playback modes (with memory function)

Indicator

Charging	Red light (always on)
Charging completed	Blue light (always on)
Search for pairing	Flash in red and blue alternately
Bluetooth music playback	Blue light flashes once every 5 sec.