




Electric Scooter

Welcometouse

Thankyou for choosing this electric scooter (hereinafter referred to electric scooter ,electric scooter is a stylish sports entertainment equipment)

For damaged or defective product,questions, replacement pars or any other service support, please contact our customer service department by the below methods:

✉ cs@cubewalk.com

Respond within 48 hours

Contact us with your Amazon Order Number in your email or text to get a quick response


Please contact CUSTOMER SERVICE before returning.

Contents

1. Product and parts.....	2
2. Functional sketch	3
3. Body assembly.....	5
4. Charge connection.....	5
5. Learning to drive.....	6
6. Safety instructions.....	7
7. Folding and transporting.....	10
8. Daily maintenance.....	10
9. Model parameter table.....	12
10. Name and content of harmful substance in the product.....	13
11. Warranty policy.....	14

1.Product and parts

Whole scooter



Access

Screwx4



Socket head wrench




Charging adapter




Please carefully check whether the contents of the box are intact.

2.Functional sketch



The control panel



2.1.Control panel and applications

- 1 Actual speed
- 2 Indicator of connected device using Bluetooth
- 3 Driving modes (W-walk; ECO-economy; D-drive)
- 4 Light on
- 5 Walk mode-walking speed reduction
- 6 Scooter overheat indicator -when the temperature exceeds 80°C
- 7 Device fault indicator -contact service centre
- 8 Battery level indicator
- 9 ON/OFF switch button

2.2.Driving modes

Switching between driving modes is done by double-clicking the ON/OFF switch button.

Walk up to 4 mph

Eco up to 9 mph

Drive up to 16 mph

2.3.Starting the operating mode

- 1) Turn on the scooter.
- 2) Press and hold the speed control fully until the display shows 16.
- 3) Hold the gear lever and press the brake lever at the same time.
- 4) Release the brake lever.
- 5) You will be switched to the last set driving mode.

2.4.Connect bluetooth function

- 1)Download the Tuya app.
- 2)Press the switch 3 times to activate bluetooth.
- 3)Find the scooter connection request on the app.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

ISED Canada Statement:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada 's licence exempt RSS(s). Operation is subject to the following two conditions:

- 1)this device may not cause interference and
- 2)this device must accept any interference, including interference that may cause undesired operation of the device.

Radiation Exposure: This equipment complies with Canada radiation Exposure limits set forth for an uncontrolled environment to maintain compliance with IC's RF Exposure guidelines. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Déclaration du Canada:

Ce dispositif contient un (S) émetteur (S)/ récepteur (S) exempté (S) de licence qui respecte l' innovation, Science et développement économique Canada a exempté le ou les RSS de licence. L' exploitation est soumise aux deux conditions suivantes:


- 1) cet appareil ne doit pas causer d' interférences et
- 2) ce dispositif doit accepter toute interférence, y compris toute interférence pouvant entraîner un fonctionnement indésirable du dispositif.

Exposition au rayonnement: cet équipement est conforme au rayonnement Canada


Les limites d' exposition fixées pour un environnement non contrôlé afin de maintenir la conformité avec les lignes directrices d' exposition aux RF d' IC. Ce dispositif et ses antennes ne doivent pas être co-localisés ni fonctionner en conjonction avec une autre antenne ou un autre émetteur.

3.Body assembly


1. Secure the scooter st and pope and open the parking bracket.



2. Install the crossbar on the st and pipe.



3. Use the hex vrench in the packing box to lock screws on both sides.



4. After the completion of the installation to carry out switch detection.




4.Charger connection



1. Open the rubber stopper




2. Insert the charging plug




3. After checking, close the rubber stopper

5. Learn to drive




There is a risk of falling injury during the study period, so please wear a helmet and a protective gear as shown




1. Turn on the power and check the power indicator




2. Single foot stand on the board, the other foot pedal back



3. After electric scooter slide, the other foot pedal, when feet remain stable, tap the port finger (to be 5km/h above the speed will start the throttle)



4. Release the throttle finger can slow deceleration, energy recovery system automatically open to help slow down, emergency brake need to shake the brake, handle at the front left handle



5. When the focus is slightly tilted to the steering direction, and slowly turn the handle

6.Safety instructions


Avoid security risks



Please avoid riding in the rain




Encounter deceleration zone/elevator threshold/potholes and other unconventional roadpavement,please donot pass at high-speed.Encounter rough road,please keep in the low speed(5-10km/h).As light kneeling allows you to better adapt to the complexroad



To avoid the head hit the door frame, elevators and other obstacles



Do not accelerate at downhill



Do not press the throttle when walking



Please avoid obstacles to ride the electric scooter



Do not hang heavy objects such as backpack on the handlebar


Do not try the dangerous actions



Do not on the pedaler on the ground




Prohibit the ride electric scooter into the motor scooter lane and the car mixed with the residential



It is forbidden to turn the handle at high speed




It is forbidden to travel in more than 2cm-water




Prohibit many people at same time driving an electric scooter or driving with children




It is forbidden to step on the back of the fender



Do not touch the disc brakes



It is forbidden to not hold the handlebar when driving




It is forbidden to ride electric scooters upstairs and downstairs or jump obstacles

Safety instructions


- An electric scooter is a sporting entertainment tool that is not a scooter, but once you drive it into a public area, it will also have a scooter property, so there are also possible safety risks for all modes of transport. Strictly following the instructions in this manual to drive for the maximum extent to protect you and the others' safety, and to ensure compliance with national and provincial traffic regulations and traffic regulations.
- At the same time, you need to understand: Once you have an electric scooter on a public road or other public place, you may be exposed to the risk of unauthorized driving/improper operation of others' scooters, even if you are in full compliance with this safe driving guide. Like walking or cycling may also be hurt by other means of transport. As with all scooters, the faster the electric scooter is driving, the longer the brakes need, and the emergency brakes on some smooth surfaces can also cause the wheels to slip and lose balance or even fall. Therefore, it is important to be vigilant and maintain the proper speed during driving, and it is important to maintain a reasonable safety distance with others and the transport means. Please be vigilant and drive a low speed before entering unfamiliar terrain.
- Please respect the right of pedestrian way when driving. Avoid frightening pedestrians, especially the children. When pedestrians are passing through, remind pedestrians and slow down when passing. As far as possible from the left side of the pedestrian (applicable to the country where the scooter is traveling right). Face to face with pedestrians, keep on the right and lower speed.

- We must strictly follow the safety requirements of this manual for drivers in countries and regions, where there are no national standards and regulations for electric scooters shall not be liable for any liability, personal injury, accident, legal dispute, and all other unfavorable events resulting from the use of violating the instructions indicated in this manual.
- Do not lend the electric scooter to a person who does not operate to avoid injury. If give the electric scooter to a friend, be sure to be responsible for the safety of your friends, you should teach him (her), and tell him (her) must wear safety care.
- Please check the electric scooter for each time before driving. If you find that the parts are loose, the battery life is obviously reduced, the tire is slow to leak or excessive wear, turn to abnormal sound or malfunction, please stop using it immediately, and do not driving force.

7. Folding and transporting



Make sure that the electric scooter is turned off, the standpipe will dip through folding, open the folding wrench, and aim at the bell position and hook the bell with the rear mudguard. When opening you need to press the bell hook at the hook, until the bell hook is out of the stall after the hook, the vertical standpipe and lock folding plate back to fold.



After folding, hold the standpipe with one hand or both hands to transport.

8. Daily maintenance

Electric scooter cleaning and storage

If the electric scooter body surface cracks, please use a soft cloth dipped in a small amount of water to wipe; if there is difficulty to clean the dirty, you can use toothpaste and wash with a toothbrush repeatedly, and then use a

damp cloth to clean.If there are scratches in body plastic,you can use sandpaper or other grinding material to polish.

Prompt:Do not use alcohol,gasoline,kerosene or other corrosive,volatile chemical solvent cleaning,otherwise it will seriously damage the appearance and internal structure of the body.It is forbidden to use a pressure water gun to spray and flush,and ensure that the electric scooter is closed all along and the charging cable has been unplugged and the rubber caps tightened.Otherwise,it may cause electric shock or serious failure due to internal water intake.

When not in use,try to store electric scooters and tire aging and reduce the lift of electric scooters and their battery pack.


Electric scooter battery maintenance

- 1.Do not use other models or brands of batteries,or there may be a security risk.
 - 2.Do not touch the battery contacts,and do not open or expose the shell.Avoid metal objects touching the battery contacts to cause a short circuit.Or it may cause damage to the battery or personal injury or death.
 - 3.Only use the original charger to charge,otherwise there is a risk of damage or fire.
 - 4.Improper disposal of used batteries may cause serious contamination of the environment.Observe local regulations when discarding this battery pack.Do not dispose of the battery pack,to protect the natural environment together.
 - 5.After each use,please recharge the battery and then store,and it is conducive to extend battery life.
- Do not place the battery in a high temperature environment higher than 50°C or below -20°C (for example,do not place the electric scooter or its battery pack under summer exposure in a car),and do not put a battery into a fire.Otherwise it may lead to battery failure,overheating,and even fire risk.When not using for more than 30 days,please be fully charged,stored in a cool dry place,and fully charged every 60 days,or it may damage the battery,and this damage is not within the warranty.

To avoid the full exhaustion of electricity and recharge,as far as possible with the charge with the use,which can greatly extend the battery life.In addition,at room temperature,the battery pack can play a higher mileage and performance;And if it is used in an environment below 0°C,battery life and performance will drop.Typically,at -20°C,the mileage may be only half or less at room temperature.And the temperature rises,the battery mileage will be restored.


Prompt:A fully charged electric scooter,depleting its stored power after about 120-180 days of standby.The battery inside has the smart chip to record the battery charge and discharge situation,and prolonged non-charging damage will not be recharged,at this time if not timely charging,it is likely to lead to excessive battery discharge damage,this damage is irreversible,and can not enjoy free warranty.(Note:Non-professional personnel is prohibited to remove the battery pack,or it may lead to serious security incidents due to electric shock or short circuit!)

Disc brakes debugging




If you feel the brakes are too tight,please use the M5 hex wrench counterclockwise to release the pressure plate screws on the disc brake seat,return the brake line to make the exposed tail length slightly shorter,and lock the pressure plate screws;If you feel the brake is too loose,release the

pressure plate screws,drag the brake cable to make theexposed tail length slightly longer,and then lock the pressure plate screws.
Handle shake debugging



If your standpipe in electric scooter is shaking,please use theM5 hex wrench to lockthe two screws at the fold mechanism.
Extendthe useof inflatable mouth



If your electric scooter front and rear tires aredeficiency,please use the extended inflatable mouth to connect thescooter body tires to cheer.First remove the front andrear tire inflatable mouth cup, and then tighten the extension of the inflatable mouth and tire inflatable mouth,and connect the pump to inflate after they are to be tightened.

9.Model parametertable

Performance index	tem	Parameters
Product dimensions	Unfolding: LengthxWidthxHeight	1140*430*1150mm 44.88*16.93*45.28in
Product dimensions	Folding: LengthxWidthx Height	1140*430*490mm 44.88*16.93*19.29in
Productweight	Weight	10.7kg(5.2A)/11.7kg(7.8A)(23.59lb(5.2A)/25.79lb(7.8A))
Riding requirements	Max loading	120kg (265lb)
	Applicableage	14-50 yearsold
	Applicableheight	120-200cm (47-80in)
Main parameters	Maxspeed	20km/h (12.43mph)
	Range (km)	20-30km/h(depends on battery capacity)(12.43-18.64mi)
	Climbing ability	≤20°
	Applicable terrain	Flat dirt road,no higherthan 1cm steps,no more than 3cm wide channel
	Working temperature °C	-10~40

	Storage temperature ℃	-20~45
	Protection levels	IPX4
Battery parameter	Rated Voltage(VDC)	37V
	Max charging voltage (VDC)	42V
	Rated power(W)	187.2 (5.2A) /280.8 (7.8A)
Motor parameter	Max power(W)	350
	Rated power(W)	71
	Rated input voltage(VAC)	100V-240V
	Rated output voltage(VDC)	42V
	Rated current(A)	1.5A
	Charging time	5-6H

(1)Body height:the distance from the ground to the top of its body.

(2)Typical life:When the electric scooter is full,75kg load,25 degrees Celsius,flat road without wind environment,in the energy-saving mode to keep at 15km/h even speed conditions measured,the actual life due to load,temperature,wind speed,road and operating habits and other factors to be different.

Note:Data and parameters vary with different models.Subject to change without notice.

10.Name and content of harmful substances in the product

Name of component	Harmful substance					
	Plumbum (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent chromium (Cr(VI))	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl ethers (PBDE)
Charger	X	0	0	0	0	0
Battery	X	0	0	0	0	0
Air tap	X	0	0	0	0	0
Charging port	X	0	0	0	0	0
Master Control board	X	0	0	0	0	0
Instrumentation circuit board	X	0	0	0	0	0
Wheel motor	X	0	0	0	0	0

Scooterframe	0	0	0	0	0	0
Tire	0	0	0	0	0	0
This table is formulated in line with the SJ/11364. 0:Indicate that the content of this harmful substance in all homogeneous materials of this components is below the limit prescribed in GB/T26572 X:Indicate thatthe content of this harmful substance in at least one homogeneous materials of this componentsis beyond the limit prescribed in GB/T 26572						

11.Warranty policy

1. Electric scooter after-sales service is strictly based on the People's Republic of China *Consumer Protection Law and People's Republic of China Product Quality Law*

Friendly tips:It is advisable to keep the packing box for at least 15 days from the date of receipt of the shipping container, because of using packing boxes to ensure the safe Transportation of the product at the process to transporting.

II.The warranty content

Category	Maintenance contents	Starting time
Machine body	Frame assembly, wheel drive, controller assembly, handlebar, forehead main body, middle tank instrument board, rear wheel, brake disc, disc brake assembly, folding handle, front fork, front fork tube rotating parts, the control bus and brake line	One year

III.Non-warranty regulations

- 1.Unauthorized repair,misuse,collision,negligence,abuse,infusion,accident,alteration,improper use of non-product accessories ortom,altered label and anti-counterfeit mark;
 - 2.Any damage is caused by force majeure;
 - 3.Does not conform to the listed performance situation in the Performance Fault list of Electric Scooter Performance Table;
Electric scooter;
 - 4.Due to man-made causes of this product and its accessories produce listed performance fault in the Electric Scooter Performance Table;
 - 5.Damage caused by man-made reasons(including but not limited to the liquid entering into scooters,puncture, impact,the traces and damage of the normal use of the appearance,ect.);
 - 6.If the product is used for commercial use,it is not guaranteed.
- IV.The performance fault table of electric scooters

Designation	Performance faults
Electric scooter	Under normal use, the motor cannot work Under normal use, the controller appears a failure Under normal use, battery appears failure Under normal use, appearing deformation, break can not continue to use