



| <h3>How to connect two speakers (TWS)</h3> <p>You can pair two speakers to create wireless stereo sound.</p> <p>Step 1: Long-press the Power Button to turn on one speaker and label it as the Primary Speaker. And then turn on another speaker and label it as the Secondary Speaker.</p> <p>Step 2: Connect Primary speaker to your phone's Bluetooth(DB A53), and do not connect the Secondary Speaker to any device.</p> <p>Specification</p> <table border="1"> <tbody> <tr> <td>1. Bluetooth Name</td> <td>DB A53</td> </tr> <tr> <td>2. Bluetooth Version</td> <td>BT 5.3</td> </tr> <tr> <td>3. Waterproof Rating</td> <td>IPX5</td> </tr> <tr> <td>4. Bluetooth Range</td> <td>>15m/49ft</td> </tr> <tr> <td>5. Speaker Battery Capacity</td> <td>700mAh</td> </tr> <tr> <td>6. TWS Range</td> <td>>12m/40ft</td> </tr> <tr> <td>7. Charging Input</td> <td>Type-C 5V/0.6A</td> </tr> <tr> <td>8. Charging Time</td> <td>1.5H</td> </tr> </tbody> </table> | 1. Bluetooth Name | DB A53 | 2. Bluetooth Version | BT 5.3 | 3. Waterproof Rating | IPX5 | 4. Bluetooth Range | >15m/49ft | 5. Speaker Battery Capacity | 700mAh | 6. TWS Range | >12m/40ft | 7. Charging Input | Type-C 5V/0.6A | 8. Charging Time | 1.5H | <p>Step 3: Double-tap the Power Button of the Primary speaker, the blue light of both speakers flashes quickly, and after you hear two prompt tones, indicating the two speakers are paired successfully, at that time, the blue light of one speaker stays on, and the other speaker flashes slowly.</p> <p>Indicator Light</p> <p>Low Battery Warning: The red LED indicator light will flash slowly when the battery is low. Low power alarm three times, once alarm every minute, and shut down directly after the third alarm.</p> <table border="1"> <thead> <tr> <th></th> <th>Blue Light</th> <th>Red Light</th> </tr> </thead> <tbody> <tr> <td>Bluetooth Connected</td> <td>Stays on</td> <td></td> </tr> <tr> <td>Play Audio</td> <td>Flashes slowly</td> <td></td> </tr> <tr> <td>Bluetooth Search Pairing</td> <td>Flashes quickly</td> <td></td> </tr> <tr> <td>TWS Search Pairing</td> <td>Flashes quickly</td> <td></td> </tr> <tr> <td>Charging</td> <td>Stays on</td> <td></td> </tr> <tr> <td>Low Battery</td> <td>Flashes slowly</td> <td></td> </tr> </tbody> </table> | | Blue Light | Red Light | Bluetooth Connected | Stays on | | Play Audio | Flashes slowly | | Bluetooth Search Pairing | Flashes quickly | | TWS Search Pairing | Flashes quickly | | Charging | Stays on | | Low Battery | Flashes slowly | | <h3>FCC Statement</h3> <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. <p>1. Environment and temperature Operating temperature should be between 0°C to 40°C/32°F to 104°F. Keep away from extreme temperature environments (such as high temperature fire, direct sunlight or extremely cold environment) to avoid battery damage. Do not approach heat sources (such as stoves, engines and other heating equipment).</p> <p>2. Use and maintenance Do not drop, disassemble or replace the battery (wrong model may cause explosion risk). Do not use corrosive detergents/oils to wipe the product. Keep away from water or humid environments (such as rainy days) when charging to prevent electric shock.</p> | <h3>Important Safety Information</h3> <p>1. Environment and temperature Operating temperature should be between 0°C to 40°C/32°F to 104°F. Keep away from extreme temperature environments (such as high temperature fire, direct sunlight or extremely cold environment) to avoid battery damage. Do not approach heat sources (such as stoves, engines and other heating equipment).</p> <p>2. Use and maintenance Do not drop, disassemble or replace the battery (wrong model may cause explosion risk). Do not use corrosive detergents/oils to wipe the product. Keep away from water or humid environments (such as rainy days) when charging to prevent electric shock.</p> <h3>Charging</h3> <p>Fully dry off the speaker and the USB port before charging. The battery may go to sleep or die if it doesn't charge/discharge for a long time. Please charge and discharge it at least one time per month.</p> <h3>Notice</h3> <p>This symbol means the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Follow local rules and never dispose of the product and rechargeable batteries with normal household waste. Correct disposal of old products and rechargeable batteries helps prevent negative consequences for the environment and human health.</p> |
|---|-------------------|-----------|----------------------|--------|----------------------|------|--------------------|-----------|-----------------------------|--------|--------------|-----------|-------------------|----------------|------------------|------|--|--|------------|-----------|---------------------|----------|--|------------|----------------|--|--------------------------|-----------------|--|--------------------|-----------------|--|----------|----------|--|-------------|----------------|--|---|---|
| 1. Bluetooth Name | DB A53 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2. Bluetooth Version | BT 5.3 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3. Waterproof Rating | IPX5 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4. Bluetooth Range | >15m/49ft | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5. Speaker Battery Capacity | 700mAh | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6. TWS Range | >12m/40ft | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7. Charging Input | Type-C 5V/0.6A | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8. Charging Time | 1.5H | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Blue Light | Red Light | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Bluetooth Connected | Stays on | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Play Audio | Flashes slowly | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Bluetooth Search Pairing | Flashes quickly | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| TWS Search Pairing | Flashes quickly | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Charging | Stays on | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Low Battery | Flashes slowly | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

400*65mm
三折 正反面彩色印 105g 书纸