

User Manual

How to use your new Bluetooth speaker



Bluetooth mode

1. Switch the power button to turn on the speaker. The blue LED flashes, the speaker enters Bluetooth pairing mode.
2. On your smartphone, enable Bluetooth, search and select Bluetooth item No. to pair. After paired, the blue LED lights up continuously.
3. If battery has low power, the speaker will warn you with sound alarm.
4. Charging: Connect to a DC 1A adapter, or to a USB port on your computer.
5. When charging: The red LED light on. When charging is complete, the red LED turns off.
6. Double-click the button to switch the TWS coupling function.

FM radio mode

1. Press the M button to switch to FM radio mode.
2. Press 3 seconds the pause button in FM mode to search and store FM radio stations automatically.
3. If the radio reception is not good, connect a USB cable to use as an antenna.

Play from a Micro SD card

1. Connect a Micro SD card. Play starts automatically.
2. Supports MP3 format.
3. Press the M button to switch between Micro SD card, FM radio and Bluetooth mode.

Play from USB

1. Connect a USB stick. Play starts automatically.
2. Supports MP3 format.
3. Press the M button to switch between USB, FM radio and Bluetooth mode.
4. Press the key to go up, and press the - key to go down

Listen to external devices

1. Use the supplied 3.5mm AUX cable, connect the speaker to an external device (e.g. MP3 or smartphone).



- Store and use this product at room temperature
- Do not expose this product to rain or wet conditions
- Do not self-dismantling, repair and transform the product
- Do not use chemical solvent cleaner to clean the product
- Do not place the lithium battery in the fire to avoid the risk of explosion

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.