




User Manual

App:O-KAM Pro

Installation steps: base mounting to tear open the 3M adhesive and stick it on the wall or on top of other objects, the minimum distance to be used is more than 20cm.

Device Description



- Built-in battery.
- Support DC 5V/1A power supply.
- The device has two working modes: AP hotspotmode and Wi-Firemote mode.
- How to factory reset: When the camera is turned on, press and hold the reset button for about 5seconds until the blue light and the red lightflash alternately.the red lightflash alternately.

Indicator Status

Yellow light: charging-always bright
fully charged-off

-1-

Blue light: waiting for Wi-Fi connection--flasheslowly, during Wi-Fi connection-flash quickly.Wi-Fi connection successfully--always bright.

Factory reset: The blue light and the red light(red light) flash alternately.

Low -power alarm: The blue light and the red light (red light) flash at the same time.

Step 1:Pre-Setup

- ☑ Turn on the camera.
- ☑ Restore the camera to the factory settings.
- ☑ Please place the camera within 2 meters rangeof the router when connecting to Wi-Fi.
- ☑ Connect your phone to Wi-Fi and clear theWi-Fi password. (Only support 2.4GHz Wi-Fi)


-2-

Step 2: APP Download and Registration



- 1 Search for "O-KAM Pro" in APP Store orGooglePlay, or scan the QR cord above to download the APP

-3-




- 2 Click "Register now" and register your account according to the prompts.

-4-


Step 3: Add Devices to the APP Method One: Bluetooth Connection

- 1 Turn on the camera and restore it to the factory settings.




- 2 Turn on the Bluetooth function of the phone

-5-




- 3 Open the APP, wait for the searched device to appear at the top of the page, and then click"Connect".(If no device is searched, please click"Add" to search again, or directly scan the QRcode on the camera)

-6-




- 4 Confirm the Wi-Fi you want to connect and enter the correct password. (5G Hz Wi-Fi is not supported)

-7-




- 5 Wait for the camera to bind to the APP.




- 6 Click "Get started" in turn.

-8-



Method Two: AP Connection



- 1 Turn on the camera and restore it to the factory settings.



- 2 Click the icon in the upper right corner and select "Hotspot Configuration"


- 3 Click "To connect"

-9-



- 4 Enter the network settings of your phone, select the signal of "@ MC -****" and connect.

-10-




- 5 Back to the APP to automatically add the device, click the play button to watch.


-11-

Wi-Fi Configuration


- 1 Click "settings"



- 2 Select "Device Settings"




- 3 Click "Wi-Fi network"




- 4 Select the Wi-Fi you want to connect and enter the correct password.

-12-



Device Share

- Enter the "System settings" of the camera and select "Share" to generate the device sharing QR code. Other users can open the APP and scan this QR code to add the device.



-13-

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.