

User Manual



Main Light Button:Press the button to turn on / tum off the main light.

main light CCT button : Press K- ,main light color temperature decreasing at 4levels:6500K , 5000K , 4000K , 2700K.

Press and hold K- button for stepless decrease color temperturechanging.

main light CCT button : Press K+,mainlight color temperature increasing at 4levels:2700K,4000K,5000K,6500K

Press and hold K+ button for stepless increase color temperturechanging.

main light dimming button : Press dimming - button, main light brightness decreasing at 7levels 100%-80%-60%-40%-20%-10%-1%.
Press and hold dimming- button for stepless decrease dimming

main light dimming button : Press dimming + button, main light brightness increasing at 7levels 1%,10%,20%,40%,60%,80%,100%.

Mood Light Button:

Press the button to turn on / turn off the mood light.

mood light dimming button : Press dimming - button, mood light brightness decreasing at 7levels 100%-80%-60%-40%-20%-10%-1%.
Press and hold dimming- button for stepless decrease dimming

main light dimming button : Press dimming + button, main light brightness increasing at 7levels 1%,10%,20%,40%,60%,80%,100%.

Press and hold dimming+ button for stepless increase dimming

Press M button, mood light to sequentially illuminate in red, orange, yellow, green, blue, indigo, violet, and music rhythm mode in a continuous loop.

Turn Off After a 30-Minute Countdown

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in 0mm exposure condition, compliance with exposure requirements.

Only in the stated conditions, the device is shown to fully comply with the FCC RF Exposure requirements of KDB 447498.