


QUICK START GUIDE

Read this manual carefully and save it for future reference.


R2

WHAT'S IN THE BOX



PRODUCT DIAGRAM

- ① Lens
- ② Indicator Light
- ③ White Light
- ④ PIR
- ⑤ Microphone
- ⑥ Power ON/OFF
- ⑦ Type-C Port
- ⑧ Reset Button
- ⑨ TF Card Port



SETUP

- Download the "Wansview Cloud" app, create an account and then log in.
- Make sure the camera is fully charged. Press the power button for about 5 seconds until you hear the startup voice prompt. Then press the reset button for about 5 seconds until the indicator light flashes red and blue alternately.
- Open the "Wansview Cloud" app, tap the "+" or "Add device" option, find the R2 camera in the list, then follow the in-app instructions.




INDICATOR LIGHTS STATUS



Light Status	Camera Status
Red light on	Camera is powered on
Flashing red & blue light	Camera ready for connection
Blue light flashing	WiFi connection in progress
Solid blue light	Camera working properly
Flashing red light	Reset/firmware upgrade in progress

INSTALLATION

1. Drill several holes in the wall with the aid of the template sticker, then screw the mounting bracket on the wall.



2. Screw the camera on the mounting base and adjust the angle for the camera view.



FAQ

»» Unable to connect the camera to Wi-Fi during setup?

If you are unable to connect the camera to Wi-Fi, please try the following solutions:

- ① Make sure your Wi-Fi meets the network requirements of the camera and check if the router supports 2.4GHz Wi-Fi.
- ② Make sure you have entered the correct Wi-Fi password.
- ③ Place your camera near the router to make sure that the Wi-Fi signal is strong enough.
- ④ Check if the indicator light is flashing red and blue alternately.

If the problem persists, please contact our customer service:

US/CA support.us@galayou-store.com

UK support.uk@galayou-store.com

»» The light is not flashing red and blue alternately?

If the light does not flash red and blue alternately, please try the following solutions:

- ① Make sure the camera is powered on.
- ② Press and hold the reset button for about 15 seconds to reset the camera.

»» Camera is offline?

① Make sure the router is working properly. Restart the router and the camera, then see if the camera reconnects automatically.

② If not, reset the camera by holding the reset button for 15 seconds, then reconnect the camera.

③ Place the camera closer to the router to make sure the connection is strong enough.

»» Does this camera support RTSP?

No, all battery cameras do not support RTSP.

»» Why this camera does not record for 24/7 continuous?

Record videos will speed up the battery depletion. To save the battery, the battery camera will automatically enter sleep mode when it does not detect any movement.

»» Does the battery need to be charged immediately out of the box?

Each camera is fully charged before shipping, but it may run out of power during transportation. When you get the camera, you can press and hold the "POW" button to check if the indicator light comes on. If not, please use the type C cord to charge it for 4-5 hours.

»» How to view longer SD card/Cloud recording?

Once you set up SD card or Cloud recording, please clicking "Replay" under live feed and view SD card&Cloud recording. Do not go to Alert page, it's 10s alert video.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/ TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operated in conjunction with any other antenna or transmitter.

After-service :

US/CA support.us@galayou-store.com

UK support.uk@galayou-store.com

1-323-686-3288 (US only)



Made in China