

Product Manual

产品说明书

DS Tag
TAG01

DISIDUW

DS Tag Instruction Manual DS Tag使用说明书

To use the Apple Find My app to locate this item, the latest version iOS is recommended.

在使用“查找”App定位此设备之前，建议使用最新版本的iOS系统。

How to set up DS Tag 如何设置DS Tag

First, make sure that the iPhone's Bluetooth and network are turned on.

首先确保已经打开iPhone手机蓝牙和网络



Follow these steps to add DS Tag: 按照以下步骤添加DS Tag:

1. Power on: Remove the plastic insulation sheet from the battery. When a short ringtone sounds, It is power on successfully

1.开机：拔下DS Tag电池的塑料绝缘片，当响起一段短铃声，即开机成功。



塑料绝缘片
Plastic insulation sheet

2. Add item: Open the Apple "Find My" App, click "Add Item", then click "Other Supported Item".

2.添加：打开苹果“查找”App，点击“添加物品”，然后点击“其他支持的物品”。



3. Connect: Place the DS Tag close to the iPhone, wait for the locator to be recognized, and click "Connect".

3.连接：将DS Tag靠近iPhone手机，等待识别到定位器，点击“连接”。



4. Set up: You can customize the "name" and "emoji" of the DS Tag, then the setting is complete

4.设置：你可以自定义DS Tag的“名称”和“表情符号”，然后完成设置。



How to remove DS Tag 如何移除DS Tag

Open the Apple "Find My" App, swipe left on the item you want to remove, then click "remove".
打开苹果“查找”App，选择想要移除的物品，向左滑动，然后点击“移除”。



完成移除后，DS Tag会响起一段短铃声。
After the removal is complete, DS Tag will sound a short ringtone.

How to replace the battery 如何更换电池

DS Tag has a built-in button battery. When the battery runs out, you can turn the back cover counterclockwise to open it, remove the battery and replace it with a new one.
DS Tag内置纽扣电池。当电量耗尽时，可以逆时针方向转动打开后盖，取下电池并更换新的电池。



How to turn off DS Tag 如何关闭DS Tag

Once the DS Tag is powered on, it cannot be turned off. If you want to turn off the DS Tag, you can remove the battery and force it to shut down.

DS Tag接通电源后，无法进行关机操作。如果你想关闭DS Tag，可以取下电池，强制关机。

Location Tracking 定位追踪

1. Open the "Find My" App, select the item you want to track.
2. Click "Directions", track the item's location on the map.

1. 打开“查找”App，选择想要追踪的物品。
2. 点击“路线”，在地图中追踪物品的位置。

Play Sound 播放声音

1. Open the "Find My" App, select the item you want to find.
2. Click "Play Sound", DS Tag will play two sets of ringtone sounds.

1. 打开“查找”App，选择想要寻找的物品。
2. 点击“播放声音”，DS Tag会播放两段响铃声。

Notifications 遗落通知

1. Open the "Find My" App, select the item you want to be reminded.
2. Select the "Notifications", enable 'Notify When Left Behind'.

1. 打开“查找”App，选择想要提醒的物品。
2. 找到“通知”栏目，开启“遗落时通知”。

Warning: 注意事项:

1. This product is not a toy or edible.
2. Obstacles or large metal objects can interfere with the Bluetooth signal.
3. This product has a built-in lithium battery. Please do not put this product directly on fire or any place near heat or fire. Otherwise, the product may be damaged or malfunctioned, or even be dangerous.

1. 本产品不是玩具，也不能食用。
2. 障碍物或大型金属物体会干扰蓝牙信号。
3. 本产品内置锂电池。请不要将本产品直接放在火上，或任何靠近高温或火源的地方。否则，可能造成产品损坏、故障，甚至发生危险。

Disclaimer: 免责声明:

This is neither an anti-theft nor an anti-lost device. This device provides the last detected location.

本产品不是防盗防丢装置，设备仅提供最后追踪到的定位位置。

Limited warranty: 有限保修:

DISIDUW offers a one-year limited warranty against product defects, effective from the time of delivery. Product defects do not include those resulting from accidents, product modification, or failure to follow instructions for use.

DISIDUW对有缺陷的产品提供为期一年的有限保修，自产品交付之日起生效。产品缺陷不包括意外事故、产品改装或未按照使用说明操作造成的缺陷。

DISIDUW DS Tag, 1pack



FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.