



# User Manual

## Dear Customer:

Thank you for purchasing our mini karaoke machine. In order to facilitate your use of this product, we have provided you with a detailed instruction manual, from which you can learn about the product parameters, usage and other information. Before you start to use this machine, please read the instruction manual carefully for correct use.



## Function :

- 1.The latest wireless Bluetooth 5.3 technology, can easily connect iPhone, Android phone, iPad and other Bluetooth devices
- 2.Low power consumption, high power class D digital amplifier

- 3. Built-in 2.4G wireless microphone system, equipped with two wireless microphones
- 4. Support reverb, sound canceling and sound change function
- 5. Built-in high-capacity rechargeable lithium battery
- 6. Fashionable and portable, suitable for home, office, outdoor travel, sports, leisure, entertainment, learning and other occasions

## Attention:

When using the product for the first time, please fully charge it first.

## Speaker Instructions:

- ① Short Press: Volume Up  
Long Press: Next Track
- ② LED Light Adjustment
- ③ Short Press: Pause / Play
- ④ Short Press: Volume Down  
Long press: Previous Track
- ⑤ Long Press: Power On / Off
- ⑥ Indicator Light  
(Charging indicator off when fully charged)
- ⑦ TF Card Slot  
(Supports up to 64G music TF card)
- ⑧ AUX-IN
- ⑨ USB Slot
- ⑩ TYPE-C Charging Port: DC-5V



# Steps to connect to your phone

1. Power on the speaker: Press and hold the power switch button for 2 seconds to turn on the speaker, the Bluetooth indicator will flash rapidly.
2. Connect Bluetooth: Turn on your phone's Bluetooth and scan. After searching "158", pair and connect. After connecting, you can hear sound from the box "Bluetooth is connected" connection tone.
3. Open your cell phone application to play music. After connecting with your cell phone once, the Bluetooth has a memory function and can be reconnected automatically when turned on.

## Microphone Instructions

1. Power on the speaker: Press and hold the power switch button for 2 seconds to turn on the speaker, the Bluetooth indicator will flash rapidly.



- ① Long Press: Power On / Off  
Short Press: Pause / Play
- ② Short Press: Volume up  
Long Press: Next track
- ③ Short Press: Volume Down  
Long Press: Previous Track
- ④ Short press: Mute/Accompaniment  
Long press: Microphone Off/On
- ⑤ Mic mode Adjustment:  
Short Press:  
Magic 1 / Magic 2 / Magic 3 / Magic4 / Magic 5  
Original / Echo / Male / Female / Doll / Magic  
Long press: Accompaniment mode; Mute on/off
- ⑥ Indicator Light:  
Red is the charging indicator light.  
Blue is the microphone connection indicator.  
The blue light is always on when the microphone is successfully lighted.
- ⑦ TYPE-C Charging Port: DC-5V

## **Steps to connect to the speaker**

1. Power on the microphone: Press and hold the power button for 2 seconds to power on the microphone.
2. The Bluetooth indicator blinks and automatically pairs with the speaker. If the Bluetooth light stays on, the pairing is successful.
3. start karaoke, the microphone is more effective when the distance between the microphone and the sound system is within 10 meters.
4. If you only listen to music, you can long press the power button to turn off the mics to avoid whistling.
5. When the microphone does not sound well or is not switched on, it is necessary to recharge the microphone to replenish the battery.

## **Precautions for charging**

1. The product will automatically shut down when the battery power is too low.
2. The device is equipped with an overcharge protection circuit, and can be charged by connecting it to a standard 1A/2A charger using the attached USB charging cable. It takes about 2-3 hours to fully charge the battery. When charging is complete, the red light will turn off automatically.
3. If the device is not used for a long period of time, it should be charged at least once every two months to protect the battery life.
4. Normal continuous use time is about 4-5 hours.

# Parameters

Model	158
Craftsmanship	ABS + Electroplated baking paint + Iron mesh
Bluetooth version	5.3
TF card	Support
Input power	5W
Frequency range	20Hz ~ 20KHz
Effective distance	≤10m
Battery capacity	Speaker 18650 - 1200mAh Microphones 14500- 500mAh
Input power supply	DC-5V 1000mA
Charging time	About 2-3 hours
Bluetooth protocol	A2DP/HFP/HSP/AVRCP/AVRTP
Communicate by telephone	Not Support
Product size	Speaker 104*89*97MM Microphones 38×38×135MM
Product weight	Speaker 346g Microphones 81g*2
Operating temperature	0 to 55 degrees Celsius
Waterproof level	Not Support

\*Note: Product parameters may vary depending on model, application, environment and other factors.

# Common problems and solutions

Common Problems	Common Causes	Troubleshooting
Cannot connect to Bluetooth	Connected to another cell phone	Turn off the Bluetooth of the connected cell phone
No sound when the speaker is playing	Volume turned off	A.Increase phone volume B.Increase player volume
Distortion during Bluetooth playback	Volume too high, battery too low	Volume too high, battery too low
The microphone is silent	Microphone volume down, microphone volume off	A. Increase microphone volume B. Short press microphone power button to turn it on
Howling	Microphones too close to front of speaker	A.Adjust the distance from the speaker B. Avoid interference from obstacles
Microphone has interference sound	Low battery	Recharge microphone batteries
The speaker/ microphones cannot be charged	Charging cable not inserted tightly;Poor contact; Charging cable damaged	A. Tighten the power charging cable B. Replace the charging cable Red light indicates normal charging

# Security and Usage

1. Please store and use this product at room temperature.
2. Do not use this product in rain or humid environment.
3. Do not disassemble, repair or modify this product by yourself.
4. Please do not throw it away, so as not to fall and cause damage to the product.
5. This product contains a built-in rechargeable battery. To prevent serious damage to the device, it is recommended not to expose the product to strong sunlight.
6. Please do not place the device near a source of ignition. Do not leave the device in an environment with an ambient temperature higher than 70 °C or lower than -20 °C for a long time.

\*Note: If you violate the above warnings and cause personal and property damage by improper use, all consequences will be borne by yourself. Our Company does not assume any legal responsibility.

## Specification

The product does not include a power adapter. Please use a CCC certified power adapter that complies with the relevant standards as a companion device.

# Specifications:

<b>Version</b>	<b>5.3</b>
<b>Input power</b>	<b>5W</b>
<b>Effective distance</b>	<b>&lt;10m</b>
<b>Battery</b>	Speaker 1200mAh Microphones 500mAh
<b>Play time</b>	<b>4~5hours</b>
<b>Frequency Range</b>	<b>20Hz ~ 20KHz</b>
<b>Rated voltage</b>	<b>3.7V</b>

## Packing List

1. Bluetooth speaker \*1
2. Microphone \*2
3. User manual \*1
4. USB charging cable \*1





## FCC Statement

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has evaluated to meet general RF exposure requirement. The device can be used in portable exposure without restriction.