



Wireless Car Charger Mount User Manual



Note: For the best performance and safety, please read this manual carefully before using the product

Product Diagram




- | | |
|---------------------------|---------------------------|
| 1. Clamping Arm | 8. Locking Nut |
| 2. Wireless Charging Area | 9. Ball Joint |
| 3. Charging Coil | 10. Telescopic Arm Knob |
| 4. Type-C Charging Port | 11. Adjustable Angle Knob |
| 5. Bottom Bracket | 12. Locking Button |
| 6. Indicator Light | 13. Suction Cup |
| 7. Release Button | |

User Instruction


1. Attach the suction cup to the mount:

- Unscrew the nut counterclockwise.
- Place the nut over the ball joint.
- Push the ball joint into the back of the mount, and tighten the nut clockwise.



2. Secure the suction cup to the cab dashboard or windshield:

- Wipe the dashboard or windshield with a cloth to ensure it is clean and dry.
- Remove the protective film from the suction cup.
- Lift the lock button and press the suction cup vertically with a little force, ensuring full adherence of the adhesive at the bottom to the dashboard or windshield.
- Press the lock button to secure it, and let it stand for 30 minutes before use.




Tips:

- Before removing the suction cup sticker, ensure that the mounting surface is flat enough to accommodate the entire suction cup. Carefully verify the placement to ensure successful adhesion on the first attempt.
- The suction cup is reusable. Before reusing it, please wash the bottom of the suction cup to remove any dust, dry it in a well-ventilated area, and then install it on the dashboard.
- To remove the suction cup mount, first lift the bottom lock button, and then gently remove the suction cup mount.

Note: This product is not suitable for leather dashboards.

3. Connect the power supply to the wireless charger:

Connect to power by using the included cable and car charger. When the power is on, the indicator light will turn red.




Note:

A car charger with an output of at least 18W is required.

4. Charge your cellphone:

Press the release buttons on both sides to open the clamp arm, put the phone on the mount, and then press the clamp arms on both sides to clamp the phone. The phone will start charging and the indicator light will turn green.

When you need to remove the phone, press the release button, and the clamping arm and bottom bracket will open automatically. Once you take out the phone, the indicator light will turn red.



Note:

- When charging your phone, be wary of heat build-up. Using the device during charging, especially activities like watching videos, can lead to overheating. In the event of overheating, the charger will automatically stop charging. Please let the phone cool down completely before resuming charging and usage.
- The charger is equipped with a foreign object detection function. When metal or magnetic objects are near the charging area, the indicator light will flash and the charger will stop charging. Please remove the relevant items to avoid affecting the wireless charging function.
- When the phone does not have wireless charging function or foreign object sensor, the red light flashes.

Important Reminders

- This charger is suitable for 4.7-6.9 inch phones with wireless charging, not for Samsung ZFLIP3/ZFLIP4/ZFLIP5/ZFLIP6.
- The maximum output power of this charger is 15W. It will automatically adjust the power output depending on the phone.
- Please only use the cable provided with the charger. Other third-party cables may interfere with charging.
- This charger requires a car charger that supports QC3.0 or PD fast charging. It is recommended to use the included car charger.
- This product supports cell phone charging with a case, and the thickness of the phone case should be less than 5mm.


⚠ Precautions

- This charger is only suitable for use inside the car, beware of rain and exposure.
- The charger must be used within -20°C~40°C (-4°F~104°F), do not use this product to charge when the ambient temperature exceeds 40°C (104°F).
- Before charging, make sure there are no metal or magnetic accessories on the back of the phone that could interfere with wireless charging. Coins, pieces of metal, and credit cards all affect wireless charging.
- Please do not attempt to open the equipment, unauthorized disassembly or modification will damage equipment or related wireless charging functions.
- Please do not throw, tap, or shake the equipment, rough handling of the equipment will damage the internal circuit board and the mechanical structure.
- Please keep the equipment dry. Do not use or store the charger in a hot or moisture place.
- Please use a clean and moist soft cloth to clean the surface of the equipment. Do not use or store the equipment in dusty or dirty places.
- Keep out of reach of children.

Specifications

Model	X140
Input	9V = 2A (MAX)
Output	15W (MAX)
Material	PC + ABS
Size	105*72*60mm
Weight	201g

In the Box



Made in China

FCC Requirement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.