

Nixie Tube Clock

Manual

V1.0.2

Video Tutorial:

www.bit.ly/NXTBC


Step1.

Connect the data cable, turn on the clock.
Turn on your phone -> Setting -> WLAN or Wi-Fi.
Connect to this: **hg6**.




Tips: If the phone hint that this network has no Internet, it may not be **safe**. Please **trust** this network and keep linking.

The setting page will pop up automatically.




Tips: If the setup page pops up automatically, skip these two pages and go directly to step 2.

If the settings page does not pop up, keep your phone connected to the **"hg6"** WiFi and **turn off mobile cellular data** for your phone.




Then enter **192.168.4.1** in your mobile browser to open the settings page.)




Step2.

After the settings page is opened, you can set the clock display mode, theme, animation, alarm, cool backlight color, night mode and other functions.



At the end of the settings page, you can also upgrade the clock firmware. For the firmware link, please visit this link www.bit.ly/NXTBC



Tips

If you don't like using WiFi to set up, you can also use the buttons on the clock to set up.

The left button is Menu/Confirm

The middle button is Minus "-"

The right button is Plus "+"

Technical Support:

ychj90@gmail.com

For more information, please visit:

www.bit.ly/NXTBC

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.