


Wireless Speaker

S9



instructions

Please read carefully before use

Manufacturer: Shenzhen Kangmingrui Technology Co., Ltd

Huayisheng Industrial Park, Fuyong Street,
Bao'an District, Shenzhen, China

TF card plays songs

When the TF card with MP3 songs is inserted, the speaker will automatically play the songs inside. Short press the "M" key to switch between Bluetooth and TF card, U disk playing, and FM radio mode.

How to choose songs?

Short press of "-" button is the previous song, long press is the volume decrease, short press of "+" button is the next song, long press is the volume increase.

How to connect Wireless

Turn on the Wireless speaker, and the blue light flashes when waiting for pairing. Use the Wireless function of the phone to search for the Wireless speaker model of the device, and click Connect.

Wireless Instructions

When the machine is in Wireless mode, the machine will prompt the Wireless status. After pairing with other devices and connecting successfully, it can realize Wireless music listening and Wireless call functions.

How to call with Wireless

Short press the "Play" button to answer the call, press this button when the call is over, hang up the call and long press it to reject the call. Double click to call the nearest call number.

FM radio function

In the radio mode, adjust the lanyard antenna, and then press the "Play" key to automatically search for stations and save clearer stations. After the automatic search, the machine will play the first saved station. At this time, press the "-" "+" key to switch channels

TWS interconnection

Both speakers are powered on. In the Bluetooth mode, long press the "Play" button to realize TWS interconnection. Two speakers play songs at the same time.

AUX use

Insert the audio cable into the AUX hole of the machine and connect it to the headphone input hole of the mobile phone or computer. Press the "M" key to switch to the external voice input mode. Open the audio software of the mobile phone or computer to play songs.

Indicator Description

The red light is on for a long time in the charging state, and goes out after it is fully charged.

Light switch (only the version with light has this function)

The flashing mode is the default when the light version is turned on. Long press the "M" key to turn off the flashing, and then long press the "M" key to turn on the flashing.

Loudspeaker Frequency Range: 20Hz-90KHZ

Manufacturer: Shenzhen Kangmingrui Technology Co., Ltd
ADD: Floor 3, Building 7, Huayisheng Industrial Park, Fuyong
Street, Bao'an District, Shenzhen, China

Functional parameters

Charging input: 5V 1A

Product size: 210*85*90 mm


Drive Unit: 52mm*2

transmission distance: 10m (Accessibility)

Loudspeaker Frequency Range: 60HZ-20KHZ



This product is sold without a power adapter. If consumers use a power adapter for power supply, they should purchase a supporting power adapter that has obtained CCC certification and meets the standard requirements. The output specification of the adapter should conform to DC5V2A



FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.