

## CH-M801 Backpack Speaker Instructions

### Bluetooth Mode

1. **Bluetooth Version:** Bluetooth 5.3, supports HFP, A2DP, and AVRCP protocols with Chinese voice prompts. The Bluetooth device name is "SPEAKER 8888".
2. Slide the power switch to the left to turn on the speaker. The speaker will issue a "power on" voice prompt.
3. After powering on, press the M (Mode) button to enter Bluetooth mode. A voice prompt "Bluetooth Mode" will be heard, and the speaker will enter Bluetooth pairing mode.
4. In pairing mode, enable Bluetooth on your device and search for "SPEAKER 8888". Select it to connect. Once connected, the speaker will give a voice prompt "Bluetooth Connected".
5. **Music Playback Functions:** Short press the M button to pause playback. Press again to resume. Short press the V-/ button to skip to the previous track; long press to decrease volume. Short press the V+/ button to skip to the next track; long press to increase volume. When the volume reaches the maximum level, there will be a "beep" prompt.
6. Short press once to turn on the white light. Short press again to turn on RGB color lights. Long press to turn the lights on/off.

### Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver

--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

RF exposure:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.