

# Floor Lamp

## parameter

### v o l t a g e :

**5V/500Milliampere -1A**

### Power Mode:

1. Press the button switch

L E D Q t y :

**5050/60individual**

Color/Dimming:

Seven colors+  
warm light+white light

Material: one



Line length: 2 meters

## Button switch and plug port




Type-C power interface



Button switch: Lightly press to turn on the light, then lightly press to switch the light color, and long press for three seconds to turn off the light.

## remote control



## Application Links

1. Scan the QR code to download the application

2. Turn on the Bluetooth function on your phone and connect to Lotuslamp X



## Installation instructions for lamp tubes and strips:



## FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for Compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help important announcement .

## Radiation Exposure Statement

To comply with FCC RF exposure compliance requirements, this grant is applicable to only mobile configurations. The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.