

126*56mm

双面印刷



Safety Information Installation

This device is not intended for use with emergency exits. If the OIO Bulb exhibits undesirable operation (buzzing, flickering, etc.), immediately turn off power, remove OIO Bulb from luminaire, and contact manufacturer. Not for use in totally enclosed luminaires.



Do not dispose of the OIO Bulb in household waste.

OIO Bulb is compatible with standard E26 sockets. Handle the bulb by its base to avoid damaging the light-emitting surface. Avoid installation with dimmer switches unless stated compatible.

Contact

For Support visit www.korrus.com/OIO. Need help with setup? Access the help section in OIO App or contact customer service email info@korrus.com.


kOrrus

KO-A19-09-OMNI-DC1-01

KO-B30-09-120D-DC1-01



Caution – Risk of fire. Use only in rated fixtures.



Warning: Risk of electric shock. Turn off power at the circuit breaker before installation.

NOT FOR USE IN TOTALLY ENCLOSED LUMINAIRES. Only use the control provided with or specified by these instructions to control this lamp. This lamp will not operate properly when connected to a standard (incandescent) dimmer or dimming control. Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.

Korrus Inc.

843 N Spring Street, Suite 404 Los Angeles, CA 90012 United States
+1 855 632 6736

Suppliers Declaration of Conformity
47 CFR § 2.1077 Compliance Information

ISED Statement:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1. *L'appareil ne doit pas produire de brouillage;*
2. *L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.*

This equipment complies with ISED RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.

Pour se conformer aux exigences de conformité CNR 102 RF exposition, une distance de séparation d'au moins 20 cm doit être maintenue entre l'antenne de cet appareil et toutes les personnes.