

KC-002

Output power	3W THD=10%
Frequency response	80Hz-20KHz
Signal to noise ratio	≥85dB
Distortion degree	<0.5%
Bluetooth	V5.3
Charging input	DC5V/1A
Interface type	type-C
Rated power	3W
Battery capacity	3.7V 800mAh

①

Operating instructions

Power on: Press and hold the  button for 3s; the blue light flashes quickly

Power off: Press and hold the  button for 3s; the blue light goes out

Music pause/play: Short press  in the playback state, the blue light flashes slowly when playing music, and the blue light stays on after pausing the music; press twice to enter TWS mode

Bluetooth reset: Long press xx key for 8 seconds to reset and restart Bluetooth

Volume up/down: long press "+" to increase volume, long press "-" to decrease volume

Song up/down: short press "+" to go to the next song, short press "-" to go to the previous song

Power on and reconnect: long press the button for 3 seconds to reconnect to the Bluetooth device

Long-distance reconnection: re-enter the Bluetooth connection range within 5 minutes to automatically reconnect, and automatically shut down after more than 5 minutes.

②

Low battery alarm: when the device is turned on or Bluetooth is playing, a low battery reminder will be given every 60 seconds when the battery is low. The device will automatically shut down if the battery is too low.

Speaker charging: connect to a DC 5V power supply to charge, the red light will stay on; the red light will go out when the battery is fully charged.

Bluetooth connection operation

Pairing status: After powering on, the speaker automatically enters the pairing status, and the blue light flashes quickly

Pairing the speaker with the phone: After powering on, the speaker automatically enters the pairing status, turn on the phone Bluetooth search Bluetooth name "KC-002" and click to connect. After pairing is successful, the blue light stays on.

Disconnect the phone Bluetooth: The speaker and the phone Bluetooth are connected normally, and after disconnecting Bluetooth, the blue light flashes quickly;

LDE indication status: The blue light is used as the speaker status indicator, and the red light is used as the charging indicator

Bluetooth search status: The blue light flashes quickly

Bluetooth pairing status: The blue light stays on after pairing is successful

Playback status:

Blue light flashes slowly

Warnings and Tips:

- To reduce the risk of fire or electric shock, do not expose this product to moisture or rain.

- Do not place this product under open flames.

- Use a safety charger for charging.

- Do not charge for a long time when not in use.

- After long-term storage, you may need to charge and discharge several times to obtain

- the best performance.

- Do not use this product to hit things.

- Do not approach heating devices.

- Do not disassemble, repair or modify it by yourself.

- Please properly dispose of waste packaging, batteries, and old electronic product parts.

- This product uses a rechargeable external battery, and the

- battery cover can be removed and installed at will.

- Even if you do not use this product, please charge it once a

- month to extend the battery life.

FCC Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including

interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential

installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from

- that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

③

④

⑤