


D35说明书尺寸: 65mm X 95mm

D35 Portable Wireless Speaker




User Manual

English & German & French & Spanish & Italian & Japanese

V1.0

Button Function Description



1. **Power Button:** Press and hold for approximately 3 seconds to turn on/off; press and hold for approximately 8 seconds to reset.
2. **Connection status button:** Short press to switch between Bluetooth/USB/TF/AUX modes (Bluetooth mode is the default pairing mode or disconnect).
3. **Volume - Button:** Long press to decrease volume; short press to go to the previous track.
4. **Play/Pause Button:** Short press to play or pause.
5. **Volume + Button:** Long press to increase volume; short press
6. **DC 5V:** Charging port.
7. **USB Port:** Supports USB drive playback.
8. **AUX IN:** 3.5mm audio input port.
9. **TF Card Slot:** Supports TF card playback.

User Guide

1. Power On/Off:

- Press and hold the power button for 3 seconds. The indicator light will turn blue and a prompt tone will sound. The device will start up in Bluetooth mode by default. Press and hold the power button for another 3 seconds to shut down.

2. Connection status:

- After startup, the device enters Bluetooth mode. The Bluetooth indicator light will flash, indicating it is ready for pairing.
- Enable Bluetooth on your phone, search for the device name "HM R-D35," and connect.
- Once connected, the blue light will remain on and a "ding-dong" sound will play. You can then play audio from your phone or other Bluetooth-enabled devices.

3. USB Mode:

- Insert a USB drive into the USB port, and the device will automatically switch to USB mode with a sound prompt, automatically playing music.
- While playing in other modes, press the mode button to switch to USB mode.
- The speaker will automatically play audio files from the USB drive.
- If no USB drive is inserted, pressing the mode button will not switch to USB mode.

4. TF Card Mode:

- Insert the TF card into the card slot, and the device will automatically switch to TF card mode with a prompt sound, and music will play automatically.

- While playing in other modes, you can press the mode button to switch to TF card mode.
- The device will automatically play audio files from the card.
- If no TF card is inserted, pressing the mode button will not switch to TF card mode.

5. AUX IN Mode:

- Connect the speaker's AUX IN port to the playback device (phone/computer, etc.) using a 3.5mm audio cable, and it will automatically switch to AUX IN mode with an audible prompt.

- While playing in other modes, you can press the mode button to switch to AUX IN mode.


- Control audio settings and play music directly on the playback device.

- If no 3.5mm audio cable is inserted, pressing the mode button will not switch to AUXIN mode.

6. TWS (Stereo) Mode:

- For two speakers of the same model, first connect the Bluetooth of one speaker. After successful connection, turn on the other speaker and hold down the mode button on either speaker. Once you hear the prompt tone, the two speakers are paired successfully, and the blue light will stay on. Play audio from your phone or other Bluetooth-enabled devices, and the two speakers will form a left-right stereo system, delivering surround sound.
- Press and hold the speaker mode button on either speaker again. When you hear the prompt tone, the two speakers will disconnect, and the blue light will flash.

Accessories



Parameters

Transmission Range	>10M
Audio Output Power	5W
Frequency Response	100-20kHz
Rated Distortion	<1.0%
Signal-to-Noise Ratio	80dB
Battery Capacity	800mAh
Battery Life	Approximately 3 hours
Charging Time	Approximately 2 hours
Power Input	DC 5V 1A
Product Net Weight	250g



Usage notes

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.