


Product Overview



Before using this product, please read this guide to ensure using safely and properly.

Product parameters

Battery: polymer lithium battery

Input/output: 5V-3A/9V-2.22A/12V-1.67A (Type-C)
5V-3A/9V-2.22A/12V-1.67A (Lightning)
5W/7.5W/10W/15W (Wireless)

Total output: 12V-3A Max

Size: 75×60×28mm

Material: fireproof PC

Color: black/white

Product list: mobile power x1

0.17M Type-C plus Lightning In two-in-one data cable x1

Instruction manual x1

LED display indicator status display

White digital light: Displays the current remaining power (%)

Green lightning icon: Output power

Wake-up button function description:

- Press the power button once to display the current remaining power, and the LED screen will automatically turn off after one second. Press the power button twice to display the current power continuously. When the LED screen displays the power for a long time, press it once to turn it off.

Charging function description:

- The color of the power on the LED display is self-illuminating.
- The LED screen flashes to show the number indicating that it is charging.
- The charger output voltage must be 5V-12V to charge the machine normally.

Discharge function description:

- No need to turn it on, it will automatically match and start charging when connected (Type-C, Lightning In, Wireless).

Foreign object detection: Charging is not possible when foreign objects are detected.

Safety information:

- Improper use of the power supply will damage the battery and keep the battery dry and ventilated.
- The power pack contains organic combustion materials. If the power supply is not used correctly, it will rupture, leak, overheat, etc., causing permanent damage to the battery. The power supply has a built-in safety protection device.
- Do not short-circuit the power supply.
- Do not use the power supply near fire or stoves or places with temperatures above 60°C because high temperatures will melt the plastic shell.
- If the power supply is placed in water, the safety protection parameters and indicators of the power supply will be damaged, so that the power supply cannot be used normally. As a result, overheating, fire and explosion will occur when using the power supply.
- Do not use heavy objects or other objects to squeeze the power supply to deform it: If you use a non-standard charger or modify the specified charger parameters, the battery will overheat, burn and explode.

If you find that the power supply has hidden secrets or other problems, stop using it immediately

- Before use, please make sure that there is no metal foreign matter between the mobile phone (including the mobile phone protective case) and the wireless charger.
- If you encounter any problems, please contact us and we will provide a 24-month warranty or free replacement.

Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.