


客户遥控英文

ELECTRONIC BIDET INSTRUCTION MANUAL




⚠ WARNING

This product is classified as Class I Equipment and must be grounded.
-Do not plug or unplug the power plug with wet hands.
-Do not get any water or cleaning solution on the main unit or power plug.
-Never disassemble, repair or alter.
-Do not use tools in places other than designated.
-Do not install the product on moving vehicles such as wheeled vehicles
-Do not use if a malfunction occurs
-In case of breakdown or other problem, be sure to cut off power by means such as unplugging the power plug.
-Possible malfunctions:
-Water is leaking from a pipe or the main unit.
-The product is cracked or broken.
-The product makes a strange noise or emits a strange odor.
-The product emits smoke.
-The product is abnormally hot.
-The toilet seat cushion is out of place.
-Continued use could cause a fire, electric shock, heat, short circuit, injury.
-Do not allow the water supply hose to touch the power plug or outlet.
-Do not do anything that may damage the power cord, power plug.
-Do not strike, yank, twist, excessively bend, damage, alter, or heat the power cords. Also, do not place anything heavy on, bind or pinch the power cords.
-Do not use a loose or faulty electrical outlet.
-Do not use any outlet or wiring equipment beyond its specified rating.
-Do not use any power supply other than the one specified.
-Do not stick a finger or anything else into the warm air outlet.
-Do not place anything on the warm air outlet or drape clothes over it.
-Keep cigarettes and other open flames away from the product.
-Refrain from sitting on the seat for long periods.
-This is an electrical product. Do not install it anywhere water is likely to get on the product or anywhere with humidity high enough that water is likely to form on the surface of this product.
-When using the product in a bathroom, install a fan or ventilation port and ensure good air flow through the bathroom
-If the electric cord is damaged, avoid danger by having the manufacturer's repair department or equivalent specialist replace it.
-Always disconnect the power plug from the outlet before cleaning, maintenance or inspection

⚠ CAUTION


-Do not apply strong force, mechanical shock, step on or stand on the toilet seat, toilet lid or main unit. Also do not place any heavy object on the toilet seat, toilet lid or main unit.
-Do not fold or crush the water supply hose: do not damage by cutting with a sharp object
When installing the water filter drain valve, make sure that it is securely tightened in its proper position

1.PRODUCT INTRODUCTION




Standard Elongated Seat Size


RC Elongated Seat Size



RC Round Seat Size




2.What's Included



3.Installation requirements


1.Ceramic toilet size requirements

	Standard Installation Size (mm)	Round Seat Installation Size (mm)
Distance A	>520	>490
Distance B	445-474	427-446
Distance C	>384	>356
Distance D	115-185	115-185



2.Power and Water Pressure requirements

Do not use any power supply other than the one specified.
Product requires the water pressure must be between 0.08 MPa and 0.8 MPa.
If the water pressure is below 0.08 MPa, it is recommended that the customer install a booster pump; otherwise, normal usage may be affected.
Please do not connect the power until installation is complete.
Ensure that the ground wire is properly connected.




4.Product Installation

1 Remove the Old Toilet Seat


A)Locate the mounting bolts on the back of the existing toilet seat, usually positioned behind the seat hinge.
B)Use a screwdriver to loosen and remove the bolts.
C)Carefully remove the old toilet seat and lid.

2 Installing two Expanding Rubber Bolts into the ceramic surface




3 Install the Bracket

-Place the Bracket (provided with the smart toilet seat) over the mounting holes on the toilet bowl.
-Secure the plate by fastening the bolts and nuts provided, ensuring the plate is firmly attached.




4 Install the Tee Connector


-Turn off the water supply valve behind the toilet. Disconnect the water hose from the Valve.



-Install the Tee Connector onto the water inlet of the Valve, ensuring it is tightly secured.




-Connect the water hose and the Tee Connector



5 Attach the bidet

-Align the smart toilet seat with the grooves on the mounting plate, and gently slide it into position. Ensure the seat is securely attached to the mounting plate.
-Attach the PE pipe to the outlet of the Tee Connector. Connect the other end of the PE pipe to the water inlet of the bidet. Ensure all connections are secure to prevent leaks.
-Attach the PE pipe to the outlet of the Tee Connector



6 Test the Unit


1. After completing the installation, plug the smart toilet seat into a power outlet. (Do not connect the power until installation is fully complete. Ensure that the ground wire is properly connected for safety.)
2. Once the power is connected, test the smart toilet seat to ensure all functions, such as the bidet, heating, and drying, are working correctly.

7 Test the Unit

8 Test the Unit

9 Test the Unit


6.Display



E1	Water Temperature Alarm: Over-temperature, Short Circuit, or Open Circuit Detected by the Water Temperature Sensor
E2	Seat Temperature Alarm: Over-temperature, Short Circuit, or Open Circuit Detected by the Seat Temperature Sensor
E3	Warm Air Temperature Alarm: Fan Damage
Warm Air Temperature Display	---, 113, 122, 131 represent the setting temperature to no heating, low level, medium level, and high level. When the air temperature is adjusted, the air temperature icon flashes, and the air temperature level light remains for 4 seconds. When the warm air drying starts, the air temperature level light is on for a long time.
Seat Temperature Display	---, 89.6, 96.8, 104 represent the setting temperature to no heating, low level, medium level, and high level. When the seat temperature is adjusted, the seat temperature icon flashes, and the seat temperature level light remains for 4 seconds. When the cleaning starts, the water temperature level light is on for a long time.
Water Temperature Display	---, 93.2, 98.8, 104 represent the setting temperature to no heating, low level, medium level, and high level. When the water temperature is adjusted, the water temperature icon flashes, and the water temperature level light remains for 4 seconds. When the cleaning starts, the water temperature level light is on for a long time.
Water Pressure Level	Low - Medium - High, and the display screen shows 1 - 2 - 3
Nozzle position level	From close to far: the display screen shows 1-2-3
Eco mode	After the ECO mode is turned on, the ECO icon on the display screen lights up. After it is turned off, the ECO icon is turned off.

7.Product Operations

Remote



AUTO	Press the "Auto" button, and the rear cleaning function start to work. Press it again, the nozzle will start to move back and forth. When you press it for the third time, the nozzle will stay at a fixed position. The working time is 90 seconds.
REAR WASH	After being seated, press the "Rear Washing" button, and the cleaning function will start to work. Press it again, the nozzle will start to move back and forth. When you press it for the third time, the nozzle will stay at a fixed position. The working time is 90 seconds.
BIDET	After being seated, press the "Front/Back Washing" button, and the cleaning function will start to work. Press it again, the nozzle will start to move back and forth. When you press it for the third time, the nozzle will stay at a fixed position. The working time is 90 seconds.
STOP	Press "STOP" to stop rear cleaning, front cleaning and drying in advance. In the off state, press "STOP" briefly to turn on the power.
DRY	Press "DRY", soft cleansing function will be activated, the pressure is maintained at the lowest level, and the water temperature is at the second level. The water pressure and temperature cannot be adjusted.
TURBO WASH	Press "TURBO WASH", strong cleansing function will be activated, the pressure is maintained at the highest level. The water pressure cannot be adjusted.
WATER PRESSURE	During the cleaning process, press "WATER PRESSURE" to adjust the water pressure.
POSITION	During the cleaning process, press "POSITION" to adjust the nozzle position.
WATER TEMP	Press "WATER TEMP" to adjust the water temperature to low, medium, and high levels.
SEAT TEMP	Press "SEAT TEMP" to adjust the seat temperature to low, medium, and high levels.
AIR TEMP	Press "AIR TEMP" to adjust the air temperature to low, medium, and high levels.
LIGHT	Press "LIGHT" to turn on/off the light.
ECO	In the off state, press "ECO" briefly to turn on the power. In the on state, press "ECO" briefly to turn off the ECO mode. In the on state, press and hold "ECO" for five seconds to turn off the power.

8.Troubleshooting

No.	Trouble	symptom of trouble	What to do
1	Bidet can not work	Power led is not lit	I. Check whether there is a power outage. II. Is the shutoff valve closed? Fully open the shutoff valve.
2	The nozzle does not come out		I. Check whether the PE pipe is linked and straighten the hose. II. Check whether the valves are all opened and open the valves. III. Confirm whether the water pressure at home meets the standard. IV. Confirm whether a higher level of water pressure is required and adjust the water pressure.
3	The cleansing water pressure is weak	Can not feel the water pressure	I. Confirm whether the protective cover has just been used, and wait until the flushing is completed before using. II. Check if the water temperature is turned on and turn it on if it is not. III. When the weather is too cold, it will cause the water temperature to rise slowly.
4	Water Temperature unstable	Water temperature is high or low	I. Check whether the protective cover is stuck and adjust the cover. II. Adjust the position of the nozzle and set it to the maximum level.
5	Nozzle Trouble	The nozzle did not reach the intended location.	I. Check whether the air temperature is turned on and adjust the air temperature level.
6	Air trouble	Air is too cold	I. Confirm whether the air temperature is turned on and adjust the air temperature level.
7	Seat is too cold		Confirm whether the seat temperature is turned on and adjust the seat temperature level.

9.Specification

Item	Electronic Bidet Toilet Seat
Rated power supply	AC 110V 60HZ OR AC 220V 50HZ
Rated power consumption	1200W
Power cord length	1.2m
Water protection level	IPX4
Water supply pressure	0.08MPa-0.8MPa
Safety device	Leakage protection
Type of water heater	Instantaneous type
Water temperature	Adjustable temperature range: OFF, about 34 to 40°C
Water cleaning	Rear cleaning: Approx. 0.5-0.8L/min Front cleaning: Approx. 0.5-0.8L/min
Mixing air and water	Mixing air and water
Safety device	Temperature Sensing
Air temperature	Adjustable temperature range: about 45 to 55°C
Safety device	Temperature fuse
Air speed	5-7 m/s
Surface temperature	Adjustable temperature range: about 32 to 40°C
Safety device	Temperature fuse
Open/Close Structure	Slow-Close

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.