

F1 FORMULA REMOTE CONTROL RACING MANUAL

Thank you for using our toy products. In order to make you have a better understanding of this product, please read the following instructions before use, which will bring you a different sense of operating experience.

Note

- Electronic control products
This product is suitable for children 14 years old and above. After being assembled and charged by adults the children can play.
- Please use this product under the supervision of an adult.
Please do not disassemble or modify this product without authorization. Any modification may cause the product to fail to operate normally.

Precautions for use

1. The toy car uses 1 piece of 3.7V rechargeable lithium battery; the remote control uses 2 sections of 1.5V "AA" non-rechargeable batteries;
2. Take out and install the battery according to the polarity and voltage in the toy battery room;
3. 2 sections of 1.5V are non-rechargeable batteries, please don't charge them;
4. The rechargeable battery must be charged under the supervision of adults;
5. Different types of batteries or old and new batteries should not be mixed;
6. The battery of the car body must use the configuration of original factory, and use the USB provided by the original factory to charge the body battery.
7. If you stop to play, take out the batteries from the car;
8. The power terminal must not be short circuited;
9. Use a screwdriver to open the screws on the battery compartment cover of the remote control, and install the battery according to the correct positive and negative polarity; Connect the power plug line with the body power line according to the correct polarity. Then close the battery cover and tighten the screws;
10. Repair and maintenance: This product is composed of plastic, hardware and electronic components. Avoid water ingress, don't place or use in a humid environment for a long time. Regularly check whether the wires, plugs, housings and other parts are defective, if found, stop using them and wait until they are repaired before using them.


2.4G automatic code instructions

1. When the battery is installed on the remote control, the indicator light of the remote control starts to flash, and the remote control car turns on the switch and starts to enter the connection state. When the connection is successful, the remote control indicator light goes out. Note: if the connection is not successful, please repeat the above operation.
2. Each remote controller can only be connected to one remote control vehicle. When the connection is successful, each vehicle will not interfere with each other.
- Note: multiple vehicles cannot be connected at the same time.
3. If the remote controller does not find the 2.4G signal from the remote control car one minute, it will automatically enter the sleep mode (the indicator light is off), you can press any key to exit the sleep mode.
4. When it is necessary to pair other remote controllers or remote control vehicles of the same model, take out the battery of the remote controller and turn off the power supply of the remote control car. It can only be paired again after switching.

Operation tips


- Please make sure that the power switch is in the "ON" position, when you are operating, such as the power switch is in the "OFF" position, the remote control car is turn off.
- When the battery power is consumed, the left and right steering becomes insensitive, and the forward and backward will also slow down. At this time, the battery needs to be removed and charged.
- The effectively controls distance of this remote control car is about 40 meters. When the distance is exceeded, the remote control car may stop or imagine uncontrolled.

(1)



How to play remote control car

1. Turn on the remote control car switch.
2. Operate the direction bar of the remote control to control the car forward or backward, left or right.
3. Turn off the switch of the remote control car after use.
4. After using, turn off the switch of the remote control car, the remote control will enter to sleep mode.



Water filling steps of spray



General troubleshooting


FAULT SYMPTOM	CAUSE OF ISSUE	APPROACH
VEHICLE CANNOT BE EXERCISED	1. The remote control is not selected or the switch of the remote control car is not turned on. 2. The remote control or remote control car is not properly inserted into the battery compartment. 3. Rechargeable battery power is insufficient.	1. Turn on the remote control car switch and reconnect the remote control. 2. Insert the battery into the remote control or remote control car correctly. 3. Charge the rechargeable battery.
VEHICLE IS UNCONTROLLED, REMOTE CONTROL DISTANCE	1. The power of battery in the remote control or the rechargeable battery is low. 2. There may be interference sources near the site.	1. Replace the battery in the remote control with a new battery or charge the rechargeable battery. 2. Change the venue.
EXCEPTION PROTECTION	1. When the function of the remote control car is hindered by external factors, the remote control function cannot be completed. 2. The circuit battery is short-circuited.	1. Re-open the power switch to remote control car power protection. 2. Check the venue.



The contained of small parts may have the dangerous of suffocated and is not suitable for children 3 years of age and younger. An adult must be present during use for monitoring and guidance. This manual has important information and should not be discarded for inquiries.

(2)

How to operate an induction watch




How to charge

1. This product use 3.7V battery. It need to charge before using.
2. First plug the USB wire plug into the charger plug according to the correct polarity connection, and then plug the charger plug into the socket.
3. When the battery is charged, the USB is equipped with a charging indicator. The "red light" is always on during charging. The indicator is on "Off" status. Do not overcharge. Charging for a long time will not increase the power.
4. Regularly check the toys and batteries, if these accessories-wires and plugs of the charging line are damaged, they should be stopped using, it can only be used after repair or replacement.

How to install the battery

Remote control

1. Open the battery cover of the remote control, and insert the 1.5V "AA" battery according to the positive and negative poles in the battery compartment of the remote control.
2. Close the battery cover and twist the battery cover switch button.



Instructions

The battery charger of this toy must be checked regularly to prevent damage to wires and other parts. In case of damage, it can only be used after being repaired.

Notes for consumers

1. When playing the remote control car indoors, please be careful not to cause damage to furniture or glass.
2. Please play in a safe place outdoors. Don't play remote control cars on the road and the crowd, as to avoid danger.
3. When playing a remote control car outdoors and hear thunder, stop playing immediately.
4. When playing a remote control car outdoors, do not swing your hand and reach close to avoid injury, and do not get involved in hair or clothes.
5. Do not drive the remote control car towards people.
6. Do not drop the remote control car.
7. When placing the remote control car, please keep away from fire and high temperature.
8. The car uses a complex electronic circuit and a large number of components, please do not disassemble or modify the circuit board at will.
9. When the remote control car is covered with mud and dust after playing, it must be wiped gently with a damp cloth.
10. Do not put toys in water, this will damage electronic components.

(3)

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.