

RGB LED LIGHT BAR

Instruction Manual

Please read the manual carefully before use




How it Works


Smart RGB Light Bar senses rhythm in real-time through built-in MC to sync with music, illuminate full-spectrum RGB LED beads, display dynamic lighting effects and a whole visual-audio feast. Multiple lighting configurations further spice up the atmosphere of various scenes.

Use Operation

1, Control Receiver



2, Remote control (The remote must be aligned with the controller of USB line while use the remote.)



3, App User Interface

1).Scan the QR code to download the app "Raingel", or open App Store, search "Raingel" and download the app.



2).Open Bluetooth, enter the app, click the icon "Raingel", it will enter Bluetooth Control Interface and automatically connect to the device.



Specification

Material: ABS+PC	Supply Voltage: DC 5V
Cable Length: 1.6m	Overall Dimensions: 9cm*9cm*27.7cm

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Statement

To maintain compliance with FCC'S RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm between the radiator and your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.