




ui

User Manual







Ui Mug



OHOM Pad




Power Adapter





USB Type C Cable




For max performance
Only use the provided adapter



Glass side facing up




100 - 240V



HEATING THE Ui MUG


- Purple LED

Place the Ui mug on the OHOM Pad. The LED will pulse purple, indicating that the mug is currently being heated. It will maintain the drink's temperature at approx. 130°F/55°C. Adding the ceramic lid can further increase the temperature of the beverage.



COFFEE & TEA STRAINER

Place the strainer directly into the mug for coffee/tea brewing. *Sold separately



Wireless Cell Phone Charging

- **Blue LED**

Place Qi-compatible phone on the OHOM Pad. The LED will pulse blue and the charging icon will appear on the phone screen.

Please avoid placing your cell phone face down on the OHOM Pad, as this may result in screen burn. Such damage might not be covered under the warranty.



FOR YOUR SAFETY

The OHOM Pad is capable of detecting a variety of foreign metal objects. For safest operation, do not place foreign metal objects on the OHOM Pad.



DO NOT MICROWAVE

The bottom layer on the Ui Mug contains metal particles, do not microwave.



OVERHEAT PROTECTION

When the mug is overheated or has been sitting on the OHOM Pad for 60 minutes without picking it up, it will automatically shut off.



WARM OHOM PAD

If the OHOM Pad becomes hot after heating the mug, wait until it cools down before charging your cell phone.



DO NOT LEAVE MUG EMPTY

Heating the empty mug without liquid may cause the ceramic to crack, do not heat empty mug on the OHOM Pad.

CLEANING

- **Ui Mug:** Hand-wash and dishwasher safe
- **OHOM Pad:** Clean with damp cloth and mild cleaning solution. The unit itself is spill-resistant but cannot be submerged. Avoid exposing it to excessive amounts of water.

SPECIFICATIONS

Ui Mug

Material: Fine ceramic

Volume: 12 fl oz/Ui, 18 fl oz/Ui Plus

OHOM Pad

Max output: Android 15W(max), Apple 15W(max)

Mug heating 22W(max)

- If the OHOM Pad is having an issue, unplug it, wait for 15 seconds, and then plug it back to reset the unit. Visit our website at ohom.com for more information.

OHOM[®]

Designed in Los Angeles, USA. Precision made in China

©2024 OHOM Inc. All rights reserved. ohom.com

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- .
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF exposure statement:

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance between 20cm the radiator your body.