

Operating Instructions

The remote is used for the pool lights only.

Note: Before using the remote, please install the matching battery and turn the switch on the side of the remote to the "N" position.

Battery Specs: 12V 23A

Control distance: 30 meters

Working Frequency: 315MHz

	ON key: Power On	OFF key: Power off
	BRI+ KEY: brightness +, 6 grade in total BRI- KEY: /brightness -, 6 grade in total B/PU key: slow animation blue/purple G/YE key: slow animation green/yellow B/CY key: slow animation blue/cyan R key: static red color G key: static green color B key: static blue color WHT key: static white color YE key: static yellow color (R+G) CY key: static cyan color (G+B) PU key: static purple color (R+B) Rainbow key: multiple colors gradual changing Four seasons key: multiple colors fade changing DISCO key: multiple colors flash changing PARTY key: multiple colors jump changing	

FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

IMPORTANT NOTE:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.