


FUNCTION INSTRUCTION OF Emitter



① Main switch (Turn off all lights and stop fan operation)	⑧ Cool white light ON
② Natural wind	⑨ Warm yellow light ON
③ Fan - Forward/Reverse	⑩ Natural light ON
④ RGB color dynamic cycle switch (Scene mode light-Melody,Rainbow, Breath, Fire, Colorful, Dazzle, Flash, Slow)	⑪ Light ON/OFF
⑤ RGB color static cycle switch (6 light colors change-Yellow, Red, Green, Blue, Violet, Cyan)	⑫ LED light brightness decrease (Short press 1 level, long press continuously lower)
⑥ Speed control (1-6 Speeds)	⑬ LED light brightness increase (Short press 1 level, long press continuously higher)
⑦ Fan Off (Long press to pair the emitter and receiver)	⑭ 2/4/8H Timer (Long press to cancel)

KINDLY REMINDERS:

1. Learning code matching mode is used between emitter and receiver. Turn on the supply power within 10 seconds and short press the emitter's " " button, when the indicator light on the emitter stops flashing the learning code code matching is successfully. (PS: Learning mode is not accepted after turn "ON" the supply power for 10 seconds.)
2. When the emitter can not control the receiver, please check the battery switch touching normally or not, correction of the positive and negative, full or empty of the power.
3. When the emitter cannot control the receiver, please check is there any existence of similar remote controlled products nearby, then check whether they works, because remote controlled product with the same frequency will disturb each other.
4. Low voltage of battery will affect the sensitivity of the emitter and the signal reception accordingly (the indicated light will flash out its warning when the battery get low voltage), must replace if the battery is getting low voltage.
5. Please take out the battery from the emitter when leaving unused for long time.
6. The maximum load of lighting see the above "POWER PARAMETER LIST"
PS: Please connect the ground wire correctly, otherwise it may cause the light micro-light or flash.
7. When installing the fan, the fan ceiling cover don't press the antenna (or other wire), it is easy to breakdown the wire and short-circuited.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

The devices has been evaluated to meet general RF exposure requirement , the device can be used in portable exposure condition without restriction