

Catalog

Cautions	01
Product Inspection	02
Familiar with this machine	03
Operating Instructions	04-05
Troubleshooting	06
Warranty Card	07
Certificate of Conformity	07

Cautions

- ◆ The repair and adjustment of this walkie-talkie is only authorized to the maintenance personnel with contractual authorization.
- ◆ To avoid problems caused by electromagnetic interference or electromagnetic compatibility, please turn off your walkie-talkie in places where the "Please turn off your walkie-talkie" sign is posted, such as hospitals and other health care facilities.
- ◆ When boarding an airplane, please turn off the walkie talkie when requested by the crew.
- ◆ In cars with airbags, do not place the walkie talkie within the area that may be involved in airbag deployment.
- ◆ Before entering a flammable or explosive environment, please turn off the walkie talkie and remove the battery.
- ◆ Do not continue to launch for too long, as the walkie talkie may overheat and burn, even damaging the walkie talkie.
- ◆ Do not use radios with damaged antennas, which may cause minor burns when in contact with the skin.
- ◆ Do not expose the walkie-talkie to direct sunlight or place it near a heating device for a long time.
- ◆ In the unlikely event that you notice any odor or smoke coming from your walkie-talkie, please remove the battery immediately and contact your nearest authorized dealer.
- ◆ In order to ensure the best intercom effect, it is recommended that the voice source and the intercom front vertical distance of 5 to 10 centimeters.
- ◆ Non-emergency, shutdown please follow the normal process, do not arbitrarily and frequently directly pull the battery shutdown.
- ◆ Other public places and administrative departments have special requirements for the use of walkie-talkies, please follow the requirements.

01

Product Inspection


Welcome to use the walkie-talkie, is before use, you are advised to:

- Please check the box of this product for signs of damage first;
- Please open the box carefully and check if there are any items listed in the table below inside the box. If you find any loss or damage in the handling of this product and its vicinity, please contact the distributor immediately.

Accessories	Quantity
Walkie Talkies	One
Battery Pack	One
Charger	One
Charging cable	One
Lanyard	One
Back clip	One
User manual	One

Note: For more information on optional accessories, please contact your dealer.

02

Familiar with this machine

03

Operating Instructions**Insert a SIM card**

Insert a valid SIM card (User Identification Card) into the machine before using it.

Side key ①: Menu function key (confirmation key)

Insert a valid SIM card (User Identification Card) into the machine before using it.

Press the side button ① briefly to enter the menu function, and then press the side button ① again to confirm the menu function after selecting the desired menu function by toggling up and down the dial button ③, and then press the side button ② briefly to exit the function selection.

Side key ② : On/off key (exit, return key)

Press and hold the side button ② for two seconds, the machine turns on, and in standby mode press and hold the key for three seconds to turn off the machine.

Dial key ③ (flashlight and selection key)

Press and hold up for ③ seconds to light up the flashlight (weak light), and then short press up to light up the flashlight in order of weak light, strong light, flashing, cycle, in this state, short press down or short press the side button ② to turn off the flashlight. In standby or call status, toggle button ③ up and down to adjust the volume level.

Select Group (Group Call)

In standby mode, operate the menu function to enter the group list, select the corresponding group, press the confirmation button to enter.

Member selection

Operate the menu function to enter the member list, select the corresponding member, and press the confirmation key to enter the single call status.

04

Operating Instructions**PTT key**

A : In standby mode (green light flashes slowly), press the PTT key to initiate a call (red light on).

B : During the call, when voice is received (green light is on). When the call is finished, it returns to idle state (green light flashes slowly).

Display operation

According to the machine display function operation, group, single call, temporary call, set menu and other functions.

Use of headphones

Please use the special headphones for this machine.

Press the PTT button on the headset to initiate the call and release the PTT button to release the call.

05

Troubleshooting**Troubleshooting Guide**

If your walkie-talkie shows the following phenomena during use, please check the following information first and contact your dealer if you still can't rule it out.

Poor signal reception

Possible causes: You are currently located in a location where the network signal is weak (e.g. basement or near a building) making it impossible for radio waves to communicate effectively, or the network is busy (e.g. high traffic on the network during peak hours, making it impossible to talk).

Solution: a. Please move to a location where you can receive the network well.
b. Please avoid using it during similar hours or please wait for a while and try again.

Echo or have noise

Possible cause: Some network operators have poor network relay lines. Solution: Turn off and then reboot, you can automatically search the base station to switch to a better quality network.

Try again in a moment

Possible reasons: Standby time is related to the network operator's system settings, the same walkie-talkie in different network operators in different systems, standby time is not the same; or battery depletion, in high temperature or cold environment, battery life will be shortened; and if you can not connect to the network, the walkie-talkie will continue to transmit the search base station signal, the walkie-talkie will continue to consume battery power, resulting in shortened standby time.

Solution: If you are in an area with a weak signal, turn the walkie-talkie off temporarily.

Unable to connect to the network

Possible causes: The UM card is running out of traffic, the signal is poor, or you are not in a network service area.

Solution: Switch to a valid UM card, move to a more open location and try again, or if you are inside a building, move to a window and try again.

06

Warranty Card

Machine type _____ Purchase Date _____

Serial number _____

Seller _____ Contact number _____

User Name _____ Contact Number _____

Address _____ Zip Code _____

Instructions

1. The warranty card is kept by the customer as a proof of warranty, lost without replacement.
2. This card must be stamped by the point of sale and fill in the date before it can take effect.
3. The card shall not be altered, please confirm the warranty card series number and the purchase of the machine number match, otherwise invalid.
4. The warranty period is one year, the charger, battery, headset, antenna and feeder are consumables and are not covered by the warranty.
5. Users can choose the following ways to obtain maintenance services:
 - a. In the original purchase office for.
 - b. Our company in the local special maintenance point.

Product Certificate of Conformity

Product Name _____

Product Model _____

Quality inspection date _____

The product has been tested to meet quality standards. The product test is qualified. Approved to leave the factory

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

Specific Absorption Rate (SAR) information:

This product meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device type: G388 (FCC ID: 2BPL5-G388) was also tested against these values. The highest SAR value for accessories worn on the body, face is 0.66 W/kg and 0.30 W/kg. The device tested typical body wear operations with the back of the product 5mm from the body. To meet FCC RF exposure requirements, use accessories that maintain a separation distance of 5mm between the user's body and the back of the product. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.