

USER MANUAL

Please read this manual sheet before using.

PHONE TRIPOD

EM-TS62-FG



Warning:

- Do not exceed the light stand maximum load capacity.
- Ensure the light stand is locked.
- Do not operate this light stand when the temperature is below -20°C or above 70°C. It is not recommended to operate in saltwater.
- Do not put this light stand in sunlight or lean it against the glass of car for a long time.
- Do not leave this light stand unattended in public place; please be careful when use it in dangerous place.
- Remove the camera from the ballhead during setup or transport.
- It is not necessary to equip lubricant. Please use standard lubricant or grease when necessary.
- For your safety, keep it out of power supply.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



Installation:

- 1 When the light stand locking knob is released, press down the leg to the needed angle, and then lock the light stand locking knob.
- 2 Loosen the loading plate and lock the knob, the angle of the loading plate can be adjusted as required.
- 3 Open the flip lock, pull out of the center column to the required height and press the flip lock.
- 4 The tripod is detachable. Rotate the bottom of the tripod to change the self-portrait mode, which makes the grip feel more comfortable.

2 in 1 Design:

Product illustration



SPECIFICATION:

COMMUNICATION	BLUETOOTH V 3.0.	BATTERY LIFE	Approx 6 months using 10x/day
FREQUENCY	2.4 GHz-2.4835 GHz	DIMENSIONS	48mmx30mmx10mm
MAX RANGE	30ft (10m)	WEIGHT	10g

STEP 1 PAIRING

A: Turn on the switch on the side of the Bluetooth, the blue LED light flashes

B: Open the Bluetooth settings of the mobile phone and connect to "EMART" in the list of optional devices

Pairing complete

STEP 2 USING

Open your phone's camera app. Press the button associated with your phone's operating system (iOS for iPhone, Android for Android Phones).

Note: If your camera does not respond it may not be compatible. In this case, download the free app "Camera 360" and use this camera app with the remote.

STEP 3 SHOOTING

Switch your phone's camera into Video mode/Picture mode first. Press the button to start/stop recording videos. Suitable for live streaming, travel, selfies, videos.

Note for Samsung Cell Phones:

1. Go to camera setting scroll down and tap "Volume keys function" and choose "Record video".

2. Open the native camera, click the iOS button (Not android) to start the video, click again to stop the video.