



WANYINBA 万音霸

E200

Bluetooth speaker


user manual

Thank you for choosing WANYINBA products, in order for you to better understand and use this product, please read the following carefully before use!

What's Inside the box?

M9 speaker host User Manual
USB-C charging cable Portable lanyard
AUX audio cable


quick start guide




Press and hold the power button for 2 seconds to turn on the device. At this point, the indicator light will flash blue, indicating that you are waiting to connect and turn on your phone's Bluetooth. When you find: BT Sound M9, click to connect. The speaker's indicator light will slowly breathe and there will be a successful connection prompt sound, and you can play music on your phone.

In Bluetooth mode, press and hold the [mode key] for 2 seconds to disconnect the Bluetooth connection: After disconnection, press and hold again for 2 seconds to reconnect to the previous disconnected Bluetooth device.


Function List



List of Interfaces



Key List



charge

Please fully charge before first use to extend the lifespan of the built-in battery

	charge	Indicator light red
	Fully charged	The indicator light is off

Please use a charger that complies with the national 3C standard, 5V/2A for charging

CONTROL

	Power on/off	Press and hold for more than 2 seconds
	RGB lamp control	Short press to switch/turn off the light effect
	Bass/Vocal Switching	Double click to switch sound effects

The RGB lights will only light up and change when the E200 speaker is turned on

	play/pause	Short press
	Handsfree/Call	Short press to connect/disconnect/ long press for 2 seconds to disconnect
	TWS pairing mode	Long press for 2 seconds to enter TWS pairing

	volume control	Short press to adjust the volume level
	Song switching	Long press the+/- keys to switch songs up and down

	Mode switching	Short press
	Disconnect Bluetooth	Long press for 2 seconds to disconnect Bluetooth connection

When the device cannot connect to the M9 speaker

Turn on the speaker power and press and hold the 'play' button for 5 seconds to clear Bluetooth pairing

Find and delete pairing with the name (BT Sound M9) already in the Bluetooth settings of the phone

pen the speaker again and search for pairing connections again.

TWS dual machine Interconnection

Two identical M9 speakers can be paired with each other, so both play the same audio (one as the L channel and one as the R channel)

Operate one of the speakers, long press the play button for 2 seconds to enter TWS pairing mode. After successful pairing, you will hear a prompt sound;

Open your phone's Bluetooth and search for BT Sound M9. Once connected successfully, you can enjoy a surround sound field composed of two speakers

After successful Interconnection, you can long press the play button for 2 seconds to disconnect TWS interconnection

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.