

STRONG RACING


USER MANUAL

3+AGES





REMOTE CONTROL CAR FREQUENCY MATCHING

Install batteries into the RC car and the remote control.



Turn on the power: Pull the power switch of the remote control car to the "ON" position, then turn on the power switch of the remote control. If the remote control operation indicator light is always on, the frequency binding is successful.

BATTERY INSTALLATION



3.7V

Equipped with
USB charging
cable, which can
be connected to
the power supply
to charge the car

USB INTERFACE

USE RECHARGEABLE BATTERY
(Included)

Note: Always switch vehicle OFF when not in use to avoid reducing the life of the vehicle.

REMOTE CONTROL FUNCTION

Light control keys

Press once for slow flashing.
Press twice for fast flashing.
Press three times to turn it off.



REMOTE CONTROL BATTERY INSTALLATION



Open the battery compartment cover at the back of the control, install the battery, and close the battery compartment cover!

Control uses 2x1.5 v battery

(Not included)

Trouble Shooting Guide

Problem	Cause	Solution
Remote control dose not work	1. Batteries are installed incorrectly.	Check that the batteries are installed with correct polarity (+/-) as shown inside the battery compartment.
	2. The battery is low.	Replace new batteries.
	3. Vehicle is out of range of remote control.	The remote control car is too far away from the remote control, exceeding the control distance.
	4. Fail to link remote control with vehicle	Remove and reinstall the batteries to the remote control. Re-set the vehicle OFF to ON. Move the sticks on the remote control to re-link remote control and vehicle.
Vehicle does not work properly	1. The power switch is in the "OFF" position	Turn the power switch to the "ON" position.
	2. The vehicle is slow to respond.	Charge the vehicle.
	3. Vehicle is out of range of remote control.	Remove and reinstall the batteries to the remote control. Re-set the vehicle OFF to ON. Move the sticks on the remote control to re-link remote control and vehicle

ATTENTION

First turn off the engine, then turn off the remote control switch, remove the body battery and remote control battery. Every product needs to be maintained after each sports car.

Failure to do so may result in excessive loss or damage to the engine and circuit board.

Keep the battery in a ventilated area, away from hot equipment, open flames, direct sunlight, or near a battery.

Keep the battery out of place where children can not.

Some parts will heat up in the sports car and do not touch until the exhaust pipe or engine is completely cooled.

Thanks for the purchase

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction