## FM/AM/SW 3 BANDS RADIO WITH USBTF PLAYER



- 1. POWER/VOLUME
- 2. TUNING KNOB
- 3. EARPUHNE JACK
- 4. TF SLOT
- 5. USB SLOT
- 6. MODE BUTTON
- 7. USB PREV BOTTON

- 8. USB PLAY PAUSE BUTTON
- 9. USB NEXT BUTTON
- 10.TORCH LIGHT ON/OFF
- 11.FUNCTION SWITCH
- 12.CHARGING SLOT
- 13.TIE ROD ANTENNA
- 14.LED LIGHT

## **Operation instruction**

- 1. Place the 18650 battery or two AA1.5V batteries into a battery slot with correct polarity and cover the battery. (18650 battery already in tank)
- 2. Turn on the power switch and volume control (1), adjust it to the optimal volume, while the power indicator lights up.
- 3. Move band switch (11) to select FM, AM, SW programs.
- 4. Turn the tuner (2). And look at the frequency indicator window and dial pointer to search for the radio program you want.
- 5. When receiving FM radio, please pull out the telescopic antenna (13) and keep it vertical to obtain better receiving effect.
- 6. When using the built-in magnetic antenna to receive AM broadcast, the best reception effect can be obtained by rotating the direction of the radio.
- 7. In order not to affect others, please insert the earphone into the headphone jack (3)(the speaker inside the radio is automatically disconnected), you can listen to the radio through the earphone.
- 8. Please charge it after receiving it.
- 9. Turn off the radio by turning down the power switch and volume control (1) when you do not want to listen to the radio.

## **Accessories:**

USB charging cable \*1 18650 800mAh battery \*1

## **FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

  The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.