

<p>Volume Adjustment</p> <p>Play/Pause</p> <p>Previous Track</p> <p>Next Track</p> <p>Answer/End Call</p> <p>Reject Call</p> <p>Noise Cancellation Function</p> <p>In BT mode or mode, press the ANC button briefly to enable active noise cancellation. Press it again briefly to switch to transparency mode, and press it once more briefly to turn off the noise cancellation function.</p> <p>Turn Microphone On/Off</p> <p>Click the microphone mute key to turn the microphone on/off.</p> <p>Turn Decorative Lights On/Off</p> <p>Double-click the ANC key to turn on/off the decorative lights. Lighting effect: Press the ANC button three times to switch the light effect between "steady on/breathing gradient".</p> <p>Turn 7.1 Sound On/Off</p> <p>While playing music, press and hold the microphone mute button to toggle 7.1 sound on/off.</p>	<p>Adjust the volume using the wheel</p> <p>Single press</p> <p>Triple press</p> <p>Double press</p> <p>Single press</p> <p>Double press</p> <p></p> <p></p> <p></p> <p></p> <p></p> <p></p> <p></p>																				
	<p>Auto Power Off and Reconnect on Out-of-Range</p> <p>The headphones will disconnect when they go out of the effective range. After 5 minutes, they will automatically reconnect when back within range. If more than 5 minutes have passed, the headphones will automatically power off.</p> <p>Headphone Specifications</p>																				
	<table border="1"> <tr> <td>Wireless Protocol</td> <td>A2DP/AVRCP/HFP/HSP</td> </tr> <tr> <td>Reception Range</td> <td>10m</td> </tr> <tr> <td>Driver Unit</td> <td>40mm</td> </tr> <tr> <td>Frequency Response Range</td> <td>20Hz-20kHz</td> </tr> <tr> <td>Speaker Sensitivity</td> <td>115±3dB</td> </tr> <tr> <td>Speaker Impedance</td> <td>32Ω±15%</td> </tr> <tr> <td>Microphone Sensitivity</td> <td>-32dB±2dB</td> </tr> <tr> <td>Microphone Sensitivity</td> <td>-26dB±1dB</td> </tr> <tr> <td>Operating Current</td> <td>10-100mA</td> </tr> <tr> <td>Charging Voltage</td> <td>5V</td> </tr> </table>	Wireless Protocol	A2DP/AVRCP/HFP/HSP	Reception Range	10m	Driver Unit	40mm	Frequency Response Range	20Hz-20kHz	Speaker Sensitivity	115±3dB	Speaker Impedance	32Ω±15%	Microphone Sensitivity	-32dB±2dB	Microphone Sensitivity	-26dB±1dB	Operating Current	10-100mA	Charging Voltage	5V
Wireless Protocol	A2DP/AVRCP/HFP/HSP																				
Reception Range	10m																				
Driver Unit	40mm																				
Frequency Response Range	20Hz-20kHz																				
Speaker Sensitivity	115±3dB																				
Speaker Impedance	32Ω±15%																				
Microphone Sensitivity	-32dB±2dB																				
Microphone Sensitivity	-26dB±1dB																				
Operating Current	10-100mA																				
Charging Voltage	5V																				
	<p>Transmitter Specifications</p> <table border="1"> <tr> <td>Wireless Protocol</td> <td>A2DP/AVRCP/HFP/HSP</td> </tr> </table>	Wireless Protocol	A2DP/AVRCP/HFP/HSP																		
Wireless Protocol	A2DP/AVRCP/HFP/HSP																				
	<p>Transmission Range</p> <p>10m</p> <p>FCC Warning</p> <p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> ► Reorient or relocate the receiving antenna. ► Increase the separation between the equipment and receiver. ► Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. ► Consult the dealer or an experienced radio/TV technician for help. <p>The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p>																				
	<p>APP</p>																				