



A9



Karaoke Microphone with Speaker

User Manual

5V Charging



3.5mm Earphones Jack

Key Controls

Button	Function
Power On/Off	<ul style="list-style-type: none"><li>• Long Press (3s): Turn ON/OFF</li><li>• Short Press: Play/Pause music</li><li>• Double Clicks: Turn on/off two microphones connected to each other</li></ul>
Volume (+/-)	<ul style="list-style-type: none"><li>• Short Press: Adjust microphones volume</li><li>• Long Press: Adjust speaker volume</li><li>• Double Clicks: Adjust the reverb volume</li></ul>
◀/▶	<ul style="list-style-type: none"><li>• Short Press: Previous/Next song</li></ul>
Voice Changing Key	<ul style="list-style-type: none"><li>• Short Press: Original / Accompaniment</li><li>• Long Press: Switch to "Magic Sound"</li></ul>
M Key	<ul style="list-style-type: none"><li>• Short Press: Switch the flashing modes of light</li></ul>

Product:	Karaoke Microphone with Speaker
Model:	A9
Bluetooth Version:	V5.3
Output Power:	Rated 5W / 7W Max
Weight:	280g
Dimensions:	208mm × 113mm
Material:	ABS + Sponge
Battery:	1200mAh
Charging:	DC 5V/0.5A (Type-C Port)

Key Controls

1. Activate Pairing Mode:  
Long press Power button for 3s → Blue LED flashes.

2. Connect Device:  
Enable Bluetooth on your devices → Select "A9" in the device list.

3. Confirmation:  
Successful: "Dong" sound + Blue LED steady ON.  
Failed: Blue LED slow flashes (retry pairing).

Charging & Battery

Indicator	Status
Red Light Steady	Charging in progress (2-3 hours to full)
Light Off	Fully charged
White Light Flashing	Low battery (voice alert x3 → auto-shutdown)

⚠ Critical Warning:

- Use ONLY 5V/0.5A chargers (9V/12V adapters may damage hardware).
- Never charge near heat sources or in temperatures >50°C.

Technical Specifications

Parameter	Specification
Bluetooth Range	Up to 10m (unobstructed)
Frequency Response	200Hz~8kHz (±3dB)
Playback Time	>2 hours (max volume)
Standby Time	~12 hours
Operating Temperature	-10°C to 50°C
Charging Temperature	0°C to 45°C
Button Durability	5,000+ presses

※ Precautions—Usage & Safety

Bluetooth Performance:

Walls or metal objects may reduce the range to below 10m.

Temperature Limits:

⚠ Never expose to direct sunlight or hot cars.

⚠ Do not operate below -10°C or above 50°C.

Storage:

Charge to ≥50% before storing >1 month.

Store at 25°C max, humidity ≤75%.

Transportation:

Protect from rain and prolonged high-temperature exposure.

Troubleshooting

Issue	Solution
No Bluetooth connection	<div><div>1. Restart the microphone &amp; device</div><div>2. Ensure within a 10m range</div></div>
Short battery life	<div><div>1. Use correct 5V/0.5A charger</div><div>2. Avoid extreme temperatures</div></div>
Distorted audio	<div><div>1. Reduce volume</div><div>2. Check Bluetooth interference</div></div>

Contact Email: [senmeituo2021@gmail.com](mailto:senmeituo2021@gmail.com)

CE FCC RoHS

Made in China

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-- Reorient or relocate the receiving antenna.  
-- Increase the separation between the equipment and receiver.  
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.