

Product List



Mute Button

Metal Button



Transmitter		Pager	
Keyboard dimension	7.1*5.9*1.2inch	Pager dimension	4.1*1.9*0.4inch
Keyboard material	ABS	Pager material	ABS
Transmitting power	130mW	Distance of transmission	About 300 meters in a open
Keyboard frequency	433 MHz	Pager frequency	433 MHz
Power adapter	Input: AC 100-240V, 50/60Hz Output: DC 9V, 1A	Pager battery	Built-in 3.7V 200mAh rechargeable lithium battery
Key press method	Touch panel	Standby time	Approximately 20 hours
Manufacturer	LOUKIENE	Reminding method	Ring vibrate and flash
FCC ID Number		Brand	LOUKIENE
		Model	LK-P1B10

Instructions

1. **Charging**

- Before using, please connect the charging base to power, and put the pagers in the charging slot for 5 minutes to charge.

2. **Switch on pager**

- Connect the charging base to power. And put the pagers in the charging slots. Pagers will be switched on automatically.

3. **Switch off pager**

- Connect the charging base to power, and put the pagers in the charging slots. Input 999 in the keypad and Press Call.

- And all pagers will be switched off. Pagers need to be paired with transmitter first.

4. **Mute Button**

- There is a **Mute** button on the right side of the pager. Press it to stop the beeper when the pager beeps.

5. **Pager number setting**

- Take the pager off the charging base and take away the **plastic cover & paper sticker**.

- There is a small round **Metal button** on the front of the pager, and a **Mute button** on the right of the pager.

- Press **Metal button** and **Mute button** at the same time. And 2 lights will illuminate on the right of the pager for approx 4 seconds.

- Within this 4 seconds, press a number from 001 - 998. (Don't use number 999, as 999 is the shut-off function.)

- Press **CALL**, then the pager will buzz. Please press the **Mute button** or wait for a few seconds, and the buzzer will stop.

- If you need to change other pager's number, just repeat pairing method above.

6. **Transmitter ID setting**

- Connect the transmitter to power. Press the **DEL** & **CALL** buttons at the same time, and the display shows F1.

- Now press **CALL** button, the screen display a number. It is the transmitter ID.

- Now input a new ID number, and press **CALL** to save. Now the transmitter ID is changed. Transmitter ID can't be 000.

- After transmitter ID is changed, all pagers need to be paired again with this transmitter.

7. **Set ringing time / Mute setting**

- Take off the plastic cover on the pager first. Press the small yellow **Metal button** on the front.

- The pager has 5 LED lights. Each press of the Metal button will turn on one light.

- One light indicates an 8-second ringing time. If all 5 lights are on, the pager's ringing time is 40 seconds.

- To enable the **Mute setting**, press the **Metal button** again when all 5 lights are on. And all light on the pager will be off.

- The pager will only vibrate and flash, without any beeps. This signifies that the pager is muted.

- The duration of prompt will be 40 seconds

Note: 2 and more transmitters can call one pager. Please change the transmitters' ID to the same ID number.

When the ID is changed, all the pagers need to be paired again to work.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.