

LOUKIENE

Restaurant Pager System



Suitable for
variety of environments

LOUKIENE Restaurant Pager System



Prompt Modes



Each mode can be enabled & disabled
Duration and different speed can be set



Transmitter		Pager	
Keyboard dimension	9.3*8.8*1.2inch	Pager dimension	3.9*2*0.43inch
Keyboard material	ABS	Pager material	ABS
Transmitting power	130mW	Distance of transmission	About 300 meters in open field
Keyboard frequency	433MHz	Pager frequency	433MHz
Power adapter	Input: AC 100-240V, 50/60Hz Output: DC 9V, 1A	Pager battery	Built-in 3.7V 200mAh Rechargeable lithium battery
Key press method	Touch panel	Standby time	Approximately 20 hours
Manufacturer	Loukiene	Reminding method	Beep, Vibration and Flash
FCC ID Number		Brand	Loukiene
		Model	LK-P1B24

Instructions

Connect the base to power, and the screen will show 888, and a UXX number and show the keyboard ID.

When the screen is showing the keyboard ID, within 2 seconds press the GEAR button to enter setup mode.

(If can not enter the setup mode, please disconnect and reconnect the power cord. And try the procedure above again)

F1---Set the Keyboard ID (setting range "001~999")

- 1.Enter setup mode, the screen will display F1.
- 2.Press "GO", screen will display Keyboard ID and flash.
- 3.Input new Keyboard ID and press GO button to save.
4. After changing the Keyboard ID, all pagers needs to be paired with this keyboard again.

Please do not change it unless there are special request!

F2---Set the Pager's Number (setting range "001~999")

- 1.Enter setup mode, the screen will display F1.
- 2.Press UP/DOWN to go to F2 and press GO.
- 3.Input the Pager's number.
- 4.Pick up the pager from the base.
- 5.Press GO within 4 seconds, and the pager will beep.
And the setting is successful.
6. Repeat steps 3 to 5 until all pagers are paired.

F3---Set the beep/buzz time (setting range "0-250 seconds")

- 1.Enter setup mode, the screen will display F1.
- 2.Press UP/DOWN to go to F3 and press GO.
- 3.Screen will show 0. Input a number(from 0-250)
- 4.Pick up the pager from the base.
5. Press GO within 4 seconds, and the pager will beep.
And the setting is successful.
6. Repeat steps 3 to 5 until all pagers are set.

When set to '0', the pager will continue beeping/buzzing until manually canceled or placed back in the charging base.

F4---Turn on or off pager Beep

- 1.Enter setup mode, the screen will display F1.
- 2.Press UP/DOWN to go to F4 and press GO.
- 3.Now the screen will show 0. Input a number(0,1,2,3).
- 4.Pick up the pager from the base.
5. Press GO within 4 seconds, and the pager will beep.
And the setting is successful.

6. Repeat steps 3 to 5 until all pagers are set.

- 0: No beep, 1: slow speed (2 beeps within 3 seconds),
2: medium speed (3 beeps within 3 seconds),
3: fast speed (8 beeps within 3 seconds).

F5---Turn on or off pager Vibration

- 1.Enter setup mode, the screen will display F1.
- 2.Press UP/DOWN to go to F5 and press GO.
- 3.Now the screen will show 0. Input a number(0 or 1).
- 4.Pick up the pager from the base.
- 5.Press GO within 4 seconds, and the pager will beep.
And the setting is successful.
6. Repeat steps 3 to 5 until all pagers are set.
(0: Vibration OFF , 1: Vibration ON).

F6---Turn on or off pager Flash

- 1.Enter setup mode, the screen will display F1.
- 2.Press UP/DOWN to go to F6 and press GO.
- 3.Now the screen will show 0. Input a number(0, 1 or 2).
- 4.Pick up the pager from the base.
- 5.Press GO within 4 seconds, and the pager will beep.
And the setting is successful.
6. Repeat steps 3 to 5 until all pagers are set.
(0: Flash off, 1: Slow Flash, 2: Fast Flash).

Note: 2 and more transmitters can call one pager.

Please change the transmitters' ID to the same ID number.

When the ID is changed, all the pagers need to be paired again to work.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.