


TV STICK


User Guide

1.TV Stick General information




2.Installation

1.Plug the HDMI cable to the HDMI port of your TV set, then the power cable to the USB port. Afterwards, plug both cables in the respective ports of the TV stick.



2.Connect the TV Stick to the WiFi network



3.About the adapters that can be used to load TV stick

If you connect the USB power cable to an adapter, the ideal voltage is from 4.8V to 5.3V, and the input current should not be less than 1A. Some quick charge adapters are not suitable for the TV stick because the output voltage of these adapters may become very high during use.

4.Exemption clause

The illustrations included in this guide are for reference only. Due to the constant upgrade of the goods, the physical product may differ slightly from the illustrations. Always refer to the physical product. FCC Caution.

FCC Caution.

(1)§ 15.19 Labelling requirements.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
§ 15.21 Changes or modification warning
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
§ 15.105 Information to the user.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

RF warning for Portable device:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.
According to §15.247(e)(i) and §1.1307(b)(1), systems operating under the provisions of this section shall be operated in a manner that ensures that the public is not exposed to radio frequency energy level in excess of the Commission's guidelines.
According to KDB 447498 (2)(a)(i)