

User Manual


10000mAh Power bank



NOTE :

1. When use the wireless charging. Please press the power button again to initiate charging.
2. Thick or magnetic phone cases may impede charging. It's advisable to remove the case before charging.

Description



Specifications


Item No.: PB189
 Capacity: 3.85V=10000mAh 38.5Wh
 Output Capacity: 5V 6380mAh
 USB-C input: 5V=2A, 9V=2A, 12V=1.5A
 USB-C output: 5V=3A, 9V=2.22A, 12V=1.67A
 Cable-1 output: 5V=2.4A
 Cable-2 output: 5V=3A, 9V=2.22A, 12V=1.67A
 Wireless charger-1: 2.5W, 5W, 7.5W, 10W, 15W
 Wireless charger-2: 2.5W
 Max output: 5V=3A(shared)

Operation Instructions


To turn on/ off the power bank
 1. Button operation: Press the button once to power on and output wireless charger-1. Long press and hold for 1 second to turn on/off wireless charger-2. Double click the button to turn off.
 2. Automatic power on: Automatically power on and output when the charging port or cable are loaded.
 3. Automatic shutdown: It will automatically shut down after a light load of about 32 seconds.

Charging your devices


1. Using the built-in charging cable.
 Your smartphone electronic devices like etc will be charged by power bank automatically once connected with the built-in cable. If not, please press the power button to turn on the power bank.



2. Connect to the USB output port through other charging cable (not included).
 Connected to the USB output port to your devices with charging cable that come with your electronic device. Then power bank will start charging. If not, please press the power button to turn on the power bank.




3. Wireless charging is compatible with Apple Watch and phones and headphones that support wireless charging.
 Press the power button to turn on the wireless charging module, and place a device above the power bank. Then the power bank will start charging them.




Charging the Power Bank

1: Using the built-in USB-C charging cable.
 Connected power bank to AC wall charger/adapter through the built-in USB-C charging cable. The LED lights will illuminate and indicate battery level in the power bank. When all 4LED lights are on and solid/none are flashing, the power bank is fully charged.



2: Using the USB-C charging cable (not included).
 Connected power bank to AC wall charger/adapter through the USB-C charging cable (not included). The LED lights will illuminate and indicate battery level in the power bank. When all 4LED lights are on and solid/none are flashing, the power bank is fully charged.



Important safety Instructions

1. During the use of the product, it is normal for the shell to become slightly hot. After being fully charged, its temperature will gradually return to normal room temperature.
 2. Do not expose power bank to excessive heat such as sunshine, fire or the like.
 3. Do not expose power bank to dripping or splashing and no objects filled with liquids such as vases, shall be placed on the devices.
 4. Do not disassemble the power bank, incorrect assembly the power bank may result in a risk of fire or injury to persons.
 5. If the product is physically damaged, please do not continue to use it.
 6. Children are prohibited from using.



Do not dispose the lithium battery with general waste.
 Please return to battery recycling collection point.



MADE IN CHINA

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC RF EXPOSURE STATEMENT:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.