


Bluetooth Headphone

Parameter configuration

Truly wireless connection, achieving wireless stereo and HIF sound effects.

Note:
Before using this product, please fully charge it.



1. Simple operation instructions

① Earphones on/off:

1. Power on: Press and hold the physical button for 3 seconds to turn on the device.
2. Shutdown: Press and hold the physical button for 5 seconds to shut down.

② IOS&Android system connected headphones:

Open the phone's "Settings" - turn on Bluetooth search - find the pair name CK21 , click connect - display "Connected". After the phone connection is completed once, the headphones will automatically connect to the phone when the first point of the operation is used again.

2. Function Definition Explanation

①、Function definition in call state

Call answering	Click the Physical button
Hang up the phone	Click the Physical button
Call rejection	Double click the Physical button

②、Function definition in music state

Upper touch point	Press and hold for 3 seconds to play the next song, and press and hold for 1 second to increase the volume
Lower touch point	Press and hold for 3 seconds to go back one song, press and hold for 1 second to reduce the volume
Pause/Play	Click the Physical buttons

③、Noise reduction mode on/off

Noise reduction mode on/off	Double-click the physical button to turn it on, double-click the physical button again to turn it off
-----------------------------	---

3. Definition and parameters of charging compartment

Product status	Indicator light display
Charging in progress	The red light is always on
Fully charged	Full of lights off

Function	Describe
Battery capacity	1000MAH
Charging time	2.5H
Endurance capability	About 80H

Matters needing attention

1. Do not treat this product violently, do not squeeze it with heavy objects, and stay away from high temperature and high humidity environments.
 2. Stay away from WIFI, routers, and other high-frequency transmitting devices, as this can affect the signal reception of the device, causing sound jamming and disconnection.
 3. Please use this product in an effective environment (10 meters), and there should be no physical obstruction (such as walls) between the Bluetooth device and the earphones
- If the product is not used for a long time (within one month), charge the headphones.

Warranty Manual

1. Please keep this warranty card properly as proof of repair:

2. During the maintenance period of the warranty equipment, if the machine itself has functional problems or malfunctions under normal use and maintenance, and it is verified to be true, our company provides repair services;
3. During the warranty period, if any of the following events occur, our company has the right to refuse service or charge materials and service fees at our discretion.

- 1) Unable to provide this guarantee and valid proof of purchase:

- 2) Product malfunctions and damages caused by improper use by users:

- 3) Human or abnormal damage;

- 4) Damage caused by unauthorized repair services not authorized by our company;

- 5) Malfunctions and damages caused by natural disasters or other force majeure factors;
- 6) Intentional damage caused by others;
4. Our company reserves the right to modify and interpret all content.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

