Functional diagram of the watch

If you want to use gesture sensing, you need to turn off the power of the hand remote control and the car switch first, then restart the car switch to match the frequency.



- 1.Long press the power switch to turn on/off the watch power, short press power switch to turn on/off the car body music.
- 2.Long press the finger switch for a one-click demonstration; short press the finger switch to change between modes 1 to 3.
- 3.When the watch is out of power, the first light flashes continuously. When the watch is charging, the three lights flash in a cycle, and the light goes out when it is fully charged.


⚠ WARNINGS:

- Batteries should be inserted or replaced by adults or under adult supervision.
- This toy is not suitable for children under 3 years old. Small parts included in this package may cause a choking hazard.

RC Stunt Car Mode free switching

4 Wheel

Introduction of the Remote Control operation



- 1.If the red light on the remote control does not flash, it indicates successful frequency pairing. After 60 seconds of being unpaired, it will enter sleep mode (you can press any key to re-pair).
- 2.Adjustable sound & light: Short press the button to turn the lights on/off; long press the button to turn the sound on/off.

Watch with Stunt Car Function Description

1. Power On/Off:

Press and hold the power button for 2 seconds to power on/off.





2. Turn on the machine and enter the frequency setting mode:

three lights blink and wait for frequency setting. During this period, turn on the remote control car switch to automatically connect to the frequency setting.

3. Mode 1 (The First Light) function description:

Hand down tilt vehicle forward, Hand up tilt vehicle backward, Hand left tilt vehicle left lateral movement, Hand right tilt vehicle right lateral movement.



4. Mode 2 (The Second Light) function description Hands up to twist the shape; hands down to restore it to a parallel state. Hand left to tilt the vehicle for a left 360° rotation; Hand right to tilt the vehicle for a right 360° rotation.



5. Mode 3 (The Third Light) function description:

Hand down tilt vehicle 45° right upward, Hand up tilt vehicle 45° left upward, Hand left tilt vehicle 45° left downward, Hand right tilt vehicle 45° right downward.



FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - -Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.