


### **PROJECTOR**



Notice: the function will be different for camera and TOF focusing. Please remove the protective film before using. Otherwise this function may can't



### INTERFACES



- 1.Please do not put anything close to the wind-in or wind-out, at least 20cm away
- 2. Suggest to use the adapter in this package for power supply
- 3.Please make sure the camera is free of obstructions, so that the function of autofocus and auto-keystone works properly
- 4. Please do not look into the lens directly to avoid harming to your eyes.

### WI-FI CONNECTION

**Operation Steps** 


- 1. Turn on the projector and access the main interface.
- 2.Locate the "WIFI" icon at the top of the main interface and select it to enter the WIFI settings
- 3. Enable WLAN, then search for and select your home Wi-Fi network
- 4.Enter the password and click "Connect".

### **BLUETOOTH CONNECTION**

Operation Steps

- 1. Turn on the projector and access the main interface.
- 2.Locate the "Bluetooth" icon at the top of the main interface and select it to access the Bluetooth settings.
- 3. Enable Bluetooth, then search for and select your Bluetooth device.
- 4. Click to pair and connect.

# **TIPS**



- 2.Please keep this projector from drop or crash. Those may damage the components inside and cause abnormal display or blur image
- 3.Please turn off the projector after it has been worked continuously for 4
- 4. Please use the original power adapter and cable in the package. If you need a replacement, please contact your supplier.
- 5.Use the power cord carefully to avoid excessive bending; Damage to the power cord may cause electric shock and misfire
- 6. The power cord should be unplugged from the electrical outlet when you don't use it
- 7.Pay attention to waterproofing. This product is not waterproof. To prevent the risk of electric shock and short-circuit. Water showers or splashes should be avoided.
- 8.Do not use harsh detergents or solvents such as alcohol or thinners to clean the projector
- 9. The lens should be cleaned with a glasses cloth or lens paper, taking care not to scratch the lens
- 10.Please use a soft brush regularly to clean the vents and speaker sections of the projector, otherwise the vents will be blocked by accumulated dust and cause the projector overheating. This may cause malfunction of projector
- 11. High temperature attention. During or after projection, it becomes hot near the exhaust port, and if you touch it, it may burn your hand.
- 12. When it is projecting, please do not look directly at the lens, otherwise it may hurt the eyes.
- 13. Please do not disassemble the projector easily. There is a risk of electric shock, also affect the warranty.
- 14.Do not place any liquid or heavy objects on the projector
- 15.Do not place items that may cause blockages in the product vents around the product
- 16.If you find that this product is damaged, do not attempt to repair it yourself, please contact the supplier.

### Indicator Light (O) Power-on/off Home (4-) (**■**×) Volume -Volume + Up/down/left/right οĸ OK Input Source $(\mathfrak{g})$ Return Down Keystone Up Keystone $\star$ (3) correction correction Setup

INFRARED REMOTE CONTROL

- 1.It is recommended to use the remote control at a distance of no more than
- 2. When using the remote control, make sure that there are no obstructions between the remote control and the projector

## **PACKAGE CONTENTS**







Remote controlx1

Power cordx1



Instruction manualx1


If there is any omission, please contact the dealer immediately.

### **ROHS DECLARATION**

Part	Hazardous Substances Contained in the Product										
Descriptions	Cd	Pb	Hg	Cr (VI)	РВВ	PBDE	DEHP	ВВР	DBP	DIBP	
РСВА	0	×	0	0	0	0	0	0	0	0	
Cable	0	0	0	0	0	0	0	0	0	0	
Metal part	0	0	0	0	0	0	0	0	0	0	
Polymeric part	0	0	0	0	0	0	0	0	0	0	
Battery	0	0	0	0	0	0	0	0	0	0	
LCD Panel	0	0	0	0	0	0	0	0	0	0	

RoHS Directive (EU) 2015/863 amending Annex II to Directive 2011/65/EU

## INSTRUCTION MANUAL



MODEL: FS210P

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.
- -This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

版本	变更原因	日期
材质: 12 印刷: 2	05x142mm 三折页 28g铜版纸 双面、黑白 文字线稿均为K100黑) HS	
公差: (   名 税   设 计   校 及   审 定	物料編号 05.01.01.52   材料 工艺   十 李琳 2025.9.3 用量 1/1 单位   比例 共1	有限公司 mm 页 页