




# Dc variable frequency fan remote control

## Operating instruction



Energy-saving pioneer • Components in the future

Schematic diagram of controller wiring      Schematic diagram of controller installation




### Power meter

power supply 85V-265V

- Adopting RF wireless digital transmission technology, one-on-one control, with a repetition rate of less than one millionth (if damaged, both the controller and remote control must be sent back to the manufacturer for repair)
- In the allowable space, the load can be controlled by any Angle of the remote control, and the direction is not limited.

### Instructions for remote control



1. Turn off all loads
2. Fan speed control
3. LED indicator light
4. Turn on the light
5. Fan off
6. Fan positive and negative rotation control
7. Fan timing control
8. The remote control USES a pair of 1.5v batteries
9. Test the battery, try the lamp, please replace the battery!

### Tips:

1. The remote control and receiver are paired using a learning code. Within 5 seconds of the controller being powered on, the remote control is directed towards the controller; Press and hold the natural wind or total key for about 5 seconds, and when you hear a beep, it indicates successful learning. After successful learning, press the gear to use it normally (Note: Power on for more than 5 seconds does not accept learning).
2. When the remote control cannot control the controller, please check if the battery is correctly installed.
3. If the battery voltage is too low, it will affect the remote control distance and may cause the remote control to malfunction. Please replace the battery in a timely manner.
4. When not in use for a long time, please remove the remote control battery.
5. Supports a maximum of 300W of lighting.
6. During installation, do not compress all wires with the fan ceiling cover, as it may cause wire breakage and short circuits.
7. Do not use any dimming speed control switch.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.