FoWHAT
C1 Zero wireless mouse

User Manual

What's Inside


Mouse ×1

User Manual ×1

WHAT

**0.8m Braided Cable ×1**

GravaStar

1K Receiver ×1

"The illustrations in the manual are for reference purposes only;
the actual product may vary. The data mentioned in the manual is sourced from GravaStar;
please refer to the actual usage for accurate information."

A: Left mouse button	D: DPI switch	G: Ambient light	J: Teflon foot pad
B: Right mouse button	E: Mouse button	H: Wireless/Power Off/Bluetooth	
C: Scroll wheel	F: Mouse button	I: Wireless USB	

The E/F side buttons are fixed with a magnetic structure. If they fall off, they can be reattached.

Specifications ▶

Model :	FW C1
BT version:	5.0
Battery capacity:	400mAh
Input:	5V~300mAh
Interface type:	Type-C
Dimensions:	124(L) × 64.5(W) × 39.5(H) mm
Weight:	85g

Battery Indicator ▶

Low Battery Warning:
Battery level ⩽ 25% (Voltage < 3.3V) – Red light blinks
Charging: Red light stays on
Fully Charged: Green light stays on

When connected to a computer, the light will switch to ambient mode after full charge

Connection Methods ▶

2.4G Connection

1. Slide the switch to 2.4G mode. The receiver is pre-paired—just plug it into your computer's USB port
2. For manual re-pairing: After removing the receiver, press and hold Left + Middle + Right buttons for 3 seconds. The red light will flash rapidly (twice per second). Insert the receiver again to complete pairing. The indicator light will turn off upon success

Bluetooth Connection

1. Slide the switch on the bottom of the mouse to Bluetooth mode
2. Long press the DPI button for 3 seconds – the blue light will flash rapidly (twice per second)
3. Search for Bluetooth devices on your computer and select "FOWHAT C1_5.0"
4. Once connected, the indicator light will turn off

Bluetooth Reset ▶

Long press the middle button for about 5 seconds until the light flashes, then release. This clears the Bluetooth pairing history After reset, the blue light will flash rapidly (twice per second), entering pairing mode

Wireless Mode

Connect the USB wireless receiver to the computer.
Use the mode switch button and slide it to the left for 2 4G mode

Warranty

One-year warranty.

Within the warranty period of the product, if any malfunctions are due to the product's own quality, users can contact the retailer with purchase receipt to receive free repair services.

These will not be covered by warranty:

· Damage caused by self-disassembly.
· Malfunctions or damage resulting from water exposure, drops, or deliberate mechanical damage.
· Malfunctions or damage caused by force majeure events.

Manufacturer: Shenzhen Zhuoye Space Co., Ltd.
Address: Room 602-1, Building 6, Shenzhen
Bay Eco-Tech Park, Nanshan District, Shenzhen City,
Guangdong Province, China
Dongguan Lingjie Electronics & Technology Co., Ltd

Building 3, No.23, Zhenxing North Road, Taiyuan,
Xiegang Town, Dongguan City, Guangdong Province, China

EUT: Fowhat 2.4GHz Receiver Model: FW C1R
FCC ID: 2BRBZ-FWC1R

FCC ID: 2BRBZ-FWC1   RoHS

CMIIT ID: 25J44Q0DC100

222-258025 CE

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

– Reorient or relocate the receiving antenna.

– Increase the separation between the equipment and receiver.

– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

– Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled

environment. This equipment should be installed and operated with a minimum distance of 20cm

between the radiator & your body. This transmitter must not be co-located or operating in

conjunction with any other antenna or transmitter.

WWW.FOWHAT.COM

Made in China