

User Manual

Model: MINI SPARK REMOTE



Product Component Description

1	Spray hole	4	Fuse	7	Cooling fan
2	Vent	5	Power port	8	Access hole
3	Power switch	6	Powder hole	9	Vent

Product Parameters

Fountain height	2.5-3.5m	Fountain direction	Up
Interface	AC INPUT	Control mode	Remote
Gross Power	350W 3.6A 110V 350W 1.8A 220V	Heating way	Resistance wire heating
Power box capacity	60g	Housing material	Flame retardant ABS +PC
Fuse	110V/6A, 220V/3A	Size/N.W.	135*135*170mm 1.58kgs

1. Package Contents

Included in delivery:

- 1 x cold spark machine;
- 1 x power cord;
- 1 x remote controller;
- 1 x user manual.

2. Indicator Description

HEAT : Red light When the machine is heating, signal light is on.

READY : Green light When the "READY" green light turns from flashing into light on, it indicates that the machine is ready to work.

SLEEP : Blue light If there is no operation during the heating or ready state for more than 2 hours, the machine will enter sleep mode.

FAULT : Yellow light The light is on with any malfunction.

3. Remote Controller



ON : When the green light is flashing, press this button briefly to enter the heating state.

OFF : Press to turn off heating.

Start : Press to start spraying fireworks. Automatically stops if no operation within 22 seconds.

Stop : Press to stop spraying fireworks or stopping material cleaning.

CLE : Press to start material cleaning.

4. Operation Instruction

When the machine Heated up will enter self-test mode. The blower will run for about 1 second. If the green light flashes, it indicates that the machine is not faulty and is in standby mode. At this point, press the ON button to enter heating mode. The red light will always on display, and the heating will last for about 3 to 5 minutes. The green light will always on display, indicating that the heating is complete and the machine is ready. Press the start button to start spraying sparks upwards, and the spraying will automatically pause for 22 seconds upon completion. You can also stop spraying by pressing the stop button. After using the machine, press the CLE button to clean the materials.

5. Consumables

1) The consumables are classified as:

SMALL: the spark fountain height 2.5-3.5m, and the spot is rarely dropped, use for indoor.

LARGE: It is forbidden to use outdoor powder, which will cause material jamming and poor spraying effect due to temperature.

2) Consumables choice:

Consumables are the customized formula for the test of our machines. Please select our consumables to avoid affecting the effect of the machine; (No warranty service is provided for machines damage caused by consumables not from our company).

3) Consumables save:

Consumables should be kept in a dry and sealed environment to prevent moisture.(wet and sundry consumables should not be used).

4) Consumables add:

Please stop running the machines before add the consumables, to avoid accidental injury.


6. Clean and Maintenance

1) Cleaning function: Must do clean Powder after each events used, avoid be stuck by inside powder for next use. The residual power of screw rod can be automatically cleaned by remote controller.

Operation step: Firstly empty the remaining powder in the material box, and then press the clear button until no sparks are ejected.

If you need to save the equipment, please pour out the remaining powder inside for separate storage after cleaning, avoid to affect the next use of the remaining powder affected by moisture.

2) External cleaning: Please wipe the machine gently with soft cotton, to avoid scratch the machine housing.



3) Heat dissipation: Clean the residual powder and stop heating before storing the machine, keeping the machine power on with 5 minutes to remove the internal heat by fan.

7. After-sales

1) Warranty: 6 months (Subject to the date of manufacture).

2) Each machine is affixed with the factory code. The factory code shall be provided when enjoying the warranty service. It is invalid if torn. It's may need provide some videos or pictures to confirm the problems.

8. Warnings and Cautions

	Above: Holes for adding powder. Below: Spark spray outlet.
	The sign is to remind users of paying attention to risk and security. Please note that the machines are not meant to be a continuous duration effect. The maximum running time is 22 seconds and can be repeated but should not be done to overheat the machine.
	Eye protection warning sign is to remind you of protecting the eyes during the machine operation.
	Warning: Dangerous voltages are present in this machine when electrical power is applied. There is a danger of injury from electric shock. Under no circumstances are you to attempt to open the machine or attempt to remove or adjust any components fitted within the machine. Only fully trained engineers can open the equipment.
	Use caution so that any liquids do not wet the machine. Keep the machine and controller dry and not use rainy or snowy days unless covered.
Cleaning	Please check the spark nozzle before use to confirm if there are any accumulated particles. If there is, please invert the machine to the cleaning port for cleaning.

- 1)** The machine is equipped with a built-in protection program, which will automatically stop when the spark spraying time exceeds 22 seconds. If it needs to work again, please operate it again. If the continuous spraying time is too long, the internal temperature will rise sharply, causing permanent damage. It is recommended not to use it continuously for more than 1 minute.
- 2)** No in/out ports, cannot be series connection.
- 3)** If there is no spark out with enough consumables or other abnormal situation, please stop running machine and contact after-sale service for help.
- 4)** After use the machines, do not immediately turn off the power. The heat-dissipating fan should take out the internal air when the power is on. Otherwise, the internal heat is quickly transmitted to the surface of housing.
- 5)** Please place the equipment in an open place and keep a safe distance of more than 5 meters from the personnel.
- 6)** Make sure the device is off before filling the consumables.
- 7)** If the consumables are accidentally ignited, please use the sand to extinguish, do not use water.
- 8)** Damage caused by improper use or human factors is not covered by the warranty.

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

***RF warning for portable device:**

The FCC certification of this device refers to RF exposure testing performed in typical operating conditions, where a person is no closer than 0 centimeters from the device surface at all times, except for non-repetitive patterns with transient time intervals in the order of a second. Only in the stated conditions, the device is shown to fully comply with the FCC RF Exposure requirements of KDB 447498.