


高清网络摄像机使用说明书

感谢您购买此产品，使用前请仔细阅读本说明书，并妥善保管。

客户端下载

扫描下方二维码，下载并安装“V720”APP，或在手机厂商应用商店搜索“V720”下载并安装。



添加设备


1.根据下图引导，按下开机键后设备开机，等待设备蓝色指示灯亮起后，长按复位键重置设备蓝色指示灯快速闪烁。



2.打开“V720”APP，等待发现新设备弹窗，点击绑定设备。（如无新设备弹出窗，请点击首页右上角“+”添加设备）



*如未弹出提示框请点击APP右上角“+”，选择添加设备



3、选择或输入您想要配置的WiFi账号并填入密码。（注意仅支持2.4Ghz频段）



4.等待设备绑定成功。

绑定成功





添加完成

AP模式

1.根据下图引导，按下开机键后设备开机，等待设备蓝色指示灯亮起后，长按复位键重置设备蓝色指示灯快速闪烁。




2.手机打开WIFI连接“NAX_”开头的WIFI热点。




*手机提示“当前WLAN不可上网”或“无线网络未接入互联网”时，请点击“继续尝试使用无线网络”

3.返回“V720”APP下拉刷新页面出来设备即代表AP模式连接成功。



APP使用说明



使用说明与注意事项

安装SD卡

确保摄像机处于断电状态，拨动镜头使其向上，露出microSD卡槽。将microSD卡按照正确方向插入卡槽。

*安装或取出microSD卡，需要先切断摄像机电源后再操作。请使用正规厂商生产的microSD卡(仅支持FAT32格式,建议microSD卡读写速度不低于U1/Class10 级)

实时画面

在首页列表找到此设备,选择即可进行实时预览。通过摄像机的控制画面,可进行摄像机画面截取、清晰度调整等操作。

回放画面

在实时画面中，点击回放按钮即可进入到回放界面，拖动时间轴即可选择对应的时间段。

注意事项

- 1.本产品适用的工作温度为-20℃~60℃，请勿在温度过高或过低的环境下使用本产品。
- 2.本产品为精密电子产品，请勿在过度潮湿或可能会导致本产品进水的环境下使用本产品，以免影响正常使用。
- 3.为更好地使用本产品，应避免镜头正面及侧面靠近玻璃、白墙等反光物体，以免造成画面近处亮、远处暗或者发白的现象。
- 4.请确保本产品安装于Wi-Fi信号覆盖的范围内，并尽可能地放置于Wi-Fi信号更佳的位置;尽量安装在远离微波炉等可能对信号产生影响的位置。
- 5.本产品如需维修请联系相关人员。

High-Definition network camera user's manual

Thank you for purchasing this product. Please read this manual carefully before using it and keep it in a safe place.

Client downloading

Please scan the lower (right) QR code, download and install the "v720" app, or search for "V720" in the mobile phone application store to




Add device


1. According to the instructions in the figure below, press the power button to turn on the device, wait for the blue indicator light of the device to light up, and then press and hold the reset button to reset the device so that the blue



2. Open the "V720" APP, wait for the new device pop-up window to appear, and click to bind the device. (If there is no new device pop-up window, please click "+" in the



*If no prompt box pops up, please click "+" in the upper right corner of the APP and select Add Device



3. Select or enter the WiFi account you want to configure and fill in the password. (Note that only 2.4Ghz



4. Wait for the device to be bound successfully.




AP Mode

1. According to the instructions in the figure below, press the power button to turn on the device, wait for the blue indicator light of the device to light up, and then press and hold the reset button to reset the device so that the blue indicator light flashes quickly.




2. On your mobile phone, enable WiFi and connect to the hotspot starting with "NAX_".




*When your phone displays "This Wi-Fi has no internet access" or "Wireless LAN is not connected to the internet", please set "Continue using Wi-Fi anyway".

3. Return to the "V720" app, pull down to refresh the page. The appearance of the device indicates successful AP mode



APP使用说明



Instructions for use and precautions

Install SD card

Make sure the camera is powered off and flip the lens upward to reveal the microSD card slot. Insert the microSD card into the card slot in the correct direction. *To install or remove the microSD card, you need to cut off the power of the camera before operating. Please use products produced by regular manufacturers microSD card (only supports FAT32 format, it is recommended that the microSD card read and write speed is not lower than U1/Class10)

Live

Find this device in the home page list and select it for real-time preview. Through the camera's control screen, operations such as camera picture interception and definition adjustment can be performed.

Play back

In the real-time screen, click the playback button to enter the playback interface, and drag the timeline to select the corresponding time period.

Precautions

1. The applicable working temperature of this product is -20°C~60°C. Please do not use this product in an environment where the temperature is too high or too low.
2. This product is a precision electronic product. Please do not use this product in an environment that is excessively humid or may cause water to enter the product, so as not to affect normal use.
3. In order to better use this product, the front and side of the lens should be kept away from glass, white walls and other reflective objects, so as not to cause the picture to be bright near, dark or white in the distance.
4. Please ensure that this product is installed within the coverage of Wi-Fi signal, and try to place it in a location with better Wi-Fi signal; try to install it as far away from microwave ovens and other places that may affect the signal.
5. If this product requires maintenance, please contact relevant personnel.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC 's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.