

TAPHUB-User Manual

Model: TAPHUB

This product is worked with iPad (10th generation or later).

At the bottom housing, there is a black type-c cable. Connect the type-c cable to the iPad. Then, cover the top housing and install the screws between the top housing and bottom housing.

Insert a game card at the card slot at the bottom housing.

Turn ON the iPad, connect the iPad with international network.

Open the game app “Lottery”. The TAPHUB has a USB Hub and a NFC reader. The NFC reader should be able to detect the game card and show the existing balance. User can start to play the game.

When user finish to play the game. Turn OFF the iPad by pressing the power button.

There is a USB type-c connector at the bottom of the unit. User can connect a USB type-c cable with a PD fast charger to charge up the iPad. User can also connect a usual USB device, e.g. a mouse, a keyboard or a USB drive. The USB Hub will connect these device to the iPad.

There is a pogo-pin connector at the back of the bottom housing. User can use a dedicated magnetic cable to connect the pogo-pin connector to a PD fast charger to charge up the iPad.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction