# C4MAX-4MUSAA\_V8 Product Safety Infrormation User Manual

Release: V1.1

# Contents

Health and Safety Information	2
General Guidelines	2
Hospital Safety	3
Road Safety	3
Vehicles Equipped with an Airbag	3
Third Party Equipment	3
Efficient Use	
RF Exposure Information	4
Battery instructions	5
FCC Regulations	6
Support	7

## **Health and Safety Information**

### **General Guidelines**

- Electrical equipment may be susceptible to electromagnetic interference. Position the device away from video displays, monitors, radios, and other electronic equipment to avoid potential interference.
- Some medical devices may also be affected such as hearing aids and pacemakers. Consult a medical physician or the medical device manufacturer prior to using near the device.
- Do not use your device in hazardous environments where there are explosive gases or explosive products being processed.
- Aftermarket accessories may affect the device performance, the device stability or increase the probability of personal injury.
- Do not attempt to disassemble the device. There are no interchangeable parts in the casing.
- Do not allow the device or accessories to come into contact with liquids or moisture at any time. Do not submerge the device in any liquid.
- Do not place objects on top of the device. This may lead to overheating of the device.
- The device must be used in ventilated environment.
- Do not expose the device to direct sunlight or store it in hot areas. High temperature can reduce the life expectancy of the device.
- Do not allow children to play with the device.
- Use an antistatic cloth to clean the device. Do not use chemical or abrasive cleansers or risk of damage to the casing may occur.
- Use the device within the listed environmental ranges:
  - temperature range of -20°C ~ +55°C

Do not use your device during a thunderstorm.

- Do not remove the micro-SIM card unnecessarily. The micro-SIM card is susceptible to static electricity damage.
- Do not place the device alongside item affected by magnetic fields such as computer disks, credit cards, travel cards or other magnetic media. The information contained on the disks or cards may be affected by the device.
- Do not paint the device.
- Do not drop, throw, or subject the device to other physical trauma.
- Stay Eco-friendly. Recycle the packaging of your device after installation.

### **Hospital Safety**

Medical facilities have various rules for using wireless devices on their premises. Consult with the facility on any questions regarding the use of this device on hospital grounds.

### **Road Safety**

- Do not use any mobile devices while operating a vehicle.
- Do not store or carry flammable or explosive materials in the same compartment as the device.

### Vehicles Equipped with an Airbag

Airbags deploy with extreme force. Do not place any objects in the area over the airbag or in the airbag deployment area. If any item is improperly installed in the airbag deployment path while the airbag is jettisoned, serious injury could result.

### **Third Party Equipment**

The use of third-party equipment, cables, or accessories, not made or authorized by MUNIC, may invalidate the warranty of the device and adversely affect the device performance and stability.

### **Efficient Use**

For optimum performance with minimum power consumption, do not cover the device with anything. Covering the device may cause damage by operating at higher power levels than recommended.

# **RF Exposure Information**

The product must be used at a distance greater than 20 cm between the unit and the human body.

### **Battery instructions**

- a) Do not disassemble or open crush, bend or deform, puncture or shred.
- b) Do not modify or remanufacture. Attempt to insert foreign objects in to the battery, immerse or expose to water or other liquids, expose to fire, explosion or other hazard.
- c) Only use the battery for the system for which it is specified.
- d) Only use the battery with a charging system that has been qualified. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or another hazard.
- e) Do not short circuit a battery or allow metallic conductive objects to contact battery terminals.
- f) Replace the battery only with another battery that has been qualified. Use of an unqualified battery may present a risk of fire, explosion, leakage, or other hazards.
- g) Promptly dispose of used batteries in accordance with local regulations.
- h) Battery usage by children should be supervised.
- j) Avoid dropping the device or battery. If the device or battery is dropped, especially on a hard surface, and the user suspects damage, take it to a service center for inspection.
- k) Improper battery use may result in a fire, explosion, or other hazard.

### **FCC Regulations**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Caution:** Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

# **Support**

For all questions not related in this installation guide, please contact the support team by email at: <a href="mailto:support@munic.io">support@munic.io</a>