



2011A ZIGBEE USB Dongle UWER Manual

INDEX

1

1.接收操作.....3


2

2.傳輸操作.....9


1.接收操作

安裝 CustomCP210xDriverInstall 中的 CP210xVCPInstaller.exe 驅動程式後，執行下列步驟


- 1.1 插入 USB Dongle 開啓裝置管理員，
檢視 Silicon Labs CP210x USB to UART Bridge 爲 COM 多少




- 1.2 開啓超級終端機




1.3 任意輸入名稱




1.4 使用連線選擇裝置管理員顯示的 COM PORT，按確定





1.5 每秒傳輸位元選擇 38400，按確定





1.6 按 F5，顯示如下畫面




1.7 按下 D 顯示下方畫面



1.8 按下 B 顯示下方畫面



1.9 按下 i 顯示下方畫面




1.10 按+-切换 Channel

2.傳輸操作


安裝 CustomCP210xDriverInstall 中的 CP210xVCPInstaller.exe 驅動程式後，執行下列步驟

2.1 插入 USB Dongle，開啓裝置管理員


檢視 Silicon Labs CP210x USB to UART Bridge 爲 COM 多少




2.2 開啓超級終端機




2.3 任意輸入名稱




2.4 使用連線選擇裝置管理員顯示的 COM PORT，按確定





2.5 每秒傳輸位元選擇 38400，按確定





2.6 按 F5，顯示如下畫面





2.7 按下 D 顯示右側畫面



2.8 按下 B 顯示右側畫面



2.9 按下 j 顯示右側畫面



2.10 按+-切換 Channel

Federal Communications Commission (FCC) Statement

15.21

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

15.105(b)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) this device may not cause **harmful** interference and
- 2) this device must accept any interference **received**, including interference that may cause undesired operation of the device.

FCC RF Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Industry Canada (IC) Statement

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Canada, avis d'Industry Canada (IC)

Cet appareil numérique de classe B est conforme aux normes canadiennes ICES-003 et RSS-210. Son fonctionnement est soumis aux deux conditions suivantes : (1) cet appareil ne doit pas causer d'interférence et (2) cet appareil doit accepter toute interférence, notamment les interférences qui peuvent affecter son fonctionnement.

Informations concernant l'exposition aux fréquences radio (RF)

La puissance de sortie émise par l'appareil de sans fil SPECTEC est inférieure à la limite d'exposition aux fréquences radio d'Industry Canada (IC). Utilisez l'appareil de sans fil SPECTEC de façon à minimiser les contacts humains lors du fonctionnement normal.