



PMAN5100/PMAN5101 COVERT WIFI WINDOW MOUNT ANTENNA

INSTALLATION MANUAL





Foreword

This manual applies to digital mobile radios, unless otherwise specified. It includes instructions for installing the Covert WIFI antenna in a vehicle window mount configuration.

Product Safety and RF Exposure Compliance



Caution

Before using this product, read the operating instructions for safe usage contained in the Product Safety and RF Exposure booklet enclosed with your radio.

ATTENTION

This radio is restricted to occupational use only to satisfy FCC RF energy exposure requirements. Before using this product, read the RF energy awareness information and operating instructions in the Product Safety and RF Exposure booklet enclosed with your radio (Motorola Solutions Publication part number 6881095C99) to ensure compliance with RF energy exposure limits.

For a list of Motorola Solutions-approved antennas, batteries and other accessories, visit https://www.motorolasolutions.com/en_us/products/apx-story.html.

Document Copyrights

No duplication or distribution of this document or any portion thereof shall take place without the express written permission of Motorola Solutions. No part of this manual may be reproduced, distributed, or transmitted in any form or by any means, electronic or mechanical, for any purpose without the express written permission of Motorola Solutions.

Disclaimer

The information in this document is carefully examined, and is believed to be entirely reliable. However, no responsibility is assumed for inaccuracies. Furthermore, Motorola Solutions reserves the right to make changes to any products herein to improve readability, function, or design. Motorola Solutions does not assume any liability arising out of the applications or use of any product or circuit described herein; nor does it cover any license under its patent rights nor the rights of others.

Introduction

The vehicle WIFI window mount antenna is intended for mounting on the windshield of the vehicle. After completing the installation, the cable is concealed between the headlining and the roof of the vehicle, with minimum disturbance to the headlining and the upholstery. Figure 1-1 shows the WIFI window mount antenna.

PMAN5100



PMAN5101



Figure 1-1. WIFI Window Mount Antenna

FCC Requirements




Caution

To comply with FCC regulations when installing the antenna lead-in cable, do not shorten the cable.

Consider the following factors when installing an antenna.

- Install the vehicle antenna internal to the vehicle on the windshield, and in accordance with the requirements contained in this manual.
- Ensure the antenna cable is easily routed to the radio.
- Ensure that the antenna cable is routed separately and not in parallel to any other vehicle wiring or mobile radio cable wiring.

PMAN5100



PMAN5101




Figure 1-2. Recommended Installation on Windshield

Installation Procedure

The antenna installation procedure is for a typical passenger car. The procedure varies depending on the type of vehicle on which the antenna is installed. The procedure outlined is universal.

Installing the Antenna

1. Select a location for the antenna on the windshield. The antenna needs to be on the passenger side, close to the top, and on the front windshield.

NOTE:

- Ensure the antenna does not obstruct the view of the driver.
 - For optimum performance, choose a higher location on the windshield.
 - Do not mount the antenna to the dashboard or the rear deck as the antenna may obstruct the view of the vehicle driver, and effect optimal RF performance.
 - Check the antenna location for any electrical interferences. Keep away from metallic tint, defroster wires, or other obstructions on the windshield.
 - Keep WIFI antenna at least one inch away from the windshield edge and the car chassis metal.
2. Ensure the antenna is vertically polarized, so the radiation pattern is omni-directional.
 3. Test fit the antenna on the selected area before removing the release liner from the tape on the antenna mounting surface.
 4. Probe the headlining with your fingers to verify that all points of obstruction are avoided.
 5. Determine the routing of the cable from the antenna to the radio set, and remove the mold and trim necessarily to pull the cable through.

NOTE: Use an electrician fishtape if you experience difficulty with cable routing.

6. Ensure the mounting glass surface is clean and free of debris. Clean the surface area with a lint-free cloth using isopropyl alcohol to remove any residue grease or dirt.
7. Remove the release liner and carefully position the antenna above the selected mounting area.
8. Place the antenna on the mounting surface, and apply even pressure to allow the foam tape to conform to the windshield curvature.


NOTE: 50% of the bond strength is achieved after 20 minutes. Avoid contact with the antenna for a minimum of 20 minutes after initial installation. Full bond strength of the adhesive tape is after 72 hours.



Caution

The adhesive tape is very strong and bonds instantly on the mounting surface. Once the antenna is placed on the surface, it cannot be moved.

9. Recheck the connections, and reinstall molding and trimming.





MOTOROLA, MOTO, MOTOROLA SOLUTIONS and the Stylized M logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC and are used under license. All other trademarks are the property of their respective owners.
© 2017 and 2018 Motorola Solutions, Inc. All rights reserved.



PMLN7726B
Printed in

