

Technical Report 2.1033(b)(4)

Equipment Manufacturer

Golden Eagle Electronics Manufactory Ltd.  
16/F Southeast Industrial Building  
611-619 Castle Peak Road  
Tsuen Wan, Hong Kong

FCC Identifier

BFVGEE900T

Operating Instructions

See Exhibit 5

Trade Name

Golden Eagle

Model Number

GEE-900

Additional Model Numbers and Trade Names

Not Applicable



**Retlif Testing Laboratories**

**Test Report Number R-7654-1**  
**FCC ID: BFVGEE900T**

# MODEL GEE-900

## SAFETY INSTRUCTIONS

DO NOT EXPOSE THIS PRODUCT TO WATER OR MOISTURE.



CAUTION

RISK OF ELECTRIC  
SHOCK DO NOT OPEN



CAUTION: TO REDUCE THE RISK OF ELECTRICAL SHOCK, DO NOT REMOVE COVER OR BACK. NO SERVICEABLE PARTS INSIDE.



The lightning flash with arrowhead, within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure; that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance instructions in the literature accompanying the appliance.

1. **READ INSTRUCTIONS:** All the operating and safety instructions should be read carefully before the appliance is operated.
2. **RETAIN INSTRUCTIONS:** The operating and safety instructions should be retained for future reference.
3. **HEED WARNINGS:** All warnings on the appliance and in the operating instructions should be adhered to.
4. **FOLLOW INSTRUCTIONS:** All operating and use instructions should be followed.
5. **WATER AND MOISTURE:** The Wetness Sensor Receiver only should not be used near water, for example, near a bath tub, wash bowl, kitchen sink, laundry tub in a wet basement, or near a swimming pool, etc.

6. **VENTILATION:** The appliance should be situated so that it's location or position does not interfere with it's proper ventilation. For example, the appliance should not be situated in a bed, sofa, rug, or similar surface that may block the ventilation openings, or placed in a built-in installation, such as a bookcase or cabinet that may impede the flow of air through the ventilation openings.
7. **HEAT:** The appliance should be situated away from heat sources such as radiators, heat registers, stoves or any other appliances including amplifiers that produce heat.
8. **POWER SOURCES:** The appliance should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.
9. **IMPORTANT:** The following applies only to UL LISTED UNITS. This appliance is being supplied with the newly required safety feature of a Polarized Plug. You will note that one prong is larger than the other so that it fits only one way into the receptacle. DO NOT TAMPER WITH OR DEFEAT ITS PURPOSE under any circumstances.
10. **POWER CORD PROTECTION:** Power supply cords should be routed so they are not likely to be walked on or pinched by items placed upon or against them. Special attention should be placed to cords at plugs, convenience receptacles and at the point where they exist from the appliance.
11. **CLEANING:** the appliance should be cleaned only as recommended by the manufacturer.
12. **NON-USE PERIODS:** The power cord of the appliance should be unplugged from the outlet when left unused for a long period of time.
13. **OBJECT AND LIQUID ENTRY:** Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.
14. **DAMAGE REQUIRING SERVICE:** The appliance should be serviced by qualified service personnel when:
  - A. The power supply cord or plug has been damaged; or
  - B. Objects have fallen, or liquid has been spilled into the appliance; or
  - C. The appliance has been exposed to rain; or
  - D. The appliance does not appear to operate normally or exhibits a marked change of performance; or
  - E. The appliance has been dropped, or the enclosure damaged.


" This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: "

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

" This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation ".


## ***OPERATING INSTRUCTIONS***

### **CAMERA UNIT**



**MIC-**  
to collect sounds from the CAMERA UNIT  
and transmit to the MONITOR UNIT.


**Power ON/OFF -**  
to turn on the electricity of  
the CAMERA UNIT.




**INFRARED -**  
to turn on the night viewing feature.

# MONITOR UNIT

**POWER-**  
to turn on the electricity  
of the MONITOR UNIT.



**VOLUME-**  
to adjust the volume of the sounds  
transmitted from CAMERA UNIT.



DC JACK CENTER POSITIVE

## HOW TO OPERATE

- Turn the monitor power on by switching the power button to the right, the LED light is on.
- Turn the CAMERA UNIT on by switching the power button to the left, the LED light is on.
- The MONITOR UNIT featured with PLL technology, is automatically locked up the frequency transmitted from the CAMERA UNIT.
- Adjust the volume button on the MONITOR UNIT.
- Turn on the InfraRed button for necessary night viewing.