



EVS-6000 BT

Roadie™ Unplugged Mobile Amped Audio System

User's Guide

Mode d'emploi

Bedienungsanleitung

Guida all'uso

Manual del usuario

Gebruikershandleiding

Favor de leer las instrucciones antes de operar su producto.

Contents

1. Introduction	2
2. Battery Precautions	2
3. Getting Started	3
4. Installation	3
5. Bluetooth® Connections	4
6. Battery Charging	5
7. General Operations	6
8. Using as a Microphone for Phone Calls	6
9. Using the Audio Cable	6
10. Troubleshooting Tips	7
11. Product Care	7
12. Product Registration	8
13. Specifications	8
14. Hearing Protection	8
15. Operating and Storage Temperatures	9
16. Recycling and Disposal	9
17. FCC Notice (U.S. only)	9
18. IC notice	10
19. EU notice	10
20. Disclaimer of Warranties	10
21. Limited Warranty (U.S.)	11
22. Limited Warranty (EU & Switzerland)	12
23. Limited Warranty (outside U.S., EU & Switzerland)	12
24. Limited Warranty (Australia)	12

Please read the following safety warnings and precautions before using your device.

1. Introduction

Thank you for purchasing *Roadie™ Unplugged Mobile Amped Audio System* - a small portable music player, speaker and amplifier. You can turn any hard surface such as wooden desk or glass table into a speaker by simply placing this device on its surface. This device can be easily connected with any audio or video devices, smartphones, etc. via Bluetooth® or audio cable connections for your traveling or daily needs.


2. Battery Precautions

The device can be powered by a built-in rechargeable lithium battery. Please charge the battery for at least 8 hours before your first use of the device.

- If the device is not used for a long period of time, the battery may lose its charge. Please recharge the battery.
- Rechargeable batteries are only to be charged under adult supervision.
- Use only the supplied USB cable or a standard 5V USB AC adapter (not supplied) to recharge the battery. Improperly charging a battery may damage it or the device.
- Do not use an unauthorized battery.
- **Never** open the device by yourself. For replacement of battery please contact our technical support (www.franklin.com). Opening the device by yourself will invalidate the warranty.
- Do not attempt to open the rechargeable battery or battery pack. There are no user serviceable parts inside.
- Should a battery leak, the device may become damaged. Clean the battery compartment immediately, avoiding contact with your skin.
- Keep batteries out of reach of small children. If swallowed, consult a physician immediately.
- Leaving the battery in hot or cold places, such as in a closed car in summer or winter conditions, will reduce the capacity and lifetime of the battery. Always try to keep the battery between 15°C and 25°C (59°F and 77°F). A device with a hot or cold battery may not work temporarily, even when the battery is fully charged.
- Do not dispose of batteries in a fire as they may explode. Batteries may also explode if damaged. Dispose of batteries according to local regulations. Do not dispose as household waste.

3. Getting Started

General Controls



Cables



Power Cable




Audio Cable

4. Installation

Rubber Stand

Remove the protective tape at the bottom of the device to reveal the rubber stand. When the rubber stand is dirty, wash it with water. Replace the protective tape to protect the rubber stand from dust when not in use.




Magnets

The device contains two modules that are connected together with magnets. Keep magnetic field sensitive products such as credit cards and video screens away from this device to avoid damage or malfunction. To avoid injuries, do not put fingers between modules when joining them together.



Flat and Hard Surface



5. Bluetooth® Connections

Connect the speaker with a smartphone

- 1. Turn on the Bluetooth function of your smartphone.**
- 2. On the device, press and hold  to turn on the device and the Bluetooth feature.**
 - A long beep sound can be heard when the speaker is turned on, then followed by two low-pitched sounds when the Bluetooth feature is turned on.
 - The  button keeps blinking when no Bluetooth connection is made.
- 3. On your mobile phone look for the device "Franklin Roadie" and connect it with your phone.**
 - No password is required.
 - You hear two low-pitched sounds when the connection is successful.
 - The  button stays lit when the Bluetooth connection is established.


Connect the speaker with a computer

- 1. Add a Bluetooth adapter to your computer.**
 - This is usually done by plugging the adapter into a USB port. (If a Bluetooth adapter is already built in or attached to your computer, ignore this step.)
- 2. On the device, press and hold  to turn on the speaker and the Bluetooth feature.**
 - A long beep sound can be heard when the speaker is turned on, then followed by two low-pitched sounds when the Bluetooth feature is turned on.
 - The  button keeps blinking when no Bluetooth connection is made.

3. Open the Control Panel of your computer, then locate and click "Bluetooth Devices".
4. Click "Add" and then follow the instructions on the computer to connect the device with the computer.
 - Look for the device "Franklin Roadie".
 - In case a password is required, enter "0000".
 - You hear a low-pitched sound when the connection is successful.
 - The  button stays lit when the Bluetooth connection is established.

6. Battery Charging

The device has a built-in rechargeable lithium-ion battery which can be charged by connecting with the USB port* of your computer.



Refer to the battery indicator (above the  button) for the charging status.

→ Indicator	→ Charging status
Blinking	Charging in progress
Stays lit	Charging completed

After charging, the device can be used without the power connection. Charge the device again when you see the battery indicator blinking quickly.

*The device can also be powered by a 5V AC adapter (not provided).

Note: Due to the used enclosure material, the device shall only be connected to a USB Interface of version 2.0 or higher. The connection to the so-called power USB is prohibited.

7. General Operations

- Press and hold  to switch on or off the device. You hear a long beep sound when the device turns on or off.
- Press and hold  or  to adjust the volume.
- Press **HD** to obtain high definition sound. Press **NORMAL** to restore to normal sound.
- When listening to music, press  to start, pause or resume playback. Press  or  to skip to the previous or next song.

8. Using as a Microphone for Phone Calls


You can use the device as a microphone to make phone calls. During a phone call, press  to mute the microphone. Press again to deactivate the mute function.

Making Calls via Internet Phone

For Skype or other IP calls via the speaker, all controls (including making calls and hang up) have to be done on your computer.

9. Using the Audio Cable

You may also use the supplied audio cable for audio input from computer, smartphone or audio device. All playback controls must be made on the respective device.



10. Troubleshooting Tips

1. I cannot connect the device with my smartphone or computer via Bluetooth.

- Make sure you have turned on the Bluetooth feature on your smartphone or computer.
- Make sure you have turned on the Bluetooth feature (or pairing mode) on the device (you hear two low-pitched sounds and the  button keeps blinking before pairing).
- Make sure the battery level of the device is not too low (charging indicator is blinking quickly).

2. I cannot turn on the device again after switch off.

- The device requires some time for complete switch off. Please wait for 5-10 seconds before you turn on the device again.

3. I cannot skip to the previous or next song by pressing –◀◀ or +▶▶.

- Make sure you are playing a series of songs on a playlist instead of only playing a single music file.
- All playback controls must be made on your computer or smartphone when you are using an audio cable for playback.

4. There is no sound or distorted sound when using the Bluetooth connection.

- Make sure that this device is not too far (within 10 meters or 33 feet) from the audio source, or the device is not having interference from wireless LAN, other 2.4 GHz wireless device, or microwave oven.

11. Product Care

Your device is designed to be light, compact and durable. However, it is an electronic device and must be treated carefully. Putting unnecessary pressure on it or striking the device against other objects can cause damage. To avoid damage to your device, please:

- Do not drop, crush, bend, or apply excessive force to the device.
- Do not expose your device to moisture, extreme or prolonged heat, cold, humidity, or other adverse conditions. Avoid storing it in damp, humid or wet places. It is not waterproof.
- Do not operate or store unit in places with frequent static electricity or electrical noise (e.g. speaker, TV set).
- Clean the unit with a soft cloth or a damp chamois leather. Never use solvents.
- The unit must only be opened by qualified personnel.

- Please keep plastic bags away from babies and children to avoid danger of suffocation.
- This device contains magnets. Keep magnetic field sensitive products such as credit cards and video screens away from this device to avoid damage or malfunction.

12. Product Registration

Visit www.franklin.com for product registration.

13. Specifications

Model EVS-6000 BT *Roadie™ Unplugged Mobile Amped Audio System*

Size: 3.6 x 2.5 x 2.5 in (92 x 64 x 64 mm)

Weight: 15.5 ounce (440 g)

Output power: 10W

Frequency range: 40Hz - 20KHz

Power supply: Built-in lithium-ion battery/USB cable

Impedance: Satellite 4 ohms + subwoofer 2 ohms

Bluetooth: Noise Blackout Extreme, operating range up to 10 meters

Franklin Electronic Publishers, Inc. Burlington, N.J. 08016-4907 U.S.A. All rights reserved.

Imported to the European Community by: Franklin Electronic Publishers GmbH, Kapellenstr. 13, 85622 Feldkirchen, Germany.



0700



FCC ID: CK2-EVS1000ABT

IC: 10137A-EVS1000ABT

Bluetooth

The word mark and logos are owned by Bluetooth SIG, Inc. and any use of such marks by Franklin Electronic Publishers Inc. is under license. Other trademarks and trade names are those of their respective owners.

Compatibility

This device is compliant with Bluetooth Specification 2.1 + EDR supporting A2DP, AVRCP, HSP1.0. Please check with the manufacturers of other devices to check for their compatibility with this device.

14. Hearing Protection

Protect your hearing from long exposure of loud sounds at high volume. Set the volume to an appropriate level in different environments. Do not hold or place the device near the ears.

15. Operating and Storage Temperatures

Do not use or store the device in environments that exceed the recommended temperatures listed below. Otherwise, the device may become hot and could result in serious injury, death, or damage to property. Keep also the device accessories away from heat sources.

• Device operating	32 to 95°F (0 to 35°C)
• Device storage	23 to 122°F (-5 to 50°C)

16. Recycling and Disposal

Device Disposal

 This device should be disposed through your local electronic product recycling system - do not throw in trash bin.

Packaging Disposal

Please save this User's Guide and all packing materials, as they contain important information. In case of disposal, please refer to your local recycling system.

Battery Disposal

 Do not dispose of batteries with normal household waste. Please obey your local regulations when disposing of used batteries. Please visit www.franklin.com/eu to contact Franklin or its distributors to get information for battery disposal and/or replacement. However, shipping and handling expenses might apply.

This unit may change operating modes, lose information stored in memory, or fail to respond due to electrostatic discharge or electrical fast transients. Normal operation of this unit may be re-established by pressing .

17. FCC Notice (U.S. only)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. Under the influence of electrostatic phenomenon, the product may malfunction and require user to reset. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1) Reorient or relocate the receiving antenna. 2) Increase the separation between the equipment and receiver. 3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. 4) Consult the dealer or an experienced radio/TV technician for help.

Note: This unit was tested with shielded cables on the peripheral devices. Shielded cables must be used with this unit to ensure compliance with the Class B FCC limits.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement :

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

18. IC notice

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

19. EU notice

This product is CE marked according to the provisions of the R & TTE Directive(1999/5/EC). Hereby, Franklin Electronic Publishers Inc., declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. A copy of the Declaration of Conformity is attached on the last page of the manual.

 0700

20. Disclaimer of Warranties

Except as specifically provided herein, Franklin makes no warranty of any kind, express or implied, with respect to this product.

21. Limited Warranty (U.S.)

LIMITED WARRANTY, DISCLAIMER OF WARRANTIES, AND LIMITED REMEDY

FRANKLIN WARRANTS TO THE ORIGINAL PURCHASER THAT THIS PRODUCT WILL BE FREE FROM DEFECTS IN MATERIALS AND WORKMANSHIP FOR A PERIOD OF ONE (1) YEAR FROM THE ORIGINAL DATE OF PURCHASE AS EVIDENCED BY A COPY OF THE SALES RECEIPT. THIS LIMITED WARRANTY DOES NOT COVER DAMAGE DUE TO ACTS OF GOD, ACCIDENT, MISUSE, ABUSE, NEGLIGENCE, MODIFICATION, UNSUITABLE ENVIRONMENT, OR IMPROPER MAINTENANCE. THE SOLE OBLIGATION AND LIABILITY OF FRANKLIN, AND THE EXCLUSIVE REMEDY UNDER THIS LIMITED WARRANTY, IS REPAIR OR REPLACEMENT AT THE SOLE OPTION OF FRANKLIN AND THIS REMEDY APPLIES ONLY IN THE CASE IN WHICH FRANKLIN DETERMINES THAT THE PRODUCT WAS DEFECTIVE AND THAT THE DEFECT AROSE WITHIN THE DURATION OF THE LIMITED WARRANTY. THIS REMEDY IS THE EXCLUSIVE REMEDY FOR BREACH OF THIS WARRANTY. THIS WARRANTY GIVES YOU CERTAIN RIGHTS; YOU MAY ALSO HAVE OTHER RIGHTS THAT MAY VARY FROM JURISDICTION TO JURISDICTION.

EXCEPT FOR THE LIMITED WARRANTY EXPRESSLY RECITED ABOVE, THIS FRANKLIN PRODUCT IS PROVIDED ON AN "AS IS" BASIS, WITHOUT ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY, MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE, OR THOSE ARISING BY LAW, STATUTE, USAGE OF TRADE, OR COURSE OF DEALING. THIS WARRANTY APPLIES ONLY TO PRODUCTS MANUFACTURED BY OR FOR FRANKLIN AND SPECIFICALLY DOES NOT INCLUDE BATTERIES, CORROSION OF BATTERY CONTACTS OR ANY OTHER DAMAGE CAUSED BY BATTERIES. FRANKLIN SHALL NOT HAVE ANY LIABILITY TO THE PURCHASER OR ANY OTHER PERSON OR ENTITY FOR ANY INDIRECT, INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES WHATSOEVER, INCLUDING, BUT NOT LIMITED TO, LOSS OF REVENUE OR PROFIT, LOST OR CORRUPTED DATA, OR OTHER COMMERCIAL OR ECONOMIC LOSS, EVEN IF FRANKLIN HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR EVEN IF OTHERWISE FORESEEABLE. FRANKLIN IS NOT RESPONSIBLE FOR CLAIMS BY A THIRD PARTY. FRANKLIN'S MAXIMUM AGGREGATE LIABILITY SHALL NOT EXCEED THE AMOUNT PAID FOR THE PRODUCT AS EVIDENCED BY THE SALES RECEIPT. SOME STATES/JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. IF THE LAWS OF THE RELEVANT JURISDICTION DO NOT PERMIT FULL WAIVER OF IMPLIED WARRANTIES, THEN THE DURATION OF IMPLIED WARRANTIES AND CONDITIONS ARE LIMITED TO THE DURATION OF THE EXPRESS WARRANTY GRANTED HEREIN.

Warranty Service: If you think your product is defective, call Franklin's Customer Service Desk, 1-800-266-5626, to request a return merchandise authorization ("RMA") number, before returning the product (transportation charges prepaid) to:

Franklin Electronic Publishers, Inc.

Attn: Service Department, One Franklin Plaza

Burlington, NJ 08016-4907

If you return a Franklin product, please include your name, address, telephone number, a brief description of the defect and a copy of your sales receipt as proof of your original date of purchase. You must also write the RMA prominently on the package if you return the product; otherwise there may be a lengthy delay in the processing of your return. Franklin strongly recommends using a trackable form of delivery to Franklin for your return.

22. Limited Warranty (EU & Switzerland)

Notwithstanding the disclaimer of warranties above, this product, excluding batteries and liquid crystal display (LCD), is guaranteed by Franklin to be free of defects in materials or workmanship for a period of two years from the date of purchase. It will be repaired or replaced with an equivalent product (at Franklin's option) free of charge for any defect in workmanship or materials during that time. This warranty explicitly excludes defects due to misuse, accidental damage, or wear and tear. This warranty does not affect the consumer's statutory rights.

23. Limited Warranty (outside U.S., EU & Switzerland)

Notwithstanding the disclaimer of warranties above, this product, excluding batteries and liquid crystal display (LCD), is guaranteed by Franklin to be free of defects in materials or workmanship for a period of one year from the date of purchase. It will be repaired or replaced with an equivalent product (at Franklin's option) free of charge for any defect in workmanship or materials during that time.

Products purchased outside the United States, the European Union and Switzerland that are returned under warranty should be returned to the original vendor with proof of purchase and description of fault. Charges will be made for all repairs unless valid proof of purchase is provided.

This warranty explicitly excludes defects due to misuse, accidental damage, or wear and tear. This warranty does not affect the consumer's statutory rights.

24. Limited Warranty (Australia)

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if goods fail to be of acceptable quality and the failure does not amount to a major failure. This product, excluding batteries and liquid crystal display (LCD), is guaranteed by Franklin to be free of defects in materials or workmanship for a period of one year from the date of purchase. If you think your product is defective, please contact Franklin to arrange for repair or replacement:

FRANKLIN ELECTRONIC PUBLISHERS (AUST) PTY LTD.

Unit 4, 25 Gibbes Street, Chatswood, NSW 2067, Australia

Contact person: Service Manager

Tel: 1800 882 588

Email: service_au@franklin.com

Charges will be made for all repairs unless valid proof of purchase is provided. Your product will be repaired or replaced with an equivalent product (at Franklin's option) free of charge for any defect in workmanship or materials during that time. The repair of your goods may result in the loss of any user-generated data. Please ensure that you have made a copy of any data saved on your goods. Goods presented for repair may be replaced by refurbished goods of the same type rather than being repaired. Refurbished parts may be used to repair the goods. This warranty explicitly excludes defects due to misuse, accidental damage, or wear and tear. This warranty does not affect the consumer's statutory rights.



Franklin Electronic Publishers, Inc.
One Franklin Plaza, Burlington, NJ 08016-4907, USA
TEL: 1-800-266-5626 URL: <http://www.franklin.com>

DECLARATION OF CONFORMITY

We, Franklin Electronic Publishers, Inc., One Franklin Plaza, Burlington, NJ 08016-4907, U.S.A. declare under our sole responsibility that the product:

Model: EVS-6000BT

to which this declaration refers conforms with the following standards:

EMC:

EN 301489-1: V1.8.1

EN 301489-17: V2.1.1

EN 55013:2001+A1:2003+A2:2006

EN 55020:2007

SAFETY:

EN 60065:2002+A1:2006+A11:2008

SPECTRUM:

EN 300328: V1.7.1

RF EXPOSURE:

EN 50371:2002

According to the Directive in 1999/5/EC(R & TTE): Article 3.1a, 3.1b, 3.2

The conformity assessment procedure referred to in Article 10 and detailed in Annex IV of Directive 1999/5/EC has been followed with the involvement of the following Notified Body:

PHOENIX TESTLAB GmbH, Königswinkel 10, 32825, Blomberg, Germany

The product is marked with the CE mark and Notified Body number according to the Directive 1999/5/EC:

CE 0700

Place Of Issue: Hong Kong

Date Of Issue: February 27, 2012

Product Development Authorization:

Signature:

Name: Pang Lee

Position: Vice President

Product Development

Franklin®
www.franklin.com