




## Quick start guide

BL108/BL108-2/BL108-3/  
BL108-4/BL108-5

DECT 6.0 cordless telephone/  
answering system with  
caller ID/call waiting



Scan the QR code for  
support information



# Congratulations

on your purchase of this AT&T product. Before using this AT&T product, please read the **Important safety information** section on pages 1-3 of this manual.

Both the model and serial numbers of your AT&T product can be found on the bottom of the telephone base. Save your sales receipt and original packaging in case it is necessary to return your telephone for warranty service.

For customer service, please visit our website at <https://telephones.att.com> or call **1 (800) 222-3111**. In Canada, dial **1 (866) 288-4268**.



Please refer to the online **BL108/BL108-2/BL108-3/BL108-4/BL108-5** DECT 6.0 cordless telephone/answering system with caller ID/call waiting Complete user's manual for a full set of installation and operation instructions at <https://telephones.att.com/manuals>.

## Parts checklist

Your telephone package contains the following items.



Quick start guide



Smart call blocker leaflet



Telephone base



Power adapter for telephone base



Cordless handset  
(1 for BL108)  
(2 for BL108-2)  
(3 for BL108-3)  
(4 for BL108-4)  
(5 for BL108-5)



Charger for cordless handset with power adapter installed  
(1 for BL108-2)  
(2 for BL108-3)  
(3 for BL108-4)  
(4 for BL108-5)



Battery for cordless handset  
(1 for BL108)  
(2 for BL108-2)  
(3 for BL108-3)  
(4 for BL108-4)  
(5 for BL108-5)



Battery compartment cover  
(1 for BL108)  
(2 for BL108-2)  
(3 for BL108-3)  
(4 for BL108-4)  
(5 for BL108-5)



Telephone line cord

# Important safety information



This symbol is to alert you to important operating or servicing instructions that may appear in this user's manual. Always follow basic safety precautions when using this product to reduce the risk of injury, fire, or electric shock.

## Safety information

---

- ▶ Read and understand all instructions in the user's manual. Observe all markings on the product.
- ▶ Use only with UL listed Bluetooth devices.
- ▶ Avoid using a telephone during a thunderstorm. There may be a slight chance of electric shock from lightning.
- ▶ Do not use a telephone in the vicinity of a gas leak. Under certain circumstances, a spark may be created when the adapter is plugged into the power outlet, or when the handset is replaced in its cradle. This is a common event associated with the closing of any electrical circuit. In an inadequately ventilated environment, the user should not plug the phone into a power outlet, nor put a charged handset into the cradle where there are concentrations of flammable or flame-supporting gases. A spark in such an environment could create a fire or explosion. Such environments might include: medical use of oxygen without adequate ventilation; industrial gases (cleaning solvents; gasoline vapors; etc.); a leak of natural gas; etc.
- ▶ Do not use this product near water or when you are wet. For example, do not use it in a wet basement or shower, nor next to a swimming pool, bathtub, kitchen sink and laundry tub. Do not use liquids or aerosol sprays for cleaning. If the product comes in contact with any liquid, unplug any line or power cord immediately. Do not plug the product back in until it has dried thoroughly.
- ▶ Install this product in a protected location where no one can trip over any line or power cords. Protect cords from damage or abrasion.
- ▶ If this product does not operate normally, see the **Troubleshooting** section of the online Complete user's manual. If you cannot solve the problem, or if the product is damaged, refer to the **Limited warranty** section (pages 33 - 35). Do not open this product except as directed in your user's manual. Opening the product or reassembling it incorrectly may expose you to hazardous voltages or other risks.
- ▶ Replace batteries, only as described in your user's manual (Page 6). Do not burn or puncture batteries — they contain caustic chemicals.
- ▶ This power adapter is intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling or an under-the-table/cabinet outlet.
- ▶ For pluggable equipment, the socket-outlet shall be installed near the equipment and shall be easily accessible.



## CAUTIONS:

Use only the power adapter provided with this product. To obtain a replacement, visit our website at **<https://telephones.att.com>** or call

**1 (800) 222-3111**. In Canada, dial **1 (866) 288-4268**.

# Important safety information



**CAUTION:** To prevent risk of fire or battery explosion, replace with the correct battery type. Dispose of used batteries according to the instructions.

- ▶ Disconnect the telephone line from the equipment before open the battery door. Do not use the battery in following conditions:
  - ▶ High or low extreme temperature during use, storage or transportation.
  - ▶ Replacement of a battery with an incorrect type that can defeat a safeguard.
  - ▶ Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.
  - ▶ Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.
  - ▶ A battery subjected to extremely low air pressure that can result in an explosion or the leakage of flammable liquid or gas.
- ▶ Use only the supplied rechargeable battery or replacement battery (model BT267661). To order, visit our website at **<https://telephones.att.com>**, or call **1 (800) 222-3111**. In Canada, dial **1 (866) 288-4268**.
- ▶ The applied nameplate is located at the bottom or near of the product.

## **Especially about cordless telephones**

---

- ▶ Privacy: The same features that make a cordless telephone convenient create some limitations. Telephone calls are transmitted between the telephone base and the handset by radio waves, so there is a possibility that your cordless telephone conversations could be intercepted by radio receiving equipment within range of the cordless handset. For this reason, you should not think of cordless telephone conversations as being as private as those on corded telephones.
- ▶ Electrical power: The telephone base of this cordless telephone must be connected to a working electrical outlet which is not controlled by a wall switch. Calls cannot be made from the handset if the telephone base is unplugged, switched off or if the electrical power is interrupted.
- ▶ Potential TV interference: Some cordless telephones operate at frequencies that may cause interference to TVs and VCRs. To minimize or prevent such interference, do not place the telephone base of the cordless telephone near or on top of a TV or VCR. If interference is experienced, moving the cordless telephone farther away from the TV or VCR will often reduce or eliminate the interference.
- ▶ Rechargeable batteries: This product contains nickel-metal hydride rechargeable batteries. Exercise care in handling batteries in order not to create a short circuit with conductive material such as rings, bracelets, and keys. The battery or conductor may overheat and cause harm. Observe proper polarity between the battery and the battery charger.

# Important safety information

- ▶ Nickel-metal hydride rechargeable batteries: Dispose of these batteries in a safe manner. Do not burn or puncture. Like other batteries of this type, if burned or punctured, they could release caustic material which could cause injury.



The RBRC Seal means that the manufacturer is voluntarily participating in an industry program to collect and recycle nickel-metal hydride rechargeable batteries when taken out of service within the United States. These batteries may be taken to a participating local retailer of replacement batteries or recycling center. You may call 1-800-8-BATTERY® for locations accepting spent Ni-MH batteries.

The RBRC Seal and 1-800-8-BATTERY® are registered trademarks of Call2recycle, Inc.

## **Precautions for users of implanted cardiac pacemakers**

---

Cardiac pacemakers (applies only to digital cordless telephones):

Wireless Technology Research, LLC (WTR), an independent research entity, led a multidisciplinary evaluation of the interference between portable wireless telephones and implanted cardiac pacemakers. Supported by the U.S. Food and Drug Administration, WTR recommends to physicians that:

### **Pacemaker patients:**

- ▶ Should keep wireless telephones at least six inches from the pacemaker.
- ▶ Should NOT place wireless telephones directly over the pacemaker, such as in a breast pocket, when it is turned ON.
- ▶ Should use the wireless telephone at the ear opposite the pacemaker.

WTR's evaluation did not identify any risk to bystanders with pacemakers from other persons using wireless telephones.

## **ECO mode**

---

This power conserving technology reduces power consumption for optimal battery performance. The ECO mode activates automatically whenever the handset is synchronized with the telephone base.

## **Especially about telephone answering systems**

---

Two-way recording: This unit does not sound warning beeps to inform the other party that the call is being recorded. To ensure that you are in compliance with any federal or state regulations regarding recording a telephone call, you should start the recording process and then inform the other party that you are recording the conversation.


# **SAVE THESE INSTRUCTIONS**

# Table of contents

|                                                                        |    |
|------------------------------------------------------------------------|----|
| Important safety information .....                                     | 1  |
| Install.....                                                           | 5  |
| Handset overview .....                                                 | 7  |
| Telephone base overview.....                                           | 10 |
| Initial basic settings.....                                            | 11 |
| Voice guide to set Smart call blocker and answering system.....        | 11 |
| Date and time .....                                                    | 11 |
| Restart voice guide to set Smart call blocker and answering system.... | 12 |
| Record your own announcement.....                                      | 12 |
| Number of rings.....                                                   | 12 |
| Ringer volume.....                                                     | 13 |
| LCD language.....                                                      | 13 |
| Voice language.....                                                    | 13 |
| Dial mode.....                                                         | 14 |
| Temporary tone dialing.....                                            | 14 |
| Set speed dial voicemail number .....                                  | 14 |
| Operate.....                                                           | 15 |
| Phonebook .....                                                        | 16 |
| Bluetooth®.....                                                        | 16 |
| Pair a Bluetooth cell phone.....                                       | 17 |
| Bluetooth connection when idle.....                                    | 17 |
| Download cell phone phonebook .....                                    | 17 |
| Answer a cell call .....                                               | 18 |
| Make a cell call .....                                                 | 18 |
| Caller ID.....                                                         | 19 |
| Caller ID announce.....                                                | 19 |
| Review and dial a number in the call log.....                          | 19 |
| Erase missed calls indicator in the call log .....                     | 19 |
| Smart call blocker *§.....                                             | 20 |
| What is Smart call blocker? .....                                      | 20 |
| Default scenarios of Smart call blocker handling.....                  | 20 |
| Prerequisite setups.....                                               | 21 |
| Other popular scenarios.....                                           | 22 |
| Block the caller while on a call.....                                  | 23 |
| Unblock a telephone number .....                                       | 24 |
| Answering system.....                                                  | 24 |
| About answering system and voicemail.....                              | 24 |
| Turn answering system on or off.....                                   | 25 |
| Message alert tone.....                                                | 25 |
| Call screening.....                                                    | 25 |
| Message playback.....                                                  | 26 |
| For C-UL compliance.....                                               | 27 |
| FCC Part 68 and ACTA .....                                             | 31 |
| FCC Part 15 .....                                                      | 32 |
| Limited warranty.....                                                  | 33 |
| Technical specifications.....                                          | 36 |

# Install


## Telephone base



### Notes:

- ▶ Plug one end of the telephone line cord into a telephone jack or a DSL filter.
- ▶ If you have DSL high-speed Internet service, a DSL filter (not included) is required.

## Charger



Caution: Use only the power adapter(s) provided with this product. To obtain a replacement, visit our website at


**<https://telephones.att.com>**

or call **1 (800) 222-3111**. In Canada, dial **1 (866) 288-4268**.


# Install

## Battery

Install the battery, as shown below.




Charge your handset(s) by placing it in the telephone base and/or charger before initial use. The battery is fully charged after 11 hours of continuous charging.



Caution: Use only the supplied rechargeable battery or replacement battery (model BT267661).



# Handset overview



## Handset

- 1 **LCD display**
- 2 
  - › Press to make or answer a call using the speakerphone.
  - › Press to switch between the speakerphone and the handset.
- 3 **Left soft key**
  - › Press to select the menu item displayed above the key.
- 4 **CALL BLOCK**
  - › Press to block the incoming call when the telephone is ringing.
  - › Press to show the call block menu options when the handset is not in use.
  - › During a call, press to block the call.
- 5  **PHONE/FLASH**
  - › Press to make a call.
  - › Press to answer a call.
  - › Press to answer an incoming call when you are on a call and receive a call waiting alert.
  - › Press to answer a cell call when the paired and connected cell phone is ringing.



# Handset overview

- 
- |                                                                                                                                                                                                                                                                                                          |                                                                                                                                                                                                                                                                                         |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 40px; height: 40px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">6</div> <div style="display: flex; align-items: center;"> <b>1</b> </div> </div> | <ul style="list-style-type: none"> <li>› While reviewing a caller ID log entry, press repeatedly to add or remove 1 in front of the telephone number before dialing or saving it in the phonebook.</li> <li>› <u>Press and hold</u> to set or to dial your voicemail number.</li> </ul> |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
- 
- |                                                                                                                                                                                                                                                                                |                                                                                                                                                                                                                                  |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 40px; height: 40px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">7</div> <div> <b>TONE</b> <b>/a&gt;A</b> </div> </div> | <ul style="list-style-type: none"> <li>› Press to switch to tone dialing temporarily during a call if you have pulse service.</li> <li>› Press to change the next letter to upper or lower case while entering names.</li> </ul> |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
- 
- |                                                                                                                                                                                                                                                                                                               |                                                                                                              |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------|
| <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 40px; height: 40px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">8</div> <div style="display: flex; align-items: center;"> <b>OPER 0</b> </div> </div> | <ul style="list-style-type: none"> <li>› While entering names or numbers, press to add a spacing.</li> </ul> |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------|
- 
- |                                                                                                                                                                                                                                                                           |                                                                                                            |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|
| <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 40px; height: 40px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">9</div> <div> <b>Right soft key</b> </div> </div> | <ul style="list-style-type: none"> <li>› Press to select the menu item displayed above the key.</li> </ul> |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|
- 
- |                                                                                                                                                                                                                                                                                                  |                                                                                                                                                                                                                                                                                                                                                                                 |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 40px; height: 40px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">10</div> <div style="display: flex; align-items: center;"> </div> </div> | <ul style="list-style-type: none"> <li>› Press to show phonebook entries when the handset is not in use.</li> <li>› Press to scroll up while in menus.</li> <li>› Press to move the cursor to the right while entering names or numbers.</li> <li>› Press to increase the listening volume when on a call.</li> <li>› Press to increase the message playback volume.</li> </ul> |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
- 
- |                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                              |
|-------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <div style="display: flex; align-items: center;"> <div style="margin-right: 10px;"><b>CID</b></div> <div style="font-size: 2em;">▼</div> </div> | <ul style="list-style-type: none"> <li>› Press to show caller ID log when the handset is not in use.</li> <li>› Press to scroll down while in menus.</li> <li>› Press to move the cursor to the left while entering names or numbers.</li> <li>› Press to decrease the listening volume when on a call.</li> <li>› Press to decrease the message playback volume.</li> </ul> |
|-------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|




## Handset overview

- 
- |      |               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|------|---------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| (10) | <b>DELETE</b> | <ul style="list-style-type: none"><li>› Press to mute the microphone during a call.</li><li>› Press to mute the ringer temporarily when the handset is ringing.</li><li>› While reviewing the caller ID log, phonebook, redial memory, block list, or star name list, press to delete an individual entry.</li><li>› Press to delete digits while predialing.</li><li>› During message playback, press to delete the playing message.</li><li>› During announcement playback, press to delete the recorded announcement.</li></ul> |
|      | <b>REDIAL</b> | <ul style="list-style-type: none"><li>› Press repeatedly to view the last ten numbers dialed.</li><li>› <u>Press and hold</u> to insert a dialing pause while entering numbers.</li></ul>                                                                                                                                                                                                                                                                                                                                          |
- 
- |      |                                                                                                          |                                                                                                                                                                                                                                                                                                                                                                                                                |
|------|----------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| (11) |  <b>OFF/<br/>CANCEL</b> | <ul style="list-style-type: none"><li>› Press to hang up a call.</li><li>› Press to cancel an operation.</li><li>› Press to return to the previous menu.</li><li>› <u>Press and hold</u> to exit the menu display.</li><li>› Press to mute the ringer temporarily when the handset is ringing.</li><li>› <u>Press and hold</u> while the telephone is not in use to erase the missed call indicator.</li></ul> |
|------|----------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
- 
- |      |                               |                                                                                                                                                                                                                                                              |
|------|-------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| (12) | <b>QUIET#<br/>(pound key)</b> | <ul style="list-style-type: none"><li>› Press repeatedly to display other dialing options when reviewing a caller ID log entry.</li><li>› <u>Press and hold</u> to enter the <b>QUIET</b> mode setting screen, or to deactivate <b>QUIET</b> mode.</li></ul> |
|------|-------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
- 
- |      |                                    |                                                                                           |
|------|------------------------------------|-------------------------------------------------------------------------------------------|
| (13) | <b>Visual ringer<br/>indicator</b> | <ul style="list-style-type: none"><li>› Flashes when there is an incoming call.</li></ul> |
|------|------------------------------------|-------------------------------------------------------------------------------------------|
- 
- |      |                                           |                                                                                                                                                                                                                                         |
|------|-------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| (14) | <b>AUDIO<br/>ASSIST® /<br/>FLASHLIGHT</b> | <ul style="list-style-type: none"><li>› Voices will sound louder and clearer when you press <b>AUDIO ASSIST®</b> while on a call using the handset.</li><li>› Press to turn on the flashlight when the handset is not in use.</li></ul> |
|------|-------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
- 
- |      |                   |  |
|------|-------------------|--|
| (15) | <b>Flashlight</b> |  |
|------|-------------------|--|
- 
- |      |                                  |  |
|------|----------------------------------|--|
| (16) | <b>Battery compartment cover</b> |  |
|------|----------------------------------|--|
- 
- 9



## Telephone base overview



### Telephone base

①

#### Message window

##### **VOL +**

- ▶ Press to increase the volume during message playback.
- ▶ While the telephone is not in use, press to increase the base ringer volume.

##### **VOL -**

- ▶ Press to decrease the volume during message playback.
- ▶ While the telephone is not in use, press to decrease the base ringer volume.

##### **◀/REPEAT**

- ▶ Press to repeat the playing message.
- ▶ Press twice to play the previous message.

##### **▶/SKIP**

- ▶ Press to skip to the next message.

②

#### Antenna

③

##### **DELETE**

- ▶ Press to delete the message currently playing.
- ▶ Press twice to delete all old messages when the phone is not in use.

④

##### **PLAY/STOP**

- ▶ Press to play messages.
- ▶ Press to stop message playback.

⑤

##### **ANS ON**

- ▶ Press to turn the built-in answering system on or off.

⑥

##### **FIND HS**

- ▶ Press to page all handsets.



## Initial basic settings

After you install your telephone or power returns following a power outage, the handset will prompt you to set the date and time. To skip setting the date and time, press **OFF/CANCEL** or **BACK** on the handset.

## Voice guide to set Smart call blocker and answering system

After the date and time setting is done or skipped, the handset will prompt if you want to set Smart call blocker. Press **YES** to start the Smart call blocker setup via voice guide.

When you hear the telephone announces, *"Hello! This voice guide will assist you with the basic set up of Smart Call blocker."* Follow the voice guide to set up the Smart Call blocker.

- ▶ To screen calls with telephone numbers that are not saved in your phonebook or star name list:-
  - ▶ All the callers will be asked to leave their names before connecting to you, unless you have saved their numbers in phonebook or their names in star name list.

### -OR-

- ▶ Do not screen calls, and allow all incoming calls to get through.
  - ▶ All incoming calls will ring but calls with numbers you have saved in your block list will be rejected.

After the Smart call blocker setting is done or skipped, the handset will then prompt if you want to set up the answering system. Press **YES** and then follow the voice guide to set up the answering system. To skip the setup, press **NO** on the handset.

**We recommend you program your telephone system before use.** The voice guide only picks a few common features for you to have a quick setup. Refer to the **Telephone settings** and **Answering system settings** in the Complete user's manual for detailed instructions on setting all telephone features.

## Date and time



Note: Set the date/time before using the answering system.

1. **MENU** -> **CID** ▼ or ▲ -> **Set date/time** -> **SELECT**.
2. Enter the month (**MM**), day (**DD**) and year (**YY**) -> **NEXT**.
3. Enter the hour (**HH**) and minute (**MM**).
4. **CID** ▼ or ▲ -> **AM** or **PM** -> **SAVE**.



## Initial basic settings

### Restart voice guide to set Smart call blocker and answering system

Restart voice guide to set Smart call blocker:

1. **Call block** -> **CID ▼** or **📖 ▲** -> **SCB settings** -> **SELECT**.
2. **CID ▼** or **📖 ▲** -> **Voice guide** -> **SELECT**.
3. Set up your Smart call blocker feature by inputting designated numbers, as instructed in the voice guide.

Restart voice guide to set Answering system:

1. **MENU** -> **CID ▼** or **📖 ▲** -> **Answering sys** -> **SELECT**.
2. **CID ▼** or **📖 ▲** -> **Voice guide** -> **SELECT**.
3. Set up your answering system by inputting designated numbers, as instructed in the voice guide.

### Record your own announcement

Your outgoing announcement plays when calls are answered by the answering system. You can use the preset announcement to answer calls, or replace it with your own recorded announcement.

1. **MENU** -> **CID ▼** or **📖 ▲** -> **Answering sys** -> **SELECT**.
2. **SELECT** to select **Announcement**.
3. **SELECT** to select **Record annnc**.
4. Speak towards the handset to record your announcement and press **STOP** to end recording and save it.

### Number of rings

You can set the answering system to answer an incoming call after 2, 3, 4, 5, 6 rings, or select toll saver. If you choose toll saver, the answering system answers a call after two rings when you have new messages, or after four rings when there are no new messages. This enables you to check for new messages and avoid paying unnecessary long distance charges if you are calling from out of your local area.

1. **MENU** -> **CID ▼** or **📖 ▲** -> **Answering sys** -> **SELECT**.
2. **CID ▼** or **📖 ▲** -> **Ans sys setup** -> **SELECT**.
3. **CID ▼** or **📖 ▲** -> **# of rings** -> **SELECT**.
4. **CID ▼** or **📖 ▲** to choose among **2, 3, 4, 5, 6**, or **Toll saver** -> **SELECT**.



## Initial basic settings

### Ringer volume

You can set the ringer volume level to one of the six levels, or turn the ringer off. When the ringer is off,  appears on the screen.

#### Adjust a cordless handset volume:

1. **MENU** -> **CID** ▼ or  ▲ -> **Ringers** -> **SELECT**.
2. **SELECT** to select **Ringer volume**.
3. **CID** ▼ or  ▲ to choose the desired level -> **SET**.



Note: You can set the volume of each handset individually and differently.

#### Adjust the telephone base volume:

- ▶ Press **VOL +** or **VOL -** on the base when the phone system is not in use.

### LCD language

1. **MENU** -> **CID** ▼ or  ▲ -> **Settings** -> **SELECT**.
2. **SELECT** again to select **LCD language**.
3. **CID** ▼ or  ▲ to choose **English**, **Français** or **Español** -> **SELECT** -> **YES**.



Note: If you accidentally change the LCD language to French or Spanish, you can reset it back to English without going through the French or Spanish menus.

- ▶ Press **MENU** on the handset when it is not in use -> enter **364#**.

### Voice language



Note: This feature is available in Canada version only.

The voice prompt language is preset to English. You can select English or French to be used for the voice prompts in your answering system.

1. **MENU** -> **CID** ▼ or  ▲ -> **Settings** -> **SELECT**.
2. **CID** ▼ or  ▲ -> **Voice language** -> **SELECT**.
3. **CID** ▼ or  ▲ to choose **English** or **Français** -> **SELECT**.



## Initial basic settings

### Dial mode

The dial mode is preset to touch-tone dialing. If you have pulse (rotary) service, you need to change the dial mode to pulse dialing before using the telephone to make a call.

1. **MENU** -> **CID** ▼ or  ▲ -> **Settings** -> **SELECT**.
2. **CID** ▼ or  ▲ -> **Dial mode** -> **SELECT**.
3. **CID** ▼ or  ▲ to choose **Touch-tone** or **Pulse** -> **SELECT**.

### Temporary tone dialing

If you have pulse (rotary) service only, you can switch from pulse to touch-tone dialing temporarily during a call. This is useful if you need to send touch-tone signals to access your telephone banking or long distance services.

1. During a call, press **TONE** ✕.
2. Use the dialing keys to enter the number. The telephone sends touch-tone signals. The telephone automatically returns to pulse dialing mode after you end the call.

### Set speed dial voicemail number

If you subscribe to a voicemail service offered by your telephone service provider, you can save the voicemail number to  **1** on each handset for easy access. When you want to retrieve voicemail messages, press and hold 1.

1. **MENU** -> **CID** ▼ or  ▲ -> **Settings** -> **SELECT**.
2. **CID** ▼ or  ▲ -> **Voicemail #** -> **SELECT**.
3. Enter the voicemail number (up to 30 digits) -> **SAVE**.



Note: Contact your telephone service provider for more information and assistance about your voicemail service.



## Operate

| Operation                                           | Steps                                                                                                                                                                                                                                                                                                                                                                                       |
|-----------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Making a call                                       | Press <b>PHONE/FLASH</b> or  -> Enter the telephone number.                                                                                                                                                                                                                                                                                                                                 |
| On-hook dialing (predialing)                        | Enter the telephone number -> Press <b>PHONE/FLASH</b> or  to call.                                                                                                                                                                                                                                                                                                                         |
| Answering a call                                    | Press <b>PHONE/FLASH</b> ,  or any dialing key ( <b>0 - 9</b> or <b>TONE X</b> ).                                                                                                                                                                                                                                                                                                           |
| Ending a call                                       | Press <b>OFF/CANCEL</b> or return the handset to the telephone base or charger.                                                                                                                                                                                                                                                                                                             |
| Handset speakerphone                                | During a call, press  to switch between handsfree speakerphone and normal handset use.                                                                                                                                                                                                                                                                                                      |
| Redial                                              | Press <b>REDIAL</b> repeatedly to select the desired entry -> <b>PHONE/FLASH</b> or  to call.                                                                                                                                                                                                                                                                                               |
| Volume control                                      | <b>Using a cordless handset:</b> <ul style="list-style-type: none"><li>During a call, press <b>CID ▼</b> to decrease or press  <b>▲</b> to increase the listening volume -&gt; <b>SET</b>.</li></ul> <b>Using the telephone base:</b> <ul style="list-style-type: none"><li>During a call, press <b>VOL -</b> to decrease or press <b>VOL +</b> to increase the listening volume.</li></ul> |
| Call waiting (Requires subscription from telephone) | Press <b>PHONE/FLASH</b> on the handset to put current call on hold and to take the new call.                                                                                                                                                                                                                                                                                               |



## Phonebook

The phonebook can store up to 1,000 entries, including any downloaded phonebook entries from your Bluetooth® cell phone. Phonebook entries are shared by all system devices.

| Operation                                     | Steps                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|-----------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Adding an entry in the phonebook              | <ol style="list-style-type: none"><li>1. <b>MENU</b> -&gt; <b>CID</b> ▼ or  ▲ -&gt; <b>Phonebook</b> -&gt; <b>SELECT</b>.</li><li>2. <b>CID</b> ▼ or  ▲ -&gt; <b>Add contact</b> -&gt; <b>SELECT</b>.</li><li>3. Enter a telephone number up to 30 digits -&gt; <b>NEXT</b>.</li><li>4. <b>CID</b> ▼ or  ▲ to choose <b>Home, Cell, Work</b> or <b>Other</b> -&gt; <b>NEXT</b>.</li><li>5. Enter a name up to 15 characters -&gt; <b>SAVE</b>.<ul style="list-style-type: none"><li>▶ Press <b>0</b> to insert a space.</li></ul></li></ol> |
| Searching/<br>dialing an entry                | <ol style="list-style-type: none"><li>1. Press  ▲ on the handset when it is not in use.</li><li>2. <b>CID</b> ▼ or  ▲ to browse through the entries.</li><li>3. When the desired entry displays, press  <b>PHONE/FLASH</b> or  to call.</li></ol>                                                                                                                                                                                                                                                                                           |
| Adding a caller ID log entry in the phonebook | <ol style="list-style-type: none"><li>1. <b>CID</b> ▼ -&gt; <b>CID</b> ▼ or  ▲ to scroll to the desired entry -&gt; <b>SAVE</b>.</li><li>2. <b>SELECT</b> to select <b>Phonebook</b>.</li><li>3. Edit the telephone number if needed -&gt; <b>NEXT</b>.</li><li>4. <b>CID</b> ▼ or  ▲ to choose <b>Home, Cell, Work</b> or <b>Other</b> -&gt; <b>NEXT</b>.</li><li>5. Edit the name if needed -&gt; <b>SAVE</b>.</li></ol>                                                                                                                  |

## Bluetooth®

Your telephone system is enhanced with Bluetooth feature. You can answer calls to a paired and connected cell phone with the cordless handset.

You can also download up to 1,000 cell phone phonebook entries to your telephone system via Bluetooth wireless technology. Each downloaded entry is stored in the telephone's phonebook with up to 30 digits for phone number and 15 characters for name.

Bluetooth wireless technology operates within a short range (up to 30 feet). Keep the connected device within 15 feet of the telephone base for optimal performance.

*The Bluetooth® word mark and logos are owned by Bluetooth SIG, Inc. and any use of such marks by Advanced American Telephones and its parent, VTech Holdings Limited, is under license. VTech Holdings Limited is a member of Bluetooth SIG, Inc. Other trademarks and trade names are those of their respective owners.*



Notes:

- ▶ Your **BL108/BL108-2/BL108-3/BL108-4/BL108-5** is compatible with Bluetooth version 2.0 or above devices.
- ▶ Before you begin, make sure that you have cellular coverage and your Bluetooth enabled cell phone is not connected to any other Bluetooth device.
- ▶ Make sure you turn on the Bluetooth feature of your cell phone. Refer to your cell phone user's manual to learn how.

## Pair a Bluetooth cell phone

### Using a cordless handset:

1. **MENU** -> **CID** ▼ or ▲ -> **Bluetooth** -> **SELECT**.
2. **SELECT** to select **Add cellular**.
  - ▶ If there is already a cell phone paired to the telephone base, it will be removed before adding a new cell phone.
3. Press **NEXT** to continue.
4. Place your cell phone next to the telephone base, and then press **NEXT**.
5. After your cell phone finds your AT&T telephone system (**AT&T DECT 6.0**), press the appropriate key on your cell phone to continue the pairing process.
  - ▶ Once paired, your cell phone may request for the permission of allowing the telephone system (**AT&T DECT 6.0**) to access your cell's phonebook. Permit the request if you wish to download phonebook.

### Cancel the pairing

- ▶ You can cancel the pairing by pressing **OFF/CANCEL**.

## Bluetooth connection when idle

When you have a paired cell phone but it is not connected, **CONNECT** appears on the handset when idle. Press **CONNECT** to start connecting to the paired cell phone.

## Download cell phone phonebook

You can download up to 1,000 cell phone directories (phonebooks) to your **BL108/BL108-2/BL108-3/BL108-4/BL108-5** telephone system via Bluetooth wireless technology. Each entry may consist of a telephone number up to 30 digits, and a name up to 15 characters.



Before downloading a cell phone phonebook, make sure the cell phone is paired, active, and connected to your telephone system.

Place your cell phone next to the telephone base when you download a cell phone phonebook to your telephone system.

### Using a cordless handset:

1. **MENU** -> **CID** ▼ or ▲ -> **Bluetooth** -> **SELECT**.
2. **CID** ▼ or ▲ -> **Download PB** -> **SELECT** to start downloading.
  - ▶ To stop downloading, press **STOP**.



Note: The telephone system will remove any duplicate entries, and any entries that contain unrecognizable symbols; therefore, the number of entries downloaded from your cell phone phonebook may be less than the number of entries stored in your cell phone.

## Answer a cell call

- ▶ When you have a paired and connected cell phone, and there is a call to the cell phone, press **PHONE/FLASH** or on the cordless handset to answer.

## Make a cell call

### When you have a paired and connected cell phone:

1. Press **CELL**.
2. Enter a telephone number up to 30 digits **OR**  
Press **OPTION** -> **CID** ▼ or ▲ to select **Caller ID log**, **Phonebook**, or **Redial** -> **SELECT** to confirm -> **CID** ▼ or ▲ to choose a contact.
3. Press **DIAL**.

## Caller ID

This product supports caller ID services offered by most telephone service providers. The telephone stores caller ID information of the last 50 incoming calls in the telephone base. This information is common to all devices.

### Caller ID announce

When this feature is on and you have an incoming call, the handset and/or base speaks “*Call from...*” and the name of the caller based on the phonebook or caller ID information. If the caller’s name is private or unknown, the phone number up to the last 11 digits will be spoken. If the caller’s phone number is also private or unknown, no information will be spoken.

1. **MENU** -> **CID ▼** or  **▲** -> **Caller ID annnc-> SELECT.**
2. **CID ▼** or  **▲** to choose **On** or **Off** -> **SELECT.**

### Review and dial a number in the call log

1. Press **CID ▼** on the handset when the phone is not in use -> **CID ▼** or  **▲** to scroll through the list.
2. Press  **PHONE/FLASH** or  on the handset to dial.
  - ▶ You can press **#** repeatedly to add or remove **1** in the number before dialing.

### Erase missed calls indicator in the call log

When you have missed calls, the screen shows **XX missed calls.**

This is the total number of calls you have not yet reviewed in the call log.

To erase this missed call indicator, you can:

- ▶ Scroll and review the call log one by one, or
- ▶ Press and hold  **OFF/CANCEL** on the handset when it is not in use.



## Smart call blocker \*§

If you have subscribed to caller ID service, then you can use the Smart call blocker feature to screen incoming calls.

### What is Smart call blocker?

Smart call blocker filters robocalls and unwanted calls for you, while allowing welcome calls to get through.

You can set up your lists of welcome callers in the Phonebook and Star name list and unwelcome callers in the Block list. The Smart call blocker allows calls from your welcome callers to get through, and it blocks calls from your unwelcome callers.

For other unknown calls, you can block, screen, or forward these calls to the answering system.

By default, your telephone allows all incoming calls to get through, but it will reject calls with numbers you have saved in the Block list.

For details, you can check out the Smart call blocker leaflet and the complete user's manual.

### Default scenarios of Smart call blocker handling

| Settings<br>Scenarios                                               | SCB screening<br>options                                      | Steps                                                                                                                                                  |
|---------------------------------------------------------------------|---------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|
| I want to allow all calls except the people on the Block list only. | <b>No screening</b><br><br>Block calls on the block list only | 1. <b>CALL BLOCK.</b><br>2. <b>SELECT</b> to choose <b>SCB screening.</b><br>3. <b>CID ▼</b> or <b>📖 ▲</b> to choose <b>No screening -&gt; SELECT.</b> |

\* Use of Smart call blocker feature requires subscription of caller ID service.

§ Includes licenced Qaltel™ technology.

Qaltel™ is a trademark of Truecall Group Limited.



# Smart call blocker

## Prerequisite setups

Perform the following setups if you want to block or screen unknown calls, or forward them to the answering system.

|                                                                                                                                                                                                                                                               |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p><b>Adding contact to Phonebook</b></p> <p>Enter and save telephone numbers of <b>family members, friends</b> and <b>frequently called businesses</b>, so that when they call, your telephone rings without having to go through the screening process.</p> | <p><b>Via direct entry:</b></p> <ol style="list-style-type: none"> <li><b>MENU</b> -&gt; <b>CID</b> ▼ or  ▲ -&gt; <b>Phonebook</b> -&gt; <b>SELECT</b>.</li> <li><b>CID</b> ▼ or  ▲ -&gt; <b>Add contact</b> -&gt; <b>SELECT</b>.</li> <li>Enter a telephone number up to 30 digits -&gt; <b>NEXT</b>.</li> <li><b>CID</b> ▼ or  ▲ to choose <b>Home, Cell, Work</b> or <b>Other</b> -&gt; <b>NEXT</b>.</li> <li>Enter a name up to 15 characters -&gt; <b>SAVE</b>.</li> </ol> <hr/> <p><b>Via Caller ID log entry:</b></p> <ol style="list-style-type: none"> <li><b>CID</b> ▼ -&gt; <b>CID</b> ▼ or  ▲ to browse through the entries.</li> <li><b>SAVE</b> when the desired entry appears.</li> <li><b>SELECT</b> again to choose <b>Phonebook</b> -&gt; <b>NEXT</b>.</li> <li><b>CID</b> ▼ or  ▲ to choose <b>Home, Cell, Work</b> or <b>Other</b> -&gt; <b>NEXT</b>.</li> <li>Enter a name up to 15 characters -&gt; <b>SAVE</b>.</li> </ol> |
| <p><b>Adding number to the Block list</b></p> <p>Add numbers that you want to prevent their calls from ringing through.</p>                                                                                                                                   | <p><b>Via direct entry:</b></p> <ol style="list-style-type: none"> <li><b>CALL BLOCK</b> -&gt; <b>CID</b> ▼ or  ▲ -&gt; <b>Block list</b> -&gt; <b>SELECT</b>.</li> <li><b>CID</b> ▼ or  ▲ -&gt; <b>Add new entry</b> -&gt; <b>SELECT</b>.</li> <li>Enter a telephone number up to 30 digits -&gt; <b>NEXT</b>.</li> <li>Enter a name up to 15 characters -&gt; <b>SAVE</b>.</li> </ol> <hr/> <p><b>Via Caller ID log entry:</b></p> <ol style="list-style-type: none"> <li><b>CID</b> ▼ -&gt; <b>CID</b> ▼ or  ▲ to browse through the entries.</li> <li><b>SAVE</b> when the desired entry appears.</li> <li><b>CID</b> ▼ or  ▲ -&gt; <b>Block list</b> -&gt; <b>SELECT</b>.</li> <li>Press <b>NEXT</b> -&gt; <b>SAVE</b>.</li> </ol>                                                                                                                                                                                                           |
| <p><b>Adding name to the Star name list</b></p> <p>Add caller names to your star name list to allow their calls to get through without having to go through the screening process.</p>                                                                        | <p><b>Via direct entry:</b></p> <ol style="list-style-type: none"> <li><b>CALL BLOCK</b> -&gt; <b>CID</b> ▼ or  ▲ -&gt; <b>SCB settings</b> -&gt; <b>SELECT</b>.</li> <li><b>SELECT</b> to select <b>Star name list</b>.</li> <li><b>CID</b> ▼ or  ▲ -&gt; <b>Add new entry</b> -&gt; <b>SELECT</b>.</li> <li>Enter a name up to 15 characters -&gt; <b>SAVE</b>.</li> </ol> <hr/> <p><b>Via Caller ID log entry:</b></p> <ol style="list-style-type: none"> <li><b>CID</b> ▼ -&gt; <b>CID</b> ▼ or  ▲ to browse through the entries.</li> <li><b>SAVE</b> when the desired entry appears.</li> <li><b>CID</b> ▼ or  ▲ -&gt; <b>Star name list</b> -&gt; <b>SELECT</b> -&gt; <b>SAVE</b>.</li> </ol>                                                                                                                                                                                                                                              |



# Smart call blocker



Note:

- There are many organizations like **schools, medical offices, and pharmacies that use robocalls** to communicate important information to you. Robocall uses an autodialer to deliver pre-recorded messages. By entering the **EXACT** Caller ID (CID)'s name of the organizations into the **Star name list**, it ensures these calls will ring through when you only know the caller names but not their numbers.

## Other popular scenarios

Based on your scenario, you can select your smart call blocker handling.

| Settings<br>Scenarios                                                                                   | Set screening options                                                                                                                                                                                                                                                                    | SCB settings                                                                                                                                                                                                                                                                                                                                                                                                                 |
|---------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| I want to screen robocalls only.                                                                        | <b>Screen unknown</b><br>- Screen and block robocalls <ol style="list-style-type: none"> <li><b>CALL BLOCK.</b></li> <li><b>SELECT</b> to choose <b>SCB screening.</b></li> <li><b>CID ▼</b> or <b>📖 ▲</b> -&gt; <b>Screen unknown -&gt; SELECT</b></li> </ol>                           | Set screening announcement: -<br><b>Robocalls only</b> <ol style="list-style-type: none"> <li><b>CALL BLOCK.</b></li> <li><b>CID ▼</b> or <b>📖 ▲</b> -&gt; <b>SCB settings -&gt; SELECT.</b></li> <li><b>CID ▼</b> or <b>📖 ▲</b> -&gt; <b>Screening annnc -&gt; SELECT.</b></li> <li><b>SELECT</b> to choose <b>SCB annnc type.</b></li> <li><b>CID ▼</b> or <b>📖 ▲</b> -&gt; <b>Robocalls only -&gt; SELECT.</b></li> </ol> |
| I want to send calls with numbers not saved in the Phonebook or Star name list to the answering system. | <b>UnknownToAns.S</b><br>- Forward all unknown calls to the answering system <ol style="list-style-type: none"> <li><b>CALL BLOCK.</b></li> <li><b>SELECT</b> to choose <b>SCB screening.</b></li> <li><b>CID ▼</b> or <b>📖 ▲</b> -&gt; <b>Unknwn to Ans. S -&gt; SELECT.</b></li> </ol> | --                                                                                                                                                                                                                                                                                                                                                                                                                           |



| Settings<br>Scenarios                                                                                            | Set screening options                                                                                                                                                                                                 | SCB settings                                                                                                                                                                                                                                                                                                                                              |
|------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| I only want to receive calls with their numbers in the Phonebook or Star name list. Other calls will be blocked. | <b>Block unknown</b><br>- Block all unknown calls<br>1. <b>CALL BLOCK.</b><br>2. <b>SELECT</b> to choose <b>SCB screening.</b><br>3. <b>CID ▼</b> or <b>📖 ▲</b> -> <b>Block unknown -&gt; SELECT.</b>                 | --                                                                                                                                                                                                                                                                                                                                                        |
| I want to screen all calls except those saved in the Phonebook or Star name list.                                | <b>Screen unknown</b><br>- Screen all calls except welcome calls<br>1. <b>CALL BLOCK.</b><br>2. <b>SELECT</b> to choose <b>SCB screening.</b><br>3. <b>CID ▼</b> or <b>📖 ▲</b> -> <b>Screen unknown -&gt; SELECT.</b> | Set screening announcement: -<br><b>Unknown caller</b><br>1. <b>CALL BLOCK.</b><br>2. <b>CID ▼</b> or <b>📖 ▲</b> -> <b>SCB settings -&gt; SELECT.</b><br>3. <b>CID ▼</b> or <b>📖 ▲</b> -> <b>Screening annc -&gt; SELECT.</b><br>4. <b>SELECT</b> to choose <b>SCB annc type.</b><br>5. <b>CID ▼</b> or <b>📖 ▲</b> -> <b>Unknown caller -&gt; SELECT.</b> |

## Block the caller while on a call

When you are on a call and speaking to the caller, and you do not want to receive calls from this caller again, you can end the call with block announcement and add the number to the block list.

1. During a call, press **CALL BLOCK.**
2. Press **SELECT** to end the call.



# Smart call blocker

## Unblock a telephone number

If you have added a telephone number to the block list, you can unblock it.

1. Press **CALL BLOCK**.
2. **CID** ▼ or ▲ -> **Block list** -> **SELECT**.
3. Press **SELECT** to select **Review**.
4. **CID** ▼ or ▲ to browse through the block entries.
5. When the desired entry displays, press **DELETE** or **UNBLOCK**, then press **YES** to confirm.

## Answering system

### About answering system and voicemail

Your telephone has separate indicators for two different types of voice messages: those left on the built-in answering system and those left at your telephone service provider's voicemail. To listen to messages recorded on the built-in answering system, refer to the **Message playback** section; to listen to voicemail, contact your telephone service provider for more information.

|                       | Built-in answering system<br>                                                                                                                                                                                                              | Voicemail service<br>                                                                                                                                                                                                           |
|-----------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Supported by          | Telephone system                                                                                                                                                                                                                           | Telephone service provider                                                                                                                                                                                                      |
| Subscription          | No                                                                                                                                                                                                                                         | Yes                                                                                                                                                                                                                             |
| Fees                  | No                                                                                                                                                                                                                                         | May apply                                                                                                                                                                                                                       |
| Answer incoming calls | <ul style="list-style-type: none"> <li>▶ After 4 rings by default.</li> <li>▶ It can be changed in the handset menu.</li> </ul>                                                                                                            | <ul style="list-style-type: none"> <li>▶ Usually after 2 rings.</li> <li>▶ It can be changed by contacting your telephone service provider.</li> </ul>                                                                          |
| Storage               | Telephone base                                                                                                                                                                                                                             | Server or System                                                                                                                                                                                                                |
| Display new messages  | <ul style="list-style-type: none"> <li>▶ Handset - <b>XX new messages</b></li> <li>▶ Telephone base - number of new messages on message counter</li> </ul>                                                                                 | <ul style="list-style-type: none"> <li>▶ Handset -  and <b>New voicemail</b></li> </ul>                                                                                                                                         |
| Retrieve messages     | <ul style="list-style-type: none"> <li>▶ Press <b>PLAY/STOP</b> on the telephone base; OR</li> <li>▶ Press <b>MENU</b>, and then select <b>Play messages</b> on the handset; OR</li> <li>▶ Access remotely with an access code.</li> </ul> | <ul style="list-style-type: none"> <li>▶ Press and hold  on the dialpad, and enter an access number from your telephone service provider; OR</li> <li>▶ Press and hold  to dial if you have saved the access number.</li> </ul> |

## ⓪⓪ Answering system

### Turn answering system on or off

The answering system must be turned on to answer and record messages.

#### Using the telephone base:

- ▶ Press **ANS ON** to turn the answering system on or off.  
If the answering system is turned on, it announces, *"Calls will be answered."* If the answering system is turned off, it announces, *"Calls will not be answered."*

#### Using a cordless handset:

1. **MENU** -> **CID** ▼ or  ▲ -> **Answering sys** -> **SELECT**.
2. **CID** ▼ or  ▲ -> **Answer On/Off** -> **SELECT**.
3. **CID** ▼ or  ▲ to choose **On** or **Off** -> **SELECT**.

When the answering system is on, the handset shows .

### Message alert tone

When this feature is on, the telephone base beeps every 10 seconds when there are new messages.

#### Using a cordless handset:

1. **MENU** -> **CID** ▼ or  ▲ -> **Answering sys** -> **SELECT**.
2. **CID** ▼ or  ▲ -> **Ans sys setup** -> **SELECT**.
3. **CID** ▼ or  ▲ -> **Msg alert tone** -> **SELECT**.
4. **CID** ▼ or  ▲ to choose **On** or **Off** -> **SELECT**.

### Call screening

Turn this feature on if you want to listen to the incoming messages at the base when they are being recorded. While monitoring an incoming message, you can answer the call by pressing  **PHONE/FLASH** on the handset.

#### Using a cordless handset:

1. **MENU** -> **CID** ▼ or  ▲ -> **Answering sys** -> **SELECT**.
2. **CID** ▼ or  ▲ -> **Ans sys setup** -> **SELECT**.
3. **SELECT** to select **Call screening**.
4. **CID** ▼ or  ▲ to choose **On** or **Off** -> **SELECT**.

## Ⓞ Ⓞ Answering system

### Message playback

#### Using the telephone base:

- › Press **PLAY/STOP** when the telephone base is not in use.

#### Using a cordless handset:

- › Press **MENU** then **SELECT** when the handset is not in use.

### Options during playback

| Feature                   | On the telephone base              | On a handset                                                                                              |
|---------------------------|------------------------------------|-----------------------------------------------------------------------------------------------------------|
| Adjust playback to volume | Press <b>VOL -</b> or <b>VOL +</b> | Press <b>CID</b> ▼ or  ▲ |
| Stop playback             | Press <b>PLAY/STOP</b>             | Press  <b>OFF/CANCEL</b> |
| Skip to the next message  | Press <b>▶▶/SKIP</b>               | Press <b>SKIP</b>                                                                                         |
| Repeat the message        | Press <b>◀◀/REPEAT</b>             | Press <b>REPEAT</b>                                                                                       |
| Play the previous message | Press <b>◀◀/REPEAT</b> twice       | Press <b>REPEAT</b> twice                                                                                 |
| Delete the message        | Press <b>DELETE</b>                | Press <b>DELETE</b>                                                                                       |

# For C-UL compliance

In compliance with the bilingual requirements for safety, caution, and warning markings of Canadian Federal and Provincial/Territorial statutes and regulations, the French version of Important safety information is included.

## Mesures de sécurité importantes

---



Ce symbole vous alertera d'informations importantes ou d'instructions d'entretien pouvant apparaître dans ce guide d'utilisation. Respectez toujours les mesures de sécurité et de sécurité de base lorsque vous utilisez ce produit, afin de réduire les risques de blessures, d'incendie, ou d'électrocution.

## Information relative à la sécurité

---

- ▶ Veuillez lire et comprendre toutes les instructions de ce guide d'utilisation. Relectez toutes les inscriptions apparaissant sur le produit.
- ▶ N'utiliser qu'avec des dispositifs Bluetooth homologués par UL
- ▶ Évitez d'utiliser le téléphone pendant un orage. Il pourrait y avoir un faible risque d'électrocution.
- ▶ N'utilisez pas un téléphone près d'une fuite de gaz. Dans certaines circonstances, une flammèche pourrait se produire lorsque l'adaptateur est branché à une prise de courant, ou lorsque le combiné est déposé sur son chargeur. Ceci est un événement fréquent associé avec la fermeture d'un circuit électrique. L'utilisateur ne devrait pas brancher un téléphone dans une prise de courant, et ne devrait pas déposer un combiné chargé dans le chargeur, si le téléphone se trouve dans un environnement comportant une concentration de gaz inflammables ou ignifuges, à moins de se trouver dans un endroit où la ventilation est adéquate. Une flammèche dans de tels environnements pourrait provoquer une explosion. De tels environnements peuvent comprendre : les endroits où de l'oxygène à des fins médicales est utilisé sans ventilation adéquate; des endroits où se trouvent des gaz industriels (dissolvants de nettoyage, des vapeurs de gazoline, etc.), une fuite de gaz naturel, etc.
- ▶ N'utilisez pas ce produit près de l'eau ou lorsque vous êtes mouillés. Par exemple, ne l'utilisez pas dans des sous-sols humides ou sous la douche, ou près d'une piscine, d'un bain, d'un évier de cuisine, ou d'une cuve de lavage. N'utilisez pas de liquides, ou de vaporisateurs aérosol de nettoyage. Si le produit entre en contact avec du liquide, débranchez immédiatement le fil téléphonique ou le cordon d'alimentation. Ne rebranchez pas le produit avant qu'il soit complètement sec.
- ▶ Installez cet appareil dans un endroit protégé où personne ne peut trébucher sur les cordons d'alimentation ou la ligne téléphonique. Protégez les câbles contre les dommages ou l'abrasion.
- ▶ Si le produit ne fonctionne pas correctement, consultez la section **Dépannage (Troubleshooting)** du guide d'utilisation. Si vous ne pouvez pas régler le problème, ou si le produit est endommagé, consultez la section **Garantie limitée (Limited warranty)** des pages 33-35. N'ouvrez pas ce produit, sauf tel qu'indiqué dans le guide d'utilisation. L'ouverture du produit ou le remontage inadéquat pourrait vous exposer à des tensions dangereuses ou autres dangers.

# For C-UL compliance

- ▶ Remplacez les piles uniquement tel que décrit dans votre guide d'utilisation (Page 6). N'incinerez pas et ne percez pas les piles — elles contiennent des produits chimiques caustiques.
- ▶ L'adaptateur de courant est conçu pour être orienté verticalement ou installé sur le plancher. Les broches ne sont pas conçues pour se maintenir en place si la fiche est branchée dans une prise de courant au plafond, sous la table ou sous une armoire.
- ▶ Pour les produits à brancher à une prise de courant, la prise de courant doit être installée près du produit, afin d'assurer une accessibilité sécuritaire à la prise de courant.



## MISES EN GARDE:

- ▶ N'utilisez seulement l'adaptateur inclus avec ce produit. Pour obtenir une pièce de rechange, visitez notre site Web au **<https://telephones.att.com>** ou composez le **1-800-222-3111**. Au Canada, composez le **1-866-288-4268**.



**ATTENTION:** Afin de prévenir les risques d'incendie ou d'explosion de la pile, remplacez la pile avec une pile du même type. Jetez les piles épuisées en respectant les instructions.

- ▶ Débrancher les lignes téléphoniques avant le remplacement des piles.

Évitez d'utiliser la batterie dans les conditions suivantes:

- ▶ des températures extrêmes faibles ou élevées auxquelles une batterie peut être soumise pendant l'utilisation, le stockage ou le transport.
- ▶ remplacement d'une batterie par un type incorrect pouvant supprimer une protection.
- ▶ mise au rebut d'une batterie dans un feu ou dans un four chaud, ou écrasement mécanique ou coupure d'une batterie, susceptible de provoquer une explosion.
- ▶ maintien d'une batterie dans un environnement à très haute température pouvant provoquer une explosion ou la fuite de liquide ou de gaz inflammables.
- ▶ batterie soumise à une pression de l'air extrêmement faible pouvant provoquer une explosion ou la fuite de liquide ou de gaz inflammables.
- ▶ N'utilisez que la pile de rechargeable incluse ou une pile de rechange (modèle BT267661). Pour commander, visitez notre site Web **<https://telephones.att.com>** ou composez le **1-800-222-3111**. Au Canada, composez le **1-866-288-4268**.
- ▶ La plaque signalétique appliquée est située au bas ou à proximité du produit.

# For C-UL compliance

## Spécifiquement en rapport avec les téléphones sans fil

- ▶ Confidentialité : Les mêmes caractéristiques qui rendent les téléphones sans fil si pratiques créent également des restrictions. Les appels téléphoniques sont transmis entre le socle du téléphone et le combiné par le biais d'ondes radio, et il se peut que vos conversations téléphoniques soient interceptées par d'autres équipements de réception d'ondes radio au sein de la portée du téléphone sans fil. Pour cette raison, vous ne devez pas considérer les conversations sur un téléphone sans fil comme étant aussi confidentielles que celles d'un téléphone à cordon.
- ▶ Alimentation électrique : La base de ce téléphone sans fil doit être branchée à une prise de courant électrique fonctionnelle. La prise électrique ne doit pas être contrôlée par un interrupteur mural. Les appels ne peuvent pas être effectués à partir du combiné si la base n'est pas branchée, si elle est hors fonction ou si le courant électrique est coupé.
- ▶ Interférences potentielles aux téléviseurs : Certains téléphones sans fil fonctionnent sur des fréquences pouvant causer des interférences aux téléviseurs et magnétoscopes. Pour réduire ou prévenir de tels parasites, ne pas déposer la base du téléphone sans fil à proximité d'un téléviseur ou magnétoscope, ni directement sur celui-ci. Si votre téléviseur affiche des interférences, éloignez le téléphone sans fil de celui-ci afin de réduire les parasites.
- ▶ Piles rechargeables : Ce produit comporte des piles rechargeables à l'hydrure métallique de nickel. Utilisez de prudence lorsque vous manipulez de telles piles et veillez à ne pas les court-circuiter avec des matériaux conducteurs, tels que des bagues, bracelets et clés. La pile ou le conducteur peut surchauffer et vous brûler. Respectez la polarité adéquate entre les piles et le chargeur de piles.  
Piles rechargeables à l'hydrure métallique de nickel : Jetez ces piles de manière sécuritaire. N'incinerez pas et ne percez pas les piles. Comme pour les autres piles du même type, si elles sont brûlées ou percées, des matières corrosives peuvent s'en échapper, ce qui risque de causer des brûlures ou autres blessures corporelles.



Le sceau de l'organisme de recyclage RBRC sur les piles à l'hydrure métallique de nickel signifie que le fabricant de cet appareil participe volontairement au programme industriel visant à reprendre et recycler ce type de piles lorsqu'elles ne servent plus, au sein du territoire des États-Unis et du Canada. Vous devez apporter ces piles chez un détaillant participant ou le centre de recyclage le plus près de chez vous. Ou vous pouvez composer le 1-800-8-BATTERY<sup>MD</sup> afin de connaître les endroits qui acceptent les piles à l'hydrure métallique de nickel mortes.

Le sceau RBRC et 1-800-8-BATTERY<sup>MD</sup> sont des marques déposées de Call2recycle, Inc.

# For C-UL compliance

## **Mesures préventives pour les utilisateurs de stimulateurs cardiaques implantés dans l'organisme**

---

Stimulateurs cardiaques (ne s'applique qu'aux téléphones sans fil numériques) :

L'organisme 'Wireless Technology Research, LLC (WTR)', une firme de recherche indépendante, a mené une évaluation pluridisciplinaire des interférences entre les téléphones sans fil portatifs et les stimulateurs cardiaques implantés dans l'organisme. Appuyée par l'Administration des aliments et drogues (FDA) des États-unis, la firme WTR recommande aux médecins :

### **Avis aux détenteurs de stimulateurs cardiaques:**

- ▶ Ils doivent tenir le téléphone sans fil à une distance d'au moins six pouces du stimulateur cardiaque.
- ▶ Ils ne doivent PAS placer le téléphone sans fil directement sur le stimulateur cardiaque, tel que dans une poche de chemise, lorsque celui-ci est en fonction.
- ▶ Ils doivent utiliser le téléphone sans fil en l'appuyant sur l'oreille qui se trouve dans la direction opposée au stimulateur cardiaque.

L'étude effectuée par l'organisme WRS n'a pas identifié de risque pour les détenteurs de simulateurs cardiaques causé par les gens qui utilisent un téléphone sans fil à proximité de ceux-ci.

### **Mode ECO**

---

Lorsque le socle communique avec le combiné, le mode ECO sera activé automatiquement. Ceci réduit la consommation d'énergie selon la distance entre le socle du téléphone et le combiné.

### **Spécifiquement en rapport avec les répondsurs téléphoniques**

---

Enregistrement deux voies : Cet appareil n'émet pas de bips d'avertissement qui permettent de prévenir l'autre partie que vous enregistrez la conversation. Pour assurer votre conformité aux règlements fédéraux ou provinciaux en rapport avec les enregistrements des conversations téléphoniques, vous devriez informer l'autre partie lorsque vous activez l'enregistrement.

## **CONSERVEZ CES INSTRUCTIONS**

# FCC Part 68 and ACTA

This equipment complies with Part 68 of the FCC rules and with technical requirements adopted by the Administrative Council for Terminal Attachments (ACTA). The label on the back or bottom of this equipment contains, among other things, a product identifier in the format US:AAAEQ##TXXXX. This identifier must be provided to your telephone service provider upon request.

The plug and jack used to connect this equipment to premises wiring and the telephone network must comply with the applicable Part 68 rules and technical requirements adopted by ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. An RJ11 jack should normally be used for connecting to a single line and an RJ14 jack for two lines. See the installation instructions in the user's manual.

The Ringer Equivalence Number (REN) is used to determine how many devices you may connect to your telephone line and still have them ring when you are called. The REN for this product is encoded as the 6th and 7th characters following the US: in the product identifier (e.g., if ## is 03, the REN is 0.3). In most, but not all areas, the sum of all RENs should be five (5.0) or less. For more information, please contact your telephone service provider.

This equipment must not be used with Party Lines. If you have specially wired alarm dialing equipment connected to your telephone line, ensure the connection of this equipment does not disable your alarm equipment. If you have questions about what will disable the alarm equipment, consult your telephone service provider or a qualified installer.

If this equipment is malfunctioning, it must be unplugged from the modular jack until the problem has been corrected. Replacement to this telephone equipment can only be made by the manufacturer or its authorized agents. For replacement procedures, follow the instructions outlined under the Limited warranty.

If this equipment is causing harm to the telephone network, the telephone service provider may temporarily discontinue your telephone service. The telephone service provider is required to notify you before interrupting service. If advance notice is not practical, you will be notified as soon as possible. You will be given the opportunity to correct the problem and the telephone service provider is required to inform you of your right to file a complaint with the FCC. Your telephone service provider may make changes in its facilities, equipment, operation, or procedures that could affect the proper functioning of this product. The telephone service provider is required to notify you if such changes are planned.

If this product is equipped with a corded or cordless handset, it is hearing aid compatible.

If this product has memory dialing locations, you may choose to store emergency telephone numbers (e.g., police, fire, medical) in these locations. If you do store or test emergency numbers, please:

- ▶ Remain on the line and briefly explain the reason for the call before hanging up.
- ▶ Perform such activities in off-peak hours, such as early morning or late evening.

## Industry Canada

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

Privacy of communications may not be ensured when using this telephone.

The term "IC:" before the certification/registration number only signifies that the Industry Canada technical specifications were met.

The Ringer Equivalence Number (REN) for this terminal equipment is 0.1. The REN indicates the maximum number of devices allowed to be connected to a telephone interface. The termination of an interface may consist of any combination of devices subject only to the requirement that the sum of the RENs of all the devices not exceed five.

This product meets the applicable Innovation, Science and Economic Development Canada technical specifications.

## FCC Part 15

NOTE: This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ▶ Reorient or relocate the receiving antenna.
- ▶ Increase the separation between the equipment and receiver.
- ▶ Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ▶ Consult the dealer or an experienced radio/TV technician for help.

WARNING: Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Privacy of communications may not be ensured when using this telephone.

To ensure safety of users, the FCC/ISED has established criteria for the amount of radio frequency energy that can be safely absorbed by a user or bystander according to the intended usage of the product. This product has been tested and found to comply with the FCC/ISED criteria. The handset may be safely held against the ear of the user. The telephone base shall be installed and used such that parts of the user's body other than the hands are maintained at a distance of approximately 20 cm (8 inches) or more.

This Class B digital apparatus complies with Canadian requirement:  
CAN ICES-3 (B)/NMB-3(B)

## Limited warranty

The AT&T brands are used under license. This product is covered by a one-year limited warranty. Any replacement or warranty service, and all questions about this product, should be directed to our website at

**<https://telephones.att.com>** or call **1 (800) 222-3111**. In Canada, dial **1 (866) 288-4268**.

### 1. What does this limited warranty cover?

The manufacturer of this AT&T Product, Advanced American Telephones, warrants to the holder of a valid proof of purchase ("Consumer" or "you") that the Product and all accessories provided by Advanced American Telephones in the sales package ("Product") are free from material defects in material and workmanship, pursuant to the following terms and conditions, when installed and used normally and in accordance with operation instructions. This limited warranty extends only to the Consumer for Products purchased and used in the United States of America and Canada.

### 2. What will Advanced American Telephones do if the Product is not free from material defects in materials and workmanship during the limited warranty period ("Materially Defective Product")?

During the limited warranty period, Advanced American Telephones' authorized service representative will replace, at Advanced American Telephones' option, without charge, a Materially Defective Product. If we choose to replace this Product, we may replace it with a new or refurbished Product of the same or similar design. Advanced American Telephones will return replacement Products to you in working condition.

Advanced American Telephones will retain defective parts, modules, or equipment. Replacement of Product, at Advanced American Telephones' option, is your exclusive remedy. You should expect the replacement to take approximately 30 days.

### 3. How long is the limited warranty period?

The limited warranty period for SynJ® and Syn248® products is TWO (2) YEARS from the date of purchase, while all other products limited warranty period is ONE (1) YEAR from the date of purchase. If we replace a Materially Defective Product under the terms of this limited warranty, this limited warranty also applies to replacement Products for a period of either (a) 90 days from the date the replacement Product is shipped to you or (b) the time remaining on the original one-year limited warranty, whichever is longer.

### 4. What is not covered by this limited warranty?

This limited warranty does not cover:

Product that has been subjected to misuse, accident, shipping or other physical damage, improper installation, abnormal operation or handling, neglect, inundation, fire, water or other liquid intrusion; or

Product that has been damaged due to repair, alteration or modification by anyone other than an authorized service representative of Advanced American Telephones; or

Product to the extent that the problem experienced is caused by signal conditions, network reliability or cable or antenna systems; or

Product to the extent that the problem is caused by use with non-Advanced American Telephones electrical accessories; or

Product whose warranty/quality stickers, Product serial number plates or electronic serial numbers have been removed, altered or rendered illegible; or

Product purchased, used, serviced, or shipped for repair from outside the United States, or used for commercial or institutional purposes (including but not limited to Products used for rental purposes); or

Product returned without valid proof of purchase (see item 6); or

Charges for installation or set up, adjustment of customer controls, and installation or repair of systems outside the unit.

### 5. How do you get warranty service?

To obtain warranty service in the United States of America, visit

**<https://telephones.att.com>** or call **1 (800) 222-3111**. In Canada, please dial **1 (866) 288-4268**.

NOTE: Before calling for service, please check the user's manual. A check of the Product controls and features may save you a service call.

Except as provided by applicable law, you assume the risk of loss or damage during transit and transportation and are responsible for delivery or handling charges incurred in the transport of Product(s) to the service location. Advanced American Telephones will return replaced Product under this limited warranty to you, transportation, delivery or handling charges prepaid. Advanced American Telephones assumes no risk for damage or loss of the Product in transit.

## **6. What must you return with the PRODUCT to get warranty service?**

- ▶ Return the entire original package and contents including the Product to the Advanced American Telephones service location along with a description of the malfunction or difficulty;
- ▶ Include “valid proof of purchase” (sales receipt) identifying the Product purchased (Product model) and the date of purchase or receipt; and
- ▶ Provide your name, complete and correct mailing address and telephone number.

## **7. Other limitations**

This warranty is the complete and exclusive agreement between you and Advanced American Telephones. It supersedes all other written or oral communications related to this Product. Advanced American Telephones provides no other warranties for this Product. The warranty exclusively describes all of Advanced American Telephones’ responsibilities regarding the Product. There are no other express warranties. No one is authorized to make modifications to this limited warranty and you should not rely on any such modification.

**State/Provincial Law Rights:** This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

**Limitations:** Implied warranties, including those of fitness for a particular purpose and merchantability (an unwritten warranty that the Product is fit for ordinary use) are limited to one year from date of purchase. Some states/provinces do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

In no event shall Advanced American Telephones be liable for any indirect, special, incidental, consequential, or similar damages (including, but not limited to lost profits or revenue, inability to use the Product, or other associated equipment, the cost of substitute equipment, and claims by third parties) resulting from the use of this Product. Some states/provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

**Please retain your original sales receipt as proof of purchase.**

# Technical specifications

|                                                                                  |                                            |                                                              |
|----------------------------------------------------------------------------------|--------------------------------------------|--------------------------------------------------------------|
| RF frequency band                                                                |                                            | 1921.536MHz — 1928.448MHz                                    |
| Channels                                                                         |                                            | 5                                                            |
|  | Telephone base voltage (DC adapter output) | 6VDC @0.4A                                                   |
|                                                                                  | Charger voltage (DC adapter output)        | 6VDC @0.4A                                                   |
| Handset voltage                                                                  |                                            | 2 x 1.2V Ni-MH battery                                       |
| Operating times*                                                                 |                                            | Talk time (handset): up to 10 hours<br>Standby: up to 6 days |

\* Operating times vary depending on your actual use and the age of the battery.

Company: Advanced American Telephones

Address: 9020 SW Washington Square Road - Ste 555 Tigard, OR 97223, United States.

Phone: 1 (800) 222-3111 in the U.S. or 1 (866) 288-4268 in Canada



Recycle this product when you are done with it

Scan the QR code or visit **telephones.att.com/recycle**  
(For the US only)



Telephones identified with this logo have reduced noise and interference when used with most T-coil equipped hearing aids and cochlear implants. The TIA-1083 Compliant Logo is a trademark of the Telecommunications Industry Association. Used under license.



The ENERGY STAR® program ([www.energystar.gov](http://www.energystar.gov)) recognizes and encourages the use of products that save energy and help protect our environment. We are proud to supply this product with an ENERGY STAR® qualified power adapter meeting the latest energy efficiency guidelines.

The Bluetooth® word mark and logos are owned by Bluetooth SIG, Inc. and any use of such marks by Advanced American Telephones and its parent, VTech Holdings Limited, is under license. VTech Holdings Limited is a member of Bluetooth SIG, Inc. Other trademarks and trade names are those of their respective owners.

©2025 Advanced American Telephones. All Rights Reserved.

AT&T and the AT&T logo are trademarks of AT&T Intellectual Property licensed to Advanced American Telephones, San Antonio, TX 78219.

Qaltel™ is a trademark of Truecall Group Limited.

Audio Assist® is a registered trademark of Advanced American Telephones.

SynJ® and Syn248® are trademarks of Advanced American Telephones.

The RBRC Seal and 1-800-8-BATTERY® are registered trademarks of Call2recycle, Inc.  
Issue 1.0 AT&T 05/25.