

What's in the box

- Device
- Charging Cable

How to Set Up the Device

1. Press and hold the crown on the device for 3 seconds.
2. Unlock your phone and turn on Bluetooth. Connect the device with your phone through Bluetooth.
3. Follow the setup instructions on your phone to finish the setting up.

How to Charge the Device

1. Plug the Magnetic Charging Cable into a USB power adapter.
2. Plug the adapter into a power outlet. Or plug the charging cable into a USB port directly.
3. Position the back of your device on the charger. The charger's magnets align your device, and you'll see the battery charging icon on the screen of the device.



WARNING: HEALTH AND SAFETY INFORMATION

To avoid damaging your device, accessories or any connected devices, and to reduce the risk of personal injury, discomfort, property damage or other potential hazards, follow these precautions below :

- Handle your Magnetic Charging Cable with care. You may damage the device if you disassemble, drop, bend, burn, crush or puncture your device. Using a damaged Magnetic Charging Cable, damaged cables or power adapter or charging when moisture or debris is present, may cause overheating, fire, electric shock, injury or damage to your charging cable or other property. Do not expose your USB-C Magnetic Charging Cable to liquids, which can cause a short circuit and overheating. If the charging cable gets wet, do not attempt to dry it using an external heat source. Your Magnetic Charging Cable is designed to work best in ambient temperatures between 32° and 95° F (0° and 35° C), and should be stored between ambient temperatures of -4° and 113° F (-20° and 45° C). Do not expose your Magnetic Charging Cable to temperatures above 113° F (45° C) as this may damage the product and pose a risk of fire. Avoid using the wireless charger in direct sunlight.

- This product must be used with a certified AC adapter with Limited Power Source (LPS) output per IEC 60950-1 and/or PS2 classified output per IEC 62368-1, rated: 5 Volts 1 Amp. Failure to use compatible accessories can cause fire, electric shock, injury, or damage to the Magnetic Charging Cable and the accessories.
- Be sure the power adapter and the charging cable are well ventilated when in use or charging. Using damaged cables or power adapters, or charging when moisture is present, can cause fire, electric shock, injury, or damage to the wireless charger or other property. When powering the wireless charger, make sure the power adapter is plugged into a socket near the wireless charger and is easily accessible.
- Do not place metallic or magnetic foreign objects between the wireless charger and the power receiver, as this could cause heating of the foreign object or cause the device not to charge properly. Examples of these objects include coins, jewelry, and credit cards.
- Maintain a distance of 20 cm (8 inches) from your body while charging to be consistent with how the device is tested for compliance with RF exposure requirements.
- Strangulation hazard. This device is not a toy. Children have strangled on cords. Keep cords out of the reach of children (more than 3 feet / 1 meter away).

Proper Handling and Usage

Care and Cleaning

Turn off your watch. Wipe your device with a damp cloth (no soap). Let air-dry or wipe with a non-abrasive cloth.

Water Resistance

Your device is designed to comply with water protection rating 5 ATM water resistance in accordance with under ISO Standard 22810:2010 when manufactured, but it is not waterproof. Water resistance is not a permanent condition, and decreases or is lost over time due to normal wear and tear, repair, disassembly, or damage. Dropping or otherwise impacting your device may result in a loss of water resistance. Deep water activities such as scuba diving or snorkeling, activities where high velocity streams of water, such as may be present, such as when diving, surfing, or water skiing, and exposure to water at high temperature, such as in a steam room or hot tub, may damage your device and should be avoided. Do not expose your device to substances such as sunscreen, soap, lotion, oil, insect repellent, perfume, alcohol or other liquids which may compromise water resistance or otherwise damage your device. Clean

and dry your device after exposure to liquids. The charger and other accessories, including some wristbands are not water resistant and should not be exposed to liquids.

EMC compliance statement

Important: This device, and other in-box accessories have demonstrated Electromagnetic Compatibility (EMC) compliance under conditions that included the use of compliant peripheral devices and shielded cables between system components. It is important that you use compliant peripheral devices and shielded cables between system components to reduce the possibility of causing interference to radios, televisions and other electronic devices.

Regulatory Information

Regulatory information, certification, and compliance marks specific to this device can be found on your device under **Settings -> System > Regulatory Information**. Additional regulatory and environmental information can be found at [\[g.co/googlewatch/xxx\]](https://g.co/googlewatch/xxx).

Regulatory information, certification, and compliance marks specific to the USB-C Magnetic Charging Cable can be found on the power cord and USB connector of your device. Additional regulatory and environmental information can be found at [\[g.co/googlewatch/xxx\]](https://g.co/googlewatch/xxx)

Manufacturer address: Google LLC, 1600 Amphitheatre Parkway, Mountain View, CA 94043.

Radio Frequency Exposure

This device has been tested and meets applicable limits for Radio Frequency (RF) exposure. To ensure the exposure levels remain at or below the as-tested levels, during the operation the device should be positioned at least 10 mm distance away from your face/head.

To comply with applicable RF exposure compliance requirements, a distance of at least 20 cm should be maintained between the USB-C Magnetic Charging Cable and a person's body during charging.

FCC Regulatory Compliance

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with

the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by Google could void your authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following 2 conditions:

1. This device may not cause harmful interference.
2. The device must accept any interference received, including interference that may cause undesired operation.

Model Numbers: GWT9R (Device), G943M (charging cable)

Responsible Party:

Google LLC

1600 Amphitheatre Parkway

Mountain View, CA 94043

g.co/pixelwatch/help

Regulatory Information: Canada

Industry Canada (IC), Class B

This Class B digital apparatus complies with CAN ICES-3(B)/NMB-3(B).

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

The device complies with IC license-exempt RSS standard(s). Operation is subject to the following two conditions:

1. This device may not cause interference, and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'IC Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes;

1. l'appareil ne doit pas produire de brouillage, et
2. l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.